

Log-in Checklist

RQ-2019-07-29-16

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 07/30/19 @ 10:10

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.3°C				12		X			4751 8781 7343

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes No X

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No X If yes, is it intact? Yes No

**Caps on tight? Yes ✓ No **Containers intact? Yes ✓ No

**Sufficient Sample Volume: Yes ✓ No

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes No X Init: Jyln

Chlorine detected? (One container checked per Field ID) Yes No Init:

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ✓ No NA Init: Jyln

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA X Init: Jyln

Coolers Unpacked/Checked by: Jyln Reynolds Date: 07/30/19 NCRs (Y/N)? N

Event ID: 2019 SMP : P Riv NCR #

S0-DIST-2019-07-30-02 (SMP)

Date Received: 30-JUL-2019 10:10

Log-in Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle TestID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle TestID(s)

Bottles Not Intact

Field ID	Bottle TestID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle TestID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_04_2018 EXP:04/29/2020
pH Test Strips 0 – 6 Lot #	213316AV EXP:05/15/2020
pH Paper 0 – 3 Lot #	
pH Paper 0 – 13 Lot #	215517 EXP: 06/01/2020
Chlorine Test Strips Lot #	8261 EXP: 07/30/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: SO-DIST

Requester: Nicole Reistad

Field Report Prepared By: MARYANN DUGAN

Project ID: SMP

Collected By: MARYANN DUGAN, MIRANDA CARROLLSampling Agency: S ROC

Location		Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab)	Eastern Central	Composite end	Bottle Group(s)
Field ID		Location		Date		Time		(See pg 2)
WIN/STORET #		Alligator N@JonesLoopRd		Date		Time		
Latitude		☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments		
Field ID		Location		Date		Time		A
WIN/STORET #		G2SD0032		Date		Time		
Latitude		☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments		
Field ID		Location		Date		Time		B
WIN/STORET #		G3SD0148		Date		Time		
Latitude		☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments		
Field ID		Location		Date		Time		A
WIN/STORET #		G3SD0154		Date		Time		
Latitude		☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments		
Field ID		Location		Date		Time		A
WIN/STORET #		PeaceRiver HorseCreek2		Date		Time		
Latitude		☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments		
Field ID		Location		Date		Time		
WIN/STORET #				Date		Time		
Latitude		☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments		

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
<u>Maryann Dugan</u>	<u>07/29/2019</u>	<u>FEDEX</u>	<u>1</u>	<u>J. R.</u>	<u>07/30/19 @ 10:10</u>

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>2</u>
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>2</u>
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WI-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>0 (2 @ Benchmark)</u>
	SD-BES-ECQ						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>2</u>
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	<u>2</u>
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS						
Group: B	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	CHLSUITE-W						
Group: B	Bottle Type:	P-250ML-WI-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>0 (1 @ Benchmark)</u>
	SD-BES-ENQ						
Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-NH3						

SA7163030
06/2/18

Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					

Group: B	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-PO4-F					

Printed: 7/30/2019 11:31:52 AM

Page 1 of 2

Date of Request: 18-JUN-2019
 Created By: REISTAD_N On: 18-JUN-2019
 Modified By: JASROTIA_P On: 11-JUL-2019
 Customer: SO-DIST
 Project: SMP
 Division:
 District: South District
 Sampling Event: 2019 SMP : P Riv

Send Coolers To:

Phone: 239-344-5718
 FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad

Program Module Number:

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 11-JUL-2019
 Biology Request Reviewed By: JASROTIA_P On: 11-JUL-2019
 Sampling Kit Required: YES Ship on: 19-JUL-2019
 Sampling Kit Shipped: YES On: 15-JUL-2019
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 29-JUL-2019
 Received By:

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: (2071, 1623B) Freshwater Nutrients, E.coli
 Group B: (2056C2) Saltwater Nutrients, Entero

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 2	Preserved With: ICE
SD-BES-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) E. coli by Colilert/QT by BEA South in North Port
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Printed: 7/30/2019 11:31:52 AM

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-BES-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert/QT by BEA South in North Port
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices