

RQ- 2019 - 10-21-31

Log-in Checklist

Login Station ID: # 3Shipping Method: FedEx | UPS | HD | GreyhoundDate/Time of Receipt: 10-23-2019 / 09:55

Cooler Temperature*	Samples Frozen	* All Samples In Cooler Preserved with		Number of Sample Containers In Cooler	Evidence Tape				Tracking # Damaged waybills only	
		YES	HNO ₃		Formalin	Present?		*Intact?		
						Yes	No	Yes		No
<u>1.9C</u>				<u>8</u>		<u>X</u>			<u>1278 4008 1980</u>	

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.

**Chain of Custody/ Field Sheet(s) Included? Yes X No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes No X

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No X If yes, is it intact? Yes No
 **Caps on tight? Yes X No **Containers intact? Yes X No
 **Sufficient Sample Volume: Yes X No

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes No Init: ABS

Chlorine detected? (One container checked per Field ID) Yes No Init: ABS

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes X No NA Init: ABS

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No X NA Init: ABS

Coolers Unpacked/Checked by: ABS Date: 10-23-2019 NCRs (Y/N)?

Event ID: 2019 SMP : Josephine NCR #
SO-DIST-2019-10-23-01 (SMP)

Log-in Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle Test ID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC 03 2018 EXP:04/29/2020
pH Test Strips 0 – 6 Lot #	213316AV EXP:05/15/2020
pH Paper 0 – 3 Lot #	220416A EXP:07/30/2020
pH Paper 0 – 13 Lot #	215517 exp:jun 1 2020
Chlorine Test Strips Lot #	8212 2021 / 05

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No **X**

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: SO-DIST

Requester: Nicole Reistad

Field Report Prepared By:

Project ID: SMP

Collected By:

Gary Snorek, Nicole Reistad

Sampling Agency:

Nicole Reistad
FDEP-SOROC

Location	Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab)	Eastern Central	Composite end	Bottle Group(s)
Field ID	Location	G4SD0104	Date	10/22/19	Time	1100	(See pg 2)
WIN/STOR	Josephine Creek EofCR17		Matrix (type, e.g., Salt, Fresh, etc)	Fresh	Diss. Oxygen	61.0%/4.89 mg/L	
			Temp (C)	26.6	pH	5.42	
			Salinity (ppt)	0.05	Comments	total depth: 0.6m secchi: 0.6m	
Location	Field ID		☐ Comp ☒ Grab	Collection (comp begin or grab)	Eastern Central	Composite end	Bottle Group(s)
Field ID	Josephine Creek EofCR17	G4SD0104_DUP	Date	10/22/19	Time	1105	
WIN/STOR	WIN ID	G4SD0104	Matrix (type, e.g., Salt, Fresh, etc)	Field Replicate	Diss. Oxygen	NR 61.0%/4.89 mg/L	
			Temp (C)	26.6 NR	pH	5.42	
			Salinity (ppt)	0.05 NR	Comments		
Location	Field ID		☐ Comp ☐ Grab	Collection (comp begin or grab)	Eastern Central	Composite end	Bottle Group(s)
Field ID			Date		Time		
WIN/STOR			Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		
			Temp (C)		pH		
			Salinity (ppt)		Comments		
Location	Field ID		☐ Comp ☐ Grab	Collection (comp begin or grab)	Eastern Central	Composite end	Bottle Group(s)
Field ID			Date		Time		
WIN/STOR			Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		
			Temp (C)		pH		
			Salinity (ppt)		Comments		

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
Nicole Reistad	10/22/19 1400	FedEx	1	AR	10-23-19

aa-55

Group: A Bottle Type: P-1L # of Bottles: 2 Preservative: ICE Enter Number of Bottles Sent to Lab 2

ALKALINITY
TURBIDITY
W-CL-IC
W-COLOR
W-F
W-SO4-IC
W-TDS
W-TSS

Group: A Bottle Type: BP-1L # of Bottles: 2 Preservative: ICE Enter Number of Bottles Sent to Lab 2

CHLSUITE-W

Group: A Bottle Type: P-500ML # of Bottles: 2 Preservative: ICE And H2SO4 Enter Number of Bottles Sent to Lab 2

W-NH3
W-NO2NO3
W-S-A-TP
W-TKN
W-TOC

SA9129100
exp. 05/09/20

Group: A Bottle Type: P-125ML # of Bottles: 2 Preservative: FILTER-ICE Enter Number of Bottles Sent to Lab 2

W-PO4-F

Date of Request: 30-SEP-2019
 Created By: REISTAD_N On: 30-SEP-2019
 Modified By: JASROTIA_P On: 07-OCT-2019
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Sampling Event: 2019 SMP : Josephine

Send Coolers To:

Phone: 239-344-5718
 FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad

Program Module Number:
 Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 07-OCT-2019
 Biology Request Reviewed By: JASROTIA_P On: 07-OCT-2019
 Sampling Kit Required: YES Ship on: 11-OCT-2019
 Sampling Kit Shipped: YES On: 11-OCT-2019
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: NO
 Date to Receive Samples: 21-OCT-2019
 Received By: SHAIK_A On: 23-OCT-2019

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: Freshwater Nutrients + DUPLICATE

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H₂SO₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L