

RQ-2019-10-21-70

Login Checklist

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 10/22/2019 @ 10:10

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
		YES	HNO ₃		Formalin	Present? Yes No	*Intact? Yes No		
1.4°C				6		x			4751 8776 8650

*All samples received on ice unless otherwise noted. If the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), received without ice, or if Evidence Seal is damaged; identify the containers in the affected cooler(s) on back of this form. HNO₃ and Formalin preserved samples do **NOT** have a temperature requirement. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation; An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes No X

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No X If yes, is it intact? Yes No

**Caps on tight? Yes ✓ No **Containers intact? Yes ✓ No

**Sufficient Sample Volume: Yes ✓ No

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ✓ No Init: Jyle P.

Chlorine detected? (One container checked per Field ID)

Yes No X Init: Jyle P.

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ✓ No NA Init: Jyle P.

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA X Init: Jyle P.

Coolers Unpacked/Checked by: Jyle Reynolds Date: 10/22/2019

NCRs (Y/N)? N

EventID: 2019 Roberts Canal

NCR #

SO-DIST-2019-10-22-02 (SMP)

Date Received: 22-OCT-2019 10:10

Login Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle Test ID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Infrared Thermometer ID:	REC_04_2018 EXP:04/29/2020
pH Test Strips 0 – 6 Lot #	213316AV EXP:05/15/2020
pH Paper 0 – 3 Lot #	N/A
pH Paper 0 – 13 Lot #	215517 EXP: 06/01/2020
Chlorine Test Strips Lot #	8261 EXP: 07/30/2021

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: SO-DIST

Requester: Gary Snorek

Field Report Prepared By:

JOHN BARRINGTON

Project ID: SMP

Collected By: GARY SNOREK

Sampling Agency: FDEP SR00C 8052

Field ID/WIN ID				☐ Comp ☒ Grab		Collection (comp begin or grab) Date 10/21/19 Time 1115		☒ Eastern ☐ Central		Composite end Date Time		Bottle Group(s) (See pg 2)	
Location		G3SD0146		Matrix (type, e.g., Salt, Fresh, etc) Fresh		Diss. Oxygen 4.30		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		A	
		Robert's Canal @SR80		Temp (C) 27.1		pH 7.38		Sample Depth 0.3		☐ ft ☒ m			
Latitude		☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt) 0.23		Comments SECCAT VISIBILITY BOTTOM			
Location				☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		☐ Eastern ☐ Central		Composite end Date Time		Bottle Group(s)	
Field ID				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #				Temp (C)		pH		Sample Depth		☐ ft ☐ m			
Latitude		☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt)		Comments			
Location				☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		☐ Eastern ☐ Central		Composite end Date Time		Bottle Group(s)	
Field ID				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #				Temp (C)		pH		Sample Depth		☐ ft ☐ m			
Latitude		☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt)		Comments			
Location				☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		☐ Eastern ☐ Central		Composite end Date Time		Bottle Group(s)	
Field ID				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #				Temp (C)		pH		Sample Depth		☐ ft ☐ m			
Latitude		☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt)		Comments			
Location				☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		☐ Eastern ☐ Central		Composite end Date Time		Bottle Group(s)	
Field ID				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #				Temp (C)		pH		Sample Depth		☐ ft ☐ m			
Latitude		☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt)		Comments			

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
JOHN BARRINGTON	10/21/19 1400	FEDEX	1	TK	10/22/19 @ 10:10

Group: A

Bottle Type:

of Bottles:

0

7

Preservative:

Enter Number of Bottles Sent to Lab

6

ALKALINITY

CHLSUITE-W

PCR-BACR

SD-SND-ECQ

TURBIDITY

W-CL-IC

W-COLOR

W-F

W-NH3

W-NO2NO3

W-PO4-F

W-S-A-TP

W-SO4-IC

W-TDS

W-TKN

W-TOC

W-TSS

PCR-HF183

W-E8321-DI

W-E8321-MS

ICE

+SA7163030

EXP RECEIPT

10/30/19

* Ecou SENT TO SANDERS OVERFLOW LAB

Date of Request: 21-OCT-2019
 Created By: SNOREK_G On: 21-OCT-2019
 Modified By: JASROTIA_P On: 22-OCT-2019
 Customer: SO-DIST
 Project: SMP
 Division:
 District: South District
 Sampling Event: 2019 Roberts Canal

Send Coolers To:

Phone: 239-344-5718
 FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Gary Snorek

Program Module Number:
 Priority: 3
 Event Status: A
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 21-OCT-2019
 Biology Request Reviewed By: JASROTIA_P On: 22-OCT-2019
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 21-OCT-2019
 Received By:

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: nutrients, PCR-HF183T, PCR-BacR, T, E.coli

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: P-120ML-WC-THI	Number of Bottles: 2	Preserved With: ICE
SD-SND-ECQ	Template: DEFAULT	(Colilert-18) E. coli by Colilert-18/QT by Sanders in Fort Myers
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.