



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION STRATEGIC MONITORING PROGRAM FIELD SHEET

January 2019

Data Qualified?

Yes / No

WIN Station Name: **Sugar Creek @ Suwannee River**

Date: **3/18/19**

WIN/ Field ID: **G1TLHR0047**

WBID: **3389**

Latitude: **30.39809905**

County: **HAMILTON**

ORG ID: **21FTLHR**

Longitude: **-82.93431**

Receiving Body of Water: **Suwannee River**

RQ: **2019-02-11-6**

Sampling Team Members					WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check
Son Woods Paul Blair					X	X	X	X	X

Sampling Equipment		
☒ Sample Container	☐ Van Dorn	☐ Pole
☐ Carboy	☒ Syringe	
☐ Dipper	☐ Other	
Depth Measured with YSI		
Equipment ID 153444		

Collection Method		
☒ Wading	☐ Canoe/Kayak	
☐ From Shore	☐ Electric Motor	
☐ Other	☐ Gasoline Motor	

Water Level: Dry/ Pooled/ Low / Normal / High / Flooded
Photos: Yes No Flow: No Flow / Intestinal / Flowing / NA
Meter ID# **153444** Matrix: Fresh Marine / DI
Tide: Rising/ Falling/ Slack/ NA Tide Times: High Low

Time Zone	Time	Total Depth (m)	Sample Depth (m)	Secchi Disk (m)	DO (mg/L)	DO (%SAT)	pH	Salinity (PPT)	Sp COND (µmhos/cm)	Temp. (C°)
EST	1140	0.3	0.15	0.3	10.47	100.4	7.26	0.05	113.2	13.7
CEN				S						

Biological Samples Collected: None HA SCI RPS Algae ID LVS LVI Other:

SBIO ID Numbers: SBIO-ID: HA-ID: RPS-ID: Macrophyte-ID: LIMS#:

Parameter Suite	Parameter Methods	Preservation	Lot#	Expiration	pH Check
Preserved Nutrients	☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP	☒ Ice ☒ H2SO4	8344070	10/12/19	☒ <2
Metals	☐ W-ICPMS ☐ W-ICP	☐ Ice ☐ HNO3		12/10/19	☐ <2
Filtered Nutrients	☒ W-PO4-F ☒ Field Filtered 0.45 µm Filter	☒ Ice			
Chlorophyll	☒ CHLSUITE-W	☒ Ice			
Physical/Aggregate (Fresh)	☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS	☒ Ice			
Physical/Aggregate (Marine)	☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	☐ Ice			
Macroinvertebrates	☐ MI-FW-QLDC	☐ Formalin			
Periphyton	☐ ALGAE-ID	☐ Ice			
Microbiology	☒ E Coli ☐ F Coli ☐ Enterococci	☒ Ice			
Molecular	☒ PCR-FILTER ☐ PCR-BacR ☐ PCR-GULL2 ☐ PCR-HF183 ☐ PCR-DG3 ☐ PCR-GFD	☒ Ice			
Tracers	☒ W-E8321-DI ☒ W-E8321-MS	☒ Ice			
Pesticides	☐ W-PSNP-TQ ☐ W-CT-CL-R ☐ W-E8321-DI ☐ W-PCL-SQ-R ☐ WE8321-MS ☐ W-CARB-AA	☐ Ice			
Phytoplankton	☐ DTY-QN-C ☐ PKD-QN-C	☐ Ice			

Place Label Here

Signature: *[Signature]*

Date: **3/18/19**

LIMS EVENT ID: WIN Import ID:

Enter Field Parameters, Verify Station ID In LIMS DMT: QC Station ID, Field Parameters In LIMS DMT:

Scan/Save Field Sheets (Initials/Date) Migrate Data to WIN: (Initials/Date) Verify Data In WIN: (Initials/Date)

Customer: TLH-ROC

Project ID: SMP

Requester: Michael Eckles

Collected By:

Field Report Prepared By: J. Woods

Sampling Agency:

Relinquished By: <i>Wood's</i>	Date/Time <i>3/15/9 1608</i>	Shipping Method <i>HO</i>	Number of Coolers Shipped: <i>2</i>	Received By: <i>[Signature]</i>	Date/Time <i>3/15/9 1610</i>
-----------------------------------	---------------------------------	------------------------------	--	------------------------------------	---------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WO-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	ECOLL-18QT						
Group: A	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	PCR-FILTER						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	W-E8321-DI						
	W-E8321-MS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	HNO3	Enter Number of Bottles Sent to Lab	2
	W-ICP						
	W-ICPMS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	2
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	2
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						

lot # 8344070
exp. 12/10/19

lot # 8344050
exp. 12/10/19

Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	/
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: B	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	/
	CHLSUITE-W						
Group: B	Bottle Type:	P-250ML-WO-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	/
	ECOLI-18QT						
Group: B	Bottle Type:	QPCR-P-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	/
	PCR-FILTER						
Group: B	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	/
	W-E8321-DI						
	W-E8321-MS						
Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	ICE	Enter Number of Bottles Sent to Lab	/
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: B	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	/
	W-PO4-F						
Group: C	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	/
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: C	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	/

Group: C	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: P-250ML-WO-THI ECOLI-18QT		# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: QPCR-P-500ML PCR-HF183		# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: BG-500ML W-E8321-DI W-E8321-MS		# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: P-500ML W-ICP W-ICPMS		# of Bottles: 2	Preservative: HNO3 834050 12/10/19	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: P-500ML W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC		# of Bottles: 2	Preservative: ICE And H2SO4 834070 12/10/19	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: P-125ML W-PO4-F		# of Bottles: 2	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	1
Group: D	Bottle Type: P-1L ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS		# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	
Group: D	Bottle Type: BP-1L CHLSUITE-W		# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	
Group: D	Bottle Type: P-500ML		# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	

Group: D	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab
	W-NH3				
	W-NO2NO3				
	W-S-A-TP				
	W-TKN				
	W-TOC				
Group: D	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab
	W-PO4-F				
Group: E	Bottle Type:	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab
	ALKALINITY				
	TURBIDITY				
	W-CL-IC				
	W-COLOR				
	W-F				
	W-SO4-IC				
	W-TDS				
	W-TSS				
Group: E	Bottle Type:	P-250ML-WO-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab
	ECOLI-18QT				
Group: E	Bottle Type:	QPCR-P-500ML	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab
	PCR-HF183				
Group: E	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab
	W-E8321-DI				
	W-E8321-MS				
Group: E	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: HNO3	Enter Number of Bottles Sent to Lab
	W-ICP				
	W-ICPMS				
Group: E	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab
	W-NH3				
	W-NO2NO3				
	W-S-A-TP				
	W-TKN				
	W-TOC				

Group: E	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab
W-PO4-F						

CALIBRATION AND VERIFICATION LOG (FDEP SOP FT 1000-FT 1500, FD 1000-FD 4000)

Boldly "X" this box if there are qualified data on this page.

Meter ID: 153484

RQ: 2019-02-11-C1

Project: SMP1903

Notes: (1) Always wait for meter to stabilize before recording any readings.

(2) Report all digits displayed. Do not round before reporting measurements. (See special instructions for depth).

(3) For Calibrations, record calibrated meter reading. Do not record initial meter reading before calibration.

Temperature (Quarterly) FT 1400

Date of Last Temperature Verification 12/31/16

DO DEP SOP FT 1500	Name	Date	Time CT-ET	Temp °C	Baro- meter mmHg	D.O. Chart mg/L	Meter D.O. mg/L	% DO	Probe Charge	Probe Gain	Pass / Fail	Lab / Field
Calibr.	Don Woods	3/18/19	455	20.1	761.7	9.07	9.09	100.3	—	1.06	P/F	L/F
ICV	"	"	910	20.5	761.9	9.00	9.05	100.7	—	—	P/F	L/F
CCV	"	"	1535	15.2	763.4	10.11	10.18	101.0	—	—	P/F	L/F
CCV											P/F	L/F

DO Acceptance criteria from Table ± 0.3 mg/L.

Rapid-Pulse Sensors: DO Gain Range 0.7 to 1.4; DO Charge Range 25-75.

Optical: DO gain range 0.85 to 1.15 (Pro DSS 0.75 to 1.50); DO charge N/A. Steady-state & Galvanic Sensors: DO Gain & Charge N/A.

Spec. Cond. FT 1200	Name	Date	Time CT-ET	Lot #	Expir. Date	Standard μ hos/cm	Meter Reading μ hos/cm	Pass / Fail	Lab / Field
Calibr.	Don Woods	3/18/19	856	180621C	7/2019	1000	1000	P/F	L/F
ICV	"	"	909	1805F61	5/2020	100	102.4	P/F	L/F
CCV	"	"	1537	180927E	10/2019	1000	996	P/F	L/F
CCV								P/F	L/F

Conductivity Acceptance criteria $\pm 5\%$

pH DEP SOP FT 1100	Name	Date	Time CT-ET	Lot #	Expir. Date	pH Buffer SU	Temp °C	Meter reading SU	mV	Pass / Fail	Lab / Field
Calibr.	Don Woods	3/18/19	900	180403C	10/2019	7.02	20.3	7.02	-27.4	P/F	L/F
Calibr.	"	"	902	180621D	7/2019	4.00	20.3	4.00	145.3	P/F	L/F
Calibr.	"	"	906	180621F	1/2020	10.06	20.3	10.06	-194.5	P/F	L/F
ICV	"	"	908	"	"	10.0	20.3	10.03	-194.6	P/F	L/F
CCV	"	"		180927A	10/2019	4.0	20.7	4.09	141.1	P/F	L/F
CCV										P/F	L/F

pH Acceptance criteria ± 0.2 SU;

mV pH 7 Range 0 ± 50 ;

mV pH 4 Range $+180 \pm 50$;

mV pH 10 Range -180 ± 50 ;

If mV are recorded: slope from 7 to 10 167.2, slope from 4 to 7 172.7 (both must be between 165 and 180 mV)

Does meter have a depth sensor that will be used to measure total depth & sample depth? YES / NO / NA (not surf. water project)

If YES, complete daily Calibr. & ICV below and list date of last quarterly depth verification: 1/9/19

If NO, what will be used? (circle one) Secchi Disk Line / Sonar Unique ID: _____; Date of last verification: _____

Depth Sensor (Daily Calibration & ICV)	Name	Date	Time CT-ET	Calibrated Value (0.00 or Offset), meters	ICV Value, meters	Pass / Fail	Lab / Field
Pressure mode in air	Don Woods	3/18/19	907	0.00	0.00	P/F	L/F

Report two decimal places. Round numbers ≤ 4 down, ≥ 5 up. ICV acceptance criteria $\pm 5\%$ or ± 0.05 m, whichever is greater.

COMMENTS:

