



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION STRATEGIC MONITORING PROGRAM FIELD SHEET

January 2019

Data Qualified?

Yes / No

WIN Station Name: **Bailey Mill Creek @ Wilson Rd**

Date: **4/11/2019**
(mm/dd/yyyy)

WIN/ Field ID: **G1TLHR0081**

WBID: **3419A**

Latitude: **30.2749**

County: **JEFFERSON**

ORG ID: **21FLTLHR**

Longitude: **83.96666667**
(Decimal Degrees)

Receiving Body of Water: **Wacissa River**

RQ: **2019-02-18-27**
(Decimal Degrees)

Sampling Team Members						WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check	Sampling Equipment				
Jon Woods Ben Harden						☒	☒	☒	☒	☒	☒ Sample Container	☐ Van Dorn	☐ Pole		
											☐ Carboy	☒ Syringe			
											☐ Dipper	☐ Other			
Depth Measured with 421						Equipment ID 153484									
											Collection Method				
						☒	☐	☐	☐	☐	☒ Wading	☐ Canoe/Kayak			
											☐ From Shore	☐ Electric Motor			
											☐ Other	☐ Gasoline Motor			
Water Level: Dry/ Pooled/ Low ☒ Normal / High / Flooded						Meter ID# 153484				Matrix: ☒ Fresh / Marine / DI					
Photos: ☒ Yes ☐ No						Flow: No Flow / Intestinal ☒ Flowing / NA				Tide: Rising/ Falling/ Slack ☒ NA				Tide Times: High Low	
Time Zone	Time	Total Depth (m)	Sample Depth (m)	Secchi Disk (m)	DO (mg/L)	DO (%SAT)	pH	Salinity (PPT)	Sp COND (µmhos/cm)	Temp. (C°)					
EST	1105	1.0	0.3	0.3	6.56	72.0	6.75	0.06	123.0	19.7					
CEN															
Biological Samples Collected: ☒ None HA SCI RPS Algae ID LVS LVI Other:															
SBIO ID Numbers: SBIO-ID: HA-ID: RPS-ID: Macrophyte-ID: LIMS#:															
Parameter Suite	Parameter Methods					Preservation	Lot#	Expiration	pH Check						
Preserved Nutrients	☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP					☒ Ice ☒ H2SO4	8344070	12/10/19	☒ <2						
Metals	☐ W-ICPMS ☐ W-ICP					☐ Ice ☐ HNO3			☐ <2						
Filtered Nutrients	☒ W-PO4-F ☒ Field Filtered 0.45 µm Filter					☒ Ice									
Chlorophyll	☒ CHLSUITE-W					☒ Ice									
Physical/Aggregate (Fresh)	☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS					☒ Ice									
Physical/Aggregate (Marine)	☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY					☐ Ice									
Macroinvertebrates	☐ MI-FW-QLDC					☐ Formalin									
Periphyton	☐ ALGAE-ID					☐ Ice									
Microbiology	☒ E Coli ☐ F Coli ☐ Enterococci					☒ Ice									
Molecular	☐ PCR-FILTER ☐ PCR-BacR ☐ PCR-GULL2 ☐ PCR-HF183 ☐ PCR-DG3 ☐ PCR-GFD					☐ Ice									
Tracers	☐ W-E8321-DI ☐ W-E8321-MS					☐ Ice									
Pesticides	☐ W-PSNP-TQ ☐ W-CT-CL-R ☐ W-E8321-DI ☐ W-PCL-SQ-R ☐ WE8321-MS ☐ W-CARB-AA					☐ Ice									
Phytoplankton	☐ DTY-QN-C ☐ PKD-QN-C					☐ Ice									

Notes:

Signature: *[Signature]*

Field/WIN ID →



G1TLHR0081

Location ↓

Bailey Mill Creek @ Wilson Rd

Date:

4/11/19

LIMS EVENT ID:

WIN Import ID:

Enter Field Parameters, Verify Station ID in LIMS DMT:

QC Station ID, Field Parameters in LIMS DMT:

Scan/Save Field Sheets

(Initials/Date)

Migrate Data to WIN:

(Initials/Date)

(Initials/Date)

Verify Data in WIN:

(Initials/Date)

(Initials/Date)

Customer: TLH-ROC

Project ID: SMP

Requester: Michael Eckles

Collected By:

Field Report Prepared By:

Sampling Agency: 4034

[illegible]

Relinquished By:

Date/Time 4/11/09

Shipping Method

Number of Coolers Shipped:

Received By:

Date/Time

Date/Time 4-11-19/3:37

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	ALKALINITY					
	TURBIDITY					
	W-BR-IC					
	W-F					
	W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	CHLSUITE-W					
Group: A	Bottle Type:	P-250ML-WO-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	ENT-24-QT					
Group: A	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	PCR-FILTER					
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	HNO3	Enter Number of Bottles Sent to Lab
	W-ICP					
	W-ICPMS					
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	ALKALINITY					
	TURBIDITY					
	W-CL-IC					
	W-COLOR					
	W-F					
	W-SO4-IC					
	W-TDS					
	W-TSS					
Group: B	Bottle Type:	BP-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab

8344070
6XP. 13/10/19

Group: B	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: ECOLI-18QT	P-250ML-WO-THI	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: PCR-FILTER	QPCR-P-500ML	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 3	Preservative: ICE And H2SO4 8344070 exp. 12/10/19	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 3	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	2
Group: C	Bottle Type: ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS	P-1L	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: C	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: C	Bottle Type: ECOLI-18QT	P-250ML-WO-THI	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: C	Bottle Type: W-NH3	P-500ML	# of Bottles: 3	Preservative: ICE And H2SO4 8344070 exp. 12/10/19	Enter Number of Bottles Sent to Lab	2

Group: C	Bottle Type:	P-500ML	# of Bottles: 3	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	2
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: C	Bottle Type:	P-125ML	# of Bottles: 3	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	2
	W-PO4-F					
Group: D	Bottle Type:	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	
	ALKALINITY					
	TURBIDITY					
	W-BR-IC					
	W-F					
	W-TSS					
Group: D	Bottle Type:	BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	
	CHLSUTE-W					
Group: D	Bottle Type:	P-250ML-WO-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	
	ENT-24-QT					
Group: D	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: D	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	
	W-PO4-F					
Group: E	Bottle Type:	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	
	ALKALINITY					
	TURBIDITY					
	W-BR-IC					
	W-F					
	W-TSS					
Group: E	Bottle Type:	P-250ML-WO-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	
	ENT-24-QT					

8344070
Exp. 12/10/19

Group: E	Bottle Type: W-ICP W-ICPMS	P-500ML	# of Bottles: 1	Preservative:	HNO3	Enter Number of Bottles Sent to Lab
Group: E	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4		Enter Number of Bottles Sent to Lab
Group: E	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE		Enter Number of Bottles Sent to Lab

CALIBRATION AND VERIFICATION LOG (FDEP SOP FT 1000-FT 1500, FD 1000-FD 4000)

Boldly "X" this box if there are qualified data on this page.

Meter ID: 153484

RQ- 2019-02-16-27

Project: SMP1904

- Notes: (1) Always wait for meter to stabilize before recording any readings.
 (2) Report all digits displayed. Do not round before reporting measurements. (See special instructions for depth).
 (3) For Calibrations, record calibrated meter reading. Do not record initial meter reading before calibration.

Temperature (Quarterly) FT 1400

Date of Last Temperature Verification 04/19

DO DEP SOP FT 1500	Name	Date	Time CT-ET	Temp °C	Baro-meter mmHg	D.O. Chart mg/L	Meter D.O. mg/L	% DO	Probe Charge	Probe Gain	Pass / Fail	Lab / Field
Calibr.	Ben Harden	04/11/19	0748	20.1	754.3	9.0	9.02	99.3		10326	P / F	L / F
ICV	"	"	0800	18.8	754.3	9.2	9.24	99.6			P / F	L / F
CCV	"	"	1537	19.0	753.5	8.2	8.21	99.4			P / F	L / F
CCV				25.0							P / F	L / F

DO Acceptance criteria from Table ± 0.3 mg/L.

Rapid-Pulse Sensors: DO Gain Range 0.7 to 1.4; DO Charge Range 25-75.

Optical: DO gain range 0.85 to 1.15 (Pro DSS 0.75 to 1.50); DO charge N/A. Steady-state & Galvanic Sensors: DO Gain & Charge N/A.

Spec. Cond. FT 1200	Name	Date	Time CT-ET	Lot #	Expir. Date	Standard μ mhos/cm	Meter Reading μ mhos/cm	Pass / Fail	Lab / Field
Calibr.	Ben Harden	04/11/19	0750	150621C	07/19	1000	1000	P / F	L / F
ICV	"	"	0752	1505F81	05/20	100	101.3	P / F	L / F
CCV	"	"	1538	150621C	07/19	1000	1015	P / F	L / F
CCV								P / F	L / F

Conductivity Acceptance criteria $\pm 5\%$

pH DEP SOP FT 1100	Name	Date	Time CT-ET	Lot #	Expir. Date	pH Buffer SU	Temp °C	Meter reading SU	mV	Pass / Fail	Lab / Field
Calibr.	Ben Harden	04/11/19	0754	150403C	10/19	7.02	19.5	7.03	-33.4	P / F	L / F
Calibr.	"	"	0756	150621D	07/19	4.00	19.0	4.00	145.7	P / F	L / F
Calibr.	"	"	0758	150621F	01/20	10.08	19.7	10.08	-197.7	P / F	L / F
ICV	"	"	0759	"	"	10.08	19.1	10.06	-197.1	P / F	L / F
CCV	"	"	1540	150621D	07/19	4.00	19.4	4.14	136.0	P / F	L / F
CCV										P / F	L / F

pH Acceptance criteria ± 0.2 SU; mV pH 7 Range 0 ± 50 ;

mV pH 4 Range $+180 \pm 50$;

mV pH 10 Range -180 ± 50 ;

If mV are recorded: slope from 7 to 10 164.3, slope from 4 to 7 179.1 (both must be between 165 and 180 mV)

Does meter have a depth sensor that will be used to measure total depth & sample depth? YES / NO / NA (not surf. water project)

If YES, complete daily Calibr. & ICV below and list date of last quarterly depth verification: 04/19

If NO, what will be used? (circle one) Secchi Disk Line / Sonar Unique ID: ; Date of last verification:

Depth Sensor (Daily Calibration & ICV)	Name	Date	Time CT-ET	Calibrated Value (0.00 or Offset), meters	ICV Value, meters	Pass / Fail	Lab / Field
Pressure mode in air	Ben Harden	04/11/19	0748	0.272	0.272	P / F	L / F

Report two decimal places. Round numbers ≤ 4 down, ≥ 5 up. ICV acceptance criteria $\pm 5\%$ or ± 0.05 m, whichever is greater.

COMMENTS:

