



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION STRATEGIC MONITORING PROGRAM FIELD SHEET

January 2019

Data Qualified?

Yes / No

WIN Station Name: **Spring Creek @ US98**

Date: **4/11/2019**
(mm/dd/yyyy)

WIN/ Field ID: **G1TLHR0084**

WBID: **3518**

Latitude: **30.084354**

(Decimal Degrees)

County: **Taylor**

ORG ID: **21FLTLHR**

Longitude: **83.664309**

(Decimal Degrees)

Receiving Body of Water: **Fenholloway River**

RQ-2019-02-18-27

Sampling Team Members					WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check	Sampling Equipment									
<i>Jon Woods</i> <i>Ben Harden</i>					☒	☒	☒	☒	☒	☒ Sample Container	☐ Van Dorn	☐ Pole							
										☐ Carboy	☒ Syringe								
										☐ Dipper	☐ Other								
Depth Measured with					Equipment ID					Collection Method									
					☒	☐	☐	☐	☐	☒ Wading	☐ Canoe/Kayak								
										☐ From Shore	☐ Electric Motor								
										☐ Other	☐ Gasoline Motor								
Water Level: Dry/ Pooled/ Low ☒ Normal / High / Flooded					Meter ID# 153484					Matrix: ☒ Fresh Marine / DI									
Photos: ☒ Yes / No					Flow: No Flow / Intestinal / ☒ Flowing / NA					Tide: Rising/ Falling/ Slack/ NA					Tide Times: High Low				
Time Zone	Time	Total Depth (m)	Sample Depth (m)	Secchi Disk (m)	DO (mg/L)	DO (%SAT)	pH	Salinity (PPT)	Sp COND (µmhos/cm)	Temp. (C°)									
EST	1230	1.1	0.3	1.1	6.64	74.0	7.44	0.19	391.3	20.6									
CEN				5															
Biological Samples Collected: ☒ None HA SCI RPS Algae ID LVS LVI Other:																			
SBIO ID Numbers: SBIO-ID: HA-ID: RPS-ID: Macrophyte-ID: LIMS#:																			
Parameter Suite		Parameter Methods					Preservation		Lot#		Expiration pH Check								
Preserved Nutrients		☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP					☒ Ice ☒ H2SO4		8344070		12/10/19 ☒ <2								
Metals		☐ W-ICPMS ☐ W-ICP					☐ Ice ☐ HNO3				☐ <2								
Filtered Nutrients		☒ W-PO4-F ☒ Field Filtered 0.45 µm Filter					☒ Ice												
Chlorophyll		☒ CHLSUITE-W					☒ Ice												
Physical/Aggregate (Fresh)		☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-CI-IC / W-COLOR / W-SO4-IC / W-TDS					☒ Ice												
Physical/Aggregate (Marine)		☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY					☐ Ice												
Macroinvertebrates		☐ MI-FW-QLDC					☐ Formalin												
Periphyton		☐ ALGAE-ID					☐ Ice												
Microbiology		☒ E Coli ☐ F Coli ☐ Enterococci					☒ Ice												
Molecular		☐ PCR-FILTER ☐ PCR-BacR ☐ PCR-GULL2 ☐ PCR-HF183 ☐ PCR-DG3 ☐ PCR-GFD					☐ Ice												
Tracers		☐ W-E8321-DI ☐ W-E8321-MS					☐ Ice												
Pesticides		☐ W-PSNP-TQ ☐ W-CT-CL-R ☐ W-E8321-DI ☐ W-PCL-SQ-R ☐ WE8321-MS ☐ W-CARB-AA					☐ Ice												
Phytoplankton		☐ DTY-QN-C ☐ PKD-QN-C					☐ Ice												

Notes:

Field/WIN ID →

Location ↓



G1TLHR0084



SPRING CREEK @ US98

Signature: *Jon Woods*

Date: **4/11/19**

LIMS EVENT ID:

WIN Import ID:

Enter Field Parameters, Verify Station ID In LIMS DMT:

QC Station ID, Field Parameters In LIMS DMT:

Scan/Save Field Sheets

Migrate Data to WIN:

Verify Data In WIN:

(Initials/Date)

(Initials/Date)

(Initials/Date)

(Initials/Date)

Customer: TLH-ROC

Project ID: SMP

Requester: Michael Eckles

Field Report Prepared By:

Collected By:

Sampling Agency:

[illegible]

Relinquished By:

Date/Time 4/12/19

Shipping Method

Number of Coolers Shipped:

8

Received By:

Date/Time

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	ALKALINITY					
	TURBIDITY					
	W-BR-IC					
	W-F					
	W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	CHLSUITE-W					
Group: A	Bottle Type:	P-250ML-WO-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	ENT-24-QT					
Group: A	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	PCR-FILTER					
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	HNO3	Enter Number of Bottles Sent to Lab
	W-ICP					
	W-ICPMS					
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	ALKALINITY					
	TURBIDITY					
	W-CL-IC					
	W-COLOR					
	W-F					
	W-SO4-IC					
	W-TDS					
	W-TSS					
Group: B	Bottle Type:	BP-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab

8344070
 6XP. 13/10/19

2

Group: B	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: ECOLI-18QT	P-250ML-WO-THI	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: PCR-FILTER	QPCR-P-500ML	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 3	Preservative: ICE And H2SO4 8344070 exp. 12/10/19	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 3	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	2
Group: C	Bottle Type: ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS	P-1L	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: C	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: C	Bottle Type: ECOLI-18QT	P-250ML-WO-THI	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: C	Bottle Type: W-NH3	P-500ML	# of Bottles: 3	Preservative: ICE And H2SO4 8344070 exp. 12/10/19	Enter Number of Bottles Sent to Lab	2

Group: C	Bottle Type:	P-500ML	# of Bottles: 3	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	2
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: C	Bottle Type:	P-125ML	# of Bottles: 3	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	2
	W-PO4-F					
Group: D	Bottle Type:	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	
	ALKALINITY					
	TURBIDITY					
	W-BR-IC					
	W-F					
	W-TSS					
Group: D	Bottle Type:	BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	
	CHLSUTE-W					
Group: D	Bottle Type:	P-250ML-WO-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	
	ENT-24-QT					
Group: D	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: D	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	
	W-PO4-F					
Group: E	Bottle Type:	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	
	ALKALINITY					
	TURBIDITY					
	W-BR-IC					
	W-F					
	W-TSS					
Group: E	Bottle Type:	P-250ML-WO-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	
	ENT-24-QT					

8344070
Exp. 12/10/19

Group: E	Bottle Type: W-ICP W-ICPMS	P-500ML	# of Bottles: 1	Preservative: HNO3	Enter Number of Bottles Sent to Lab
Group: E	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab
Group: E	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab

CALIBRATION AND VERIFICATION LOG (FDEP SOP FT 1000-FT 1500, FD 1000-FD 4000)

Boldly "X" this box if there are qualified data on this page.

Meter ID: 153484

RQ: 2019-02-18-27

Project: SMP1904

Notes: (1) Always wait for meter to stabilize before recording any readings.

(2) Report all digits displayed. Do not round before reporting measurements. (See special instructions for depth).

(3) For Calibrations, record calibrated meter reading. Do not record initial meter reading before calibration.

Temperature (Quarterly) FT 1400

Date of Last Temperature Verification 04/19

DO DEP SOP FT 1500	Name	Date	Time CT-ET	Temp °C	Baro- meter mmHg	D.O. Chart mg/L	Meter D.O. mg/L	% DO	Probe Charge	Probe Gain	Pass / Fail	Lab / Field
Calibr.	Ben Harden	04/11/19	0748	20.1	754.3	9.0	9.02	99.3		0326	P / F	L / F
ICV	"	"	0800	18.8	754.3	9.2	9.24	99.6			P / F	L / F
CCV	"	"	1537	19.0	753.5	8.2	8.21	99.4			P / F	L / F
CCV				25.0							P / F	L / F

DO Acceptance criteria from Table ± 0.3 mg/L.

Rapid-Pulse Sensors: DO Gain Range 0.7 to 1.4; DO Charge Range 25-75.

Optical: DO gain range 0.85 to 1.15 (Pro DSS 0.75 to 1.50); DO charge N/A. Steady-state & Galvanic Sensors: DO Gain & Charge N/A.

Spec. Cond. FT 1200	Name	Date	Time CT-ET	Lot #	Expir. Date	Standard μ hos/cm	Meter Reading μ hos/cm	Pass / Fail	Lab / Field
Calibr.	Ben Harden	04/11/19	0750	180621C	07/19	1000	1000	P / F	L / F
ICV	"	"	0752	1805F81	05/20	100	101.3	P / F	L / F
CCV	"	"	1538	180621C	07/19	1000	1015	P / F	L / F
CCV								P / F	L / F

Conductivity Acceptance criteria $\pm 5\%$

pH DEP SOP FT 1100	Name	Date	Time CT-ET	Lot #	Expir. Date	pH Buffer SU	Temp °C	Meter reading SU	mV	Pass / Fail	Lab / Field
Calibr.	Ben Harden	04/11/19	0754	180403C	10/19	7.02	19.5	7.03	-33.4	P / F	L / F
Calibr.	"	"	0756	180621D	07/19	4.00	19.0	4.00	145.7	P / F	L / F
Calibr.	"	"	0758	180621F	01/20	10.08	18.7	10.08	-197.7	P / F	L / F
ICV	"	"	0759	"	"	10.08	19.1	10.06	-197.1	P / F	L / F
CCV	"	"	1540	180621D	07/19	4.00	19.4	4.14	136.0	P / F	L / F
CCV										P / F	L / F

pH Acceptance criteria ± 0.2 SU; mV pH 7 Range 0 ± 50 ;

mV pH 4 Range $+180 \pm 50$;

mV pH 10 Range -180 ± 50 ;

If mV are recorded: slope from 7 to 10 164.3, slope from 4 to 7 179.1 (both must be between 165 and 180 mV)

Does meter have a depth sensor that will be used to measure total depth & sample depth? YES / NO / NA (not surf. water project)

If YES, complete daily Calibr. & ICV below and list date of last quarterly depth verification: 04/19

If NO, what will be used? (circle one) Secchi Disk Line / Sonar Unique ID: _____; Date of last verification: _____

Depth Sensor (Daily Calibration & ICV)	Name	Date	Time CT-ET	Calibrated Value (0.00 or Offset), meters	ICV Value, meters	Pass / Fail	Lab / Field
Pressure mode in air	Ben Harden	04/11/19	0748	0.272	0.272	P / F	L / F

Report two decimal places. Round numbers ≤ 4 down, ≥ 5 up. ICV acceptance criteria $\pm 5\%$ or ± 0.05 m, whichever is greater.

COMMENTS:

