

Log-in Checklist

RQ- 2019- 04-15-08

Login Station ID: #4

Shipping Method: FedEx UPS | HD | Greyhound

Date/Time of Receipt: 04/ 09 /19 @ 9:25

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.8°C				12		X			4751 8778 4197

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above standard temperature without customer notification/confirmation.**

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an **NCR**.

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes No X

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No X If yes, is it intact? Yes No

**Caps on tight? Yes ✓ No **Containers intact? Yes ✓ No

**Sufficient Sample Volume: Yes ✓ No

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes ✓ No Init: Tyler R.

Check the Box marked "Yes" or "No" for the Presence of Chlorine. If Cl detected, an NCR is required.					
Analysis	Yes	No	Analysis	Yes	No
W-1,4 DIOX			W-PC-AA-SF		
W-E8321-DI, -MS, -21		X	W-NP-AA-SF		
W-BNA (-625, -R)			W-PDQUAT		
W-CARB-AA (-CAB-AA-R)			W-PCL-SQ-R		
W-U2060-MS			W-TR-TQ		
W-PCB-R			W-CT-CI-R		
W-PAH (-R)			W-PSNP-TQ		X
W-PFAS-MS					

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ✓ No NA Init: Tyler R.

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA X Init: Tyler R.

Coolers Unpacked/Checked by: Tyler Reynolds

Date: 04/ 09 /19

NCRs (Y/N)? N

Event ID: SCIs

SW-DIST-2019-04-09-05 (SCIREF)

NCR #

Page 1 of 2 Date Received: 09-APR-2019 09:25

Federal Express BIOLOGY

Log-in Checklist

Samples with Incorrect pH Preservation or presence of Chlorine

Field ID	Bottle Test ID(s)	pH / Cl	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	
pH Paper 0.0 – 3.0 Lot #	
pH Paper 0 – 13 Lot #	
Chlorine Test Strips Lot #	

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Request Number: RQ-2019-04-15-08

Florida Department of Environmental Protection

1 of 2

Page 1 of 3

SCIs

EVENT # 1 of 2

Central Laboratory Submittal Form

last revised Jan 25, 2018

Customer: SW-DIST

Requester: Benjamin Paswater

Field Report Prepared By:

Judy Ashton

Project ID: SCIREF

Collected By:

J. Ashton B. Paswater, S. Meyer

Sampling Agency:

FOLP

Location		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 4-8-19 Time 1240		Eastern Central		Composite end Date Time		Bottle Group(s) (See pg 2)	
Field ID/WIN G2SW0105		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		A/B	
WIN/ Site Name: Manatee River E. Fork @ Duette Park		Temp (C) 23.2		pH 7.01		Sample Depth 0.2		Sp. Conductance (umho/cm) 261.4			
Latitude ☐ dd ☐ dms		Salinity (ppt) 0.12		Comments NO BACTERIA							

Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments					

Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments					

Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments					

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
J. Ashton	4-8-19 1700	Fed Ex	1	Tyler Reynolds	04/09/19 @ 9:25

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WI-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	SWD-AEL-EC						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	W-E8321-DI						
	W-E8321-MS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	HNO3	Enter Number of Bottles Sent to Lab	1
	W-ICP						
	W-ICPMS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	1
	W-PO4-F						
Group: A	Bottle Type:	BG-1L	# of Bottles: 6	Preservative:	ICE	Enter Number of Bottles Sent to Lab	4
	W-PSNP-TQ						
Group: B	Bottle Type:	PT-50ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	ALGAL_ID						
Group: B	Bottle Type:	PJ-2L	# of Bottles: 4	Preservative:	Formalin	Enter Number of Bottles Sent to Lab	2
	MI-FN-DLDC						

Date of Request: 06-FEB-2019
 Created By: PASWATER_B On: 06-FEB-2019
 Modified By: JASROTIA_P On: 25-MAR-2019
 Customer: SW-DIST
 Project: SCIREF
 Division: Division of Environmental Assessment and Restoration
 District: Southwest District
 Sampling Event: SCIs

Send Coolers To:

Phone: 813-632-7600
 FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater

Program Module Number:

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 18-MAR-2019
 Biology Request Reviewed By: JASROTIA_P On: 25-MAR-2019
 Sampling Kit Required: YES Ship on: 05-APR-2019
 Sampling Kit Shipped: YES On: 01-APR-2019
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 15-APR-2019
 Received By:

Send Final Report To:

FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments:**Bottle Group A (Water) With 2 Samples:**

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 2	Preserved With: ICE
SWD-AEL-EC	Template: DEFAULT	(EPA 1603) Escherichia coli by membrane filter Advanced Environmental Laboratory in Tampa
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO ₃
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium		
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO3
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

*Boron
Aluminum
Antimony
Arsenic
Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-1L	Number of Bottles: 6	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270D) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Bottle Group B (Biological) With 2 Samples:

Bottle Type: PJ-2L	Number of Bottles: 4	Preserved With: Formalin
MI-FW-QLDC	Template: DEFAULT	(SOP-IZ06) No. Taxa of FW macroinverts, qual samp, 20 dipnets.
Bottle Type: PT-50ML	Number of Bottles: 2	Preserved With: ICE
ALGAL_ID	Template: DEFAULT	(SOP-AB05) Qualitative assessment of algal taxa present without counts

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.