

RQ-2019-10-14-02

Login Checklist

Login Station ID: #4

Shipping Method: FedEx UPS | HD | Greyhound

Date/Time of Receipt: 10/11/2019 @ 10:00

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only	
		YES	HNO ₃		Formalin	Present?		*Intact?		
						Yes	No	Yes		No
2.1°C				4		x			1190 3162 1370	

*All samples received on ice unless otherwise noted. If the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), received without ice, or if Evidence Seal is damaged; identify the containers in the affected cooler(s) on back of this form. HNO₃ and Formalin preserved samples do **NOT** have a temperature requirement. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation; An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes ☐ No ☒ If yes, is it intact? Yes ☐ No ☐

**Caps on tight? Yes ☒ No ☐ **Containers intact? Yes ☒ No ☐

**Sufficient Sample Volume: Yes ☒ No ☐

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: me

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init:

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ☒ No ☐ NA ☐ Init: me

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☐ NA ☒ Init: me

Coolers Unpacked/Checked by: Lulu Reynolds Date: 10/11/2019

NCRs (Y/N)? N

Event ID: Hurrah Creek HA 2 of 2
SW-DIST-2019-10-11-01 (SMP)

NCR #

Date Received: 11-OCT-2019 10:00

Login Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle Test ID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_04_2018 EXP: 04/29/2020
pH Test Strips 0 – 6 Lot #	213316AV EXP: 05/15/2020
pH Paper 0 – 3 Lot #	N/A
pH Paper 0 – 13 Lot #	215517 EXP: 06/01/2020
Chlorine Test Strips Lot #	8261 EXP: 07/30/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Request Number: RQ-2019-10-14-02

Hurrah Creek HA 2 of 2 *SUNDANCE*Florida Department of Environmental Protection
Central Laboratory Submittal Form

Page 1 of 2

last revised Jan 25, 2018

Customer: SW-DIST

Project ID: SMP

Requester: Benjamin Paswater

Field Report Prepared By:

Collected By: *J. Ashton, B. Paswater*

Sampling Agency:

Location		☐ Comp ☒ Grab		Collection (comp begin or grab) Date <i>10-10-19</i> Time <i>1310</i>		Eastern Central		Composite end Date Time		Bottle Group(s) (See pg 2)	
Field ID/WIN G2SW0038		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen <i>4.37</i>		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		A	
WIN 		Temp (C) <i>25.5</i>		pH <i>7.33</i>		Sample Depth <i>0.1</i>		Sp. Conductance (umho/cm) <i>1503</i>			
Site Name: Sundance Creek		☐ dd ☐ dms		Salinity (ppt) <i>0.75</i>		Comments <i>E. COLI DRAGS OUT @ BRANCH MARK</i>					
Latitude											

Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)			
Latitude		☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt)			
Location											

Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)			
Latitude		☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt)			
Location											

Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)			
Latitude		☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt)			
Location											

Relinquished By: <i>J. Ashton</i>	Date/Time <i>10/10/19 1600</i>	Shipping Method <i>450 Lx</i>	Number of Coolers Shipped: <i>2</i>	Received By: <i>Tyler Purnolds</i>	Date/Time <i>10/11/19 @ 10:00</i>
--------------------------------------	-----------------------------------	----------------------------------	--	---------------------------------------	--------------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WI-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	SW-AEL-ECQ SW-BEA-ECQ						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	1
	W-PO4-F						

Date 10-10-19

Date of Request: 08-AUG-2019
 Created By: PASWATER_B On: 08-AUG-2019
 Modified By: JASROTIA_P On: 23-SEP-2019
 Customer: SW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southwest District
 Sampling Event: Hurrah Creek HA 2 of 2

Send Coolers To:

Phone: 813-632-7600
 FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater

Program Module Number:

Priority: 3

Event Status: S

Criminal Investigation: NO

Chemistry Request Reviewed By: WATTS_J On: 20-SEP-2019

Biology Request Reviewed By: JASROTIA_P On: 23-SEP-2019

Sampling Kit Required: YES Ship on: 04-OCT-2019

Sampling Kit Shipped: YES On: 30-SEP-2019

Sampling Kit Packed By: REYNOLDS_T

Preservatives Needed: NO

Date to Receive Samples: 14-OCT-2019

Received By:

Send Final Report To:

FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater

Report Type: Final Only

FTP Data: NO

QC Report: YES

Date Log: NO

Authorization Log: NO

Comments: Hurrah Creek HA 2 of 2

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SW-AEL-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert-18/QT by AEL in Tampa
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

