

Log-in Checklist

RQ- 2019-11-25-04

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 11/26/19 @ 9:45

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.7				12		✓			1278 4009 2793
0.7				11		✓			1278 4009 2771
0.7 2.8				10		✓			1278 4009 2782

* HNO3 and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No ✓ If yes, is it intact? Yes No

**Caps on tight? Yes ✓ No **Containers intact? Yes ✓ No

**Sufficient Sample Volume: Yes ✓ No

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes ✓ No Init: KK

Chlorine detected? (One container checked per Field ID) Yes No ✓ Init: KK

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ✓ No NA Init: KK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA ✓ Init: KK

Coolers Unpacked/Checked by: KK Date: 11/26/19 NCRs (Y/N)? N

Event ID: Gilley, Owen, Myakka@Clay Gully
SW-DIST-2019-11-26-01 (SMP)
 Date Received: 26-NOV-2019 09:45
 NCR #

Log-in Checklist

10-25-2018

Samples with Incorrect pH Preservation

Field ID	Bottle Test ID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_07_2018 EXP:12/28/19
pH Test Strips 0 – 6 Lot #	
pH Paper 0 – 3 Lot #	220416A EXP:7/30/20
pH Paper 0 – 13 Lot #	215517 EXP:6/1/20
Chlorine Test Strips Lot #	091417V EXP:9/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: SW-DIST

Project ID: SMP

Requester: Judy Ashton

Field Report Prepared By:

Collected By:

Sampling Agency:

Location	Field ID/WIN G2SW0024	Field ID	WIN/STC	Site Name: Gilley Creek @ Stricklands	Latitude	☐ dms ☐ dd ☐ dms	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 11/25/19 Time 940	☒ Eastern ☐ Central	Composite end Date Time	Bottle Group(s) (See pg 2)	
								Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen 9.12	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
								Temp (C) 15.6	pH 7.21	Sample Depth 0.3	☐ ft ☒ m	Sp. Conductance (umho/cm) 140.6
								Salinity (ppt) 0.07	Comments			A
Location	Field ID/WIN G3SW0054	Field ID	WIN/STC	Site Name: Myakka River @ Clay Gulley in Park	Latitude	☐ dms ☐ dd ☐ dms	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 11/25/19 Time 1030	☒ Eastern ☐ Central	Composite end Date Time	Bottle Group(s)	
								Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen 4.10	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
								Temp (C) 16.6	pH 7.40	Sample Depth 0.3	☐ ft ☒ m	Sp. Conductance (umho/cm) 503
								Salinity (ppt) 0.24	Comments			B
Location	Field ID/WIN G3SW0053	Field ID	WIN/STC	Site Name: Owen Creek	Latitude	☐ dms ☐ dd ☐ dms	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 11/25/19 Time 1130	☒ Eastern ☐ Central	Composite end Date Time	Bottle Group(s)	
								Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen 8.53	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
								Temp (C) 17.0	pH 7.60	Sample Depth 0.3	☐ ft ☒ m	Sp. Conductance (umho/cm) 460.5
								Salinity (ppt) 0.22	Comments			B
Location	Field ID/WIN G3SW0056	Field ID	WIN/STC	Site Name: Mobley Ditch @ 70	Latitude	☐ dms ☐ dd ☐ dms	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 11/25/19 Time 1100	☒ Eastern ☐ Central	Composite end Date Time	Bottle Group(s)	
								Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen 2.52	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
								Temp (C) 17.0	pH 7.18	Sample Depth 0.3	☐ ft ☒ m	Sp. Conductance (umho/cm)
								Salinity (ppt) 0.31	Comments			B

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
<i>Ben Paswater</i>	11/25/19 4pm	Fed Ex	3	BR	11-26-19 10445

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: A	Bottle Type:	QPCR-P-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	PCR-BACR PCR-DG3 PCR-HF183						
Group: A	Bottle Type:	P-120ML-WC-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1 to Benchmark
	SW-BEA-ECQ						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	CH2ClCOOH Pre-Preserved	Enter Number of Bottles Sent to Lab	1
	W-CARB-AA						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab	4
	W-CT-CI-R W-PCL-SQ-R						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	W-E8321-DI W-E8321-MS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	1
	W-PO4-F						

Group: A	Bottle Type: W-PSNP-TQ	BG-1L	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>4</u>
Group: B	Bottle Type: ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>3</u>
Group: B	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>3</u>
Group: B	Bottle Type: PCR-BACR PCR-HF183	QPCR-P-500ML	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>3</u>
Group: B	Bottle Type: SW-BEA-ECQ	P-120ML-WC-THI	# of Bottles: 6	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>3 to Benchmark</u>
Group: B	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>3</u>
Group: B	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 3	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>3</u>
Group: B	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 3	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab <u>3</u>

Benchmark EnviroAnalytical, Inc
1711 12th Street East
Palmetto, FL 34221
941-723-9986
941-723-6061 Fax

PO# B578C6

Client Information: FDEP

Address: 13051 N. Telecom Parkway

Tampa FL 33604

Phone # 815-470-5772

Report to: Judy.ashton@dep.state.fl.us, DEP-Overflomicro@dep.state

Invoice to: FDEP Micro Overflow

Project Name: RQ- 2019-11-25-04

Laboratory Submission # 19111206

Sample Name	Sample Type ¹ / Sample Matrix ²	Collection		Container			Preservative ⁴	Parameters for Analysis	Laboratory Sample #
		Date	Time	Qty	Capacity	Type ³			
G2SW0024	SW	11/25/19	0940	1	120mL	P	Plain (on Ice)	E. coli	1
G3SW0054	SW	11/25/19	1030	1	120mL	P	Plain (on Ice)	E. coli	2
G3SW0053	SW	11/25/19	1100	1	120mL	P	Plain (on Ice)	E. coli	3
G2SW0101	SW	11/25/19	1130	1	120mL	P	Plain (on Ice)	E. coli	4
	SW				120mL	P	Plain (on Ice)		
	SW				120mL	P	Plain (on Ice)		
	SW				120mL	P	Plain (on Ice)		

1. "Sample Type" is used to indicate whether the sample was a grab (G) or whether it was a composite (C).
2. "Sample Matrix" is used to indicate whether the sample is being discharged to drinking water (DW), groundwater (GW), surface water (SW), fresh surface water (FSW), saline surface water (SSW), soil, sediment (SDMNT), or sludge (SLDG).
3. "Container Type" is used to indicate whether the container is plastic (P) or glass (G).
4. Sample must be refrigerated or stored in wet ice after collection. The temperature during storage should be less than or equal to 4°C (47.8°F).
Under "Preservative," list any preservatives that were added to the sample container.

Instructions:
1. Each bottle has a label identifying sample ID, preservative contained in the bottle, sample type, client ID, and parameters for analysis.
2. The following information should be added to each bottle label after collection with permanent black ink: date and time of collection, sample's name or initials, and any field number or ID.
3. All bottles not containing preservative may be rinsed with appropriate sample prior to collection.
4. The client is responsible for documentation of the sampling event. Please note special sampling events on the sample custody form.

Laboratory Sample Acceptability:
Temperature: 4.80°C

1	Collected / Relinquished By: <u>Ben Paswater</u>	Date: <u>11/25/19</u>	Time:	Received By:	Date:	Time:
2	Relinquished By: <u>Kaitlin Panzer</u>	Date: <u>11/25/19</u>	Time: <u>1259</u>	Received By: <u>[Signature]</u>	Date: <u>11-25-19</u>	Time: <u>1259</u>

Date of Request: 05-AUG-2019
 Created By: ASHTON_J On: 05-AUG-2019
 Modified By: JASROTIA_P On: 05-NOV-2019
 Customer: SW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southwest District
 Sampling Event: Gilley, Owen, Myakka@Clay Gully

Send Coolers To:

Phone: 813-470-5772
 FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Judy Ashton

Send Final Report To:

FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Judy Ashton

Program Module Number:

Priority: 3

Event Status: S

Criminal Investigation: NO

Chemistry Request Reviewed By: WATTS_J On: 04-NOV-2019

Biology Request Reviewed By: JASROTIA_P On: 05-NOV-2019

Sampling Kit Required: YES Ship on: 15-NOV-2019

Sampling Kit Shipped: YES On: 12-NOV-2019

Sampling Kit Packed By: MCCOY_I

Preservatives Needed: NO

Date to Receive Samples: 25-NOV-2019

Received By:

Report Type: Final Only

FTP Data: NO

QC Report: YES

Date Log: NO

Authorization Log: NO

Comments: Group A: Nutrients & Pesticides

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: P-120ML-WC-THI	Number of Bottles: 2	Preserved With: ICE
SW-BEA-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by BEA in Palmetto
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ CICOOH Pre-Preserved

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-Cl-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 3 Samples:

Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 3	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: QPCR-P-500ML	Number of Bottles: 3	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: P-120ML-WC-THI	Number of Bottles: 6	Preserved With: ICE
SW-BEA-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by BEA in Palmetto
Bottle Type: BG-500ML	Number of Bottles: 3	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 3	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.