

Log-in Checklist

RQ-2019-06-03-27

Login Station ID: #1

Shipping Method: FedEx | UPS (HD) | Greyhound

Date/Time of Receipt: 6/28/19 0805

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.0				16		✓			

* HNO₃ and Formalin preserved samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes No ✓

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No ✓ If yes, is it intact? Yes No
 **Caps on tight? Yes ✓ No **Containers intact? Yes ✓ No
 **Sufficient Sample Volume: Yes ✓ No

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ✓ No Init:

Chlorine detected? (One container checked per Field ID)

Yes No ✓ Init:

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ✓ No NA Init:

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA ✓ Init:

Coolers Unpacked/Checked by: Date: 6/28/19 NCRs (Y/N)? N

Event ID: NWQ1 - Alligator Creek NCR #

WAS-SECT-2019-06-28-02 (SMP)
 Date Received: 28-JUN-2019 08:05

Log-in Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle TestID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle TestID(s)

Bottles Not Intact

Field ID	Bottle TestID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle TestID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_01_2018 EXP:04/29/2020
pH Test Strips 0 – 6 Lot #	213316AV EXP:05/15/2020
pH Paper 0 – 3 Lot #	
pH Paper 0 – 13 Lot #	215517 EXP: 06/01/2020
Chlorine Test Strips Lot #	8261 EXP: 07/30/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No ☒ _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection
Central Laboratory Submittal Form

NWQI - Alligator Creek

last revised Jan 25, 2018

Customer: WAS-SECT

Requester: Curtis Musson

Field Report Prepared By:


Project ID: SMP


Collected By:

April Wood-M'Grath/Curtis Musson

Sampling Agency:

FDEP

Location	WIN ID / FILED ID → 	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 6/27/19 Time 13:47	Eastern Central	Composite end Date — Time —	Bottle Group(s) (See pg 2)
Field ID	G2WA0020	Matrix (type, e.g., Salt, Fresh, etc) Fresh	Diss. Oxygen 93.6	☐ mg/L ☒ % sat	Total Res. Chlorine (mg/L)	C
WIN/STORET #	Location: Wilson Mill Creek Upstream of 274	Temp (C) 28.6	pH 6.26	Sample Depth 0.1	Sp. Conductance (umho/cm) 87.5	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 0.04	Comments	
Location	WIN ID / FILED ID → 	☐ Comp ☐ Grab	Collection (comp begin or grab) Date — Time —	Eastern Central	Composite end Date — Time —	Bottle Group(s)
Field ID	G2WA0010	Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	C
WIN/STORET #	Location: Big Branch Downstream of Road 5	Temp (C) —	pH —	Sample Depth —	Sp. Conductance (umho/cm) —	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) —	Comments: NOT SAMPLED	
Location	WIN ID / FILED ID → 	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 6/27/19 Time 15:02	Eastern Central	Composite end Date — Time —	Bottle Group(s)
Field ID	G2WA0012	Matrix (type, e.g., Salt, Fresh, etc) Fresh	Diss. Oxygen 59.2	☐ mg/L ☒ % sat	Total Res. Chlorine (mg/L)	C
WIN/STORET #	Location: Stone Mill Creek Upstream of Dianna St.	Temp (C) 27.4	pH 4.63	Sample Depth 0.3	Sp. Conductance (umho/cm) 38.6	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 0.02	Comments	
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date — Time —	Eastern Central	Composite end Date — Time —	Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN/STORET #		Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments	

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
	6/28/19 0805	Hand Delivered	2		6/28/19 0805

Group: B	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab <u>0</u>
Group: C	Bottle Type: ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS	P-1L	# of Bottles: 6	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>2</u>
Group: C	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 6	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>2</u>
Group: C	Bottle Type: ECOLI-18QT	P-250ML-WO-THI	# of Bottles: <u>6</u> <u>12</u>	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>4</u>
Group: C	Bottle Type: PCR-BACR PCR-HF183	QPCR-P-500ML	# of Bottles: 6	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>2</u>
Group: C	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 6	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>2</u>
Group: C	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 6	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>2</u>
Group: C	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 6	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab <u>2</u>
Group: D	Bottle Type: ALKALINITY TURBIDITY W-CL-IC	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>0</u>

Cooler Packing Worksheet for Request: RQ-2019-06-03-27

NWQI - Alligator Creek

Ship Cooler On: 5/30/2019

Customer/Project: WAS-SECT/SMP

Assigned To: KLUG_K

Requester: Curtis Musson

Priority: 3

850-245-8453

2600 Blair Stone Rd

Tallahassee, FL 32399

Attn: Curtis Musson

Please return
packing list with
sample submittal
forms.

Comments:

No preservatives needed.

Group A: Nutrients, Metals, PCR-FILTER, Pesticides, E. coli

WBID 130 Minnow Creek *not sampled AUM 6/19*

Group B: Nutrients, Metals, PCR (HF183, BacR), Tracers, E. coli

WBID 123 Alligator Creek at SR 273 ✓

Group C x 6

Nutrients, PCR (HF183, BacR), Tracers, E. coli

WBIDs 123x2, 195, 233A, 235, 262A *only one from 123 sampled AUM 6/19
three sites sampled 6/27/19 AUM*

Group D: QC DUP

Nutrients, Metals, PCR (HF183, BacR), Tracers, E. coli

WBID 123 Alligator Creek at SR 273 ✓

Group E: QC Blank

Nutrients, Metals, PCR (HF183, BacR), Tracers, E. coli ✓

Packing Notes:

No FedEx labels

No Trash Bags

Requested Analyses:

Bottle Group: A

of Sites: 1

Container ID: P-1L

Qty: 1 Preservation: ICE

Lot # 000 73 354

Description: Plastic Bottle 1L

Analysis

ALKALINITY

TURBIDITY

W-CL-IC

W-COLOR

W-F

W-SO4-IC

W-TDS

Description

Alkalinity in aqueous matrices as mg CaCO₃/L

Turbidity in aqueous matrices

Chloride in aqueous matrices

True Color measured at 450 nm

Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)

Sulfate in aqueous matrices

Total Dissolved Solids in aqueous matrices

Container ID: BP-1L

Qty: 1 Preservation: ICE

Lot # 1248230

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-250ML-WO-THI

Qty: 1 Preservation: ICE

* Lot # 7805-TN

Description: 250 ml Sterilized no tablet

* Out of P-250ML-WO-THI bottles

Analysis

ECOLI-18QT

Description

Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Container ID: QPCR-P-500ML

Qty: 1 Preservation: ICE

Lot # 0007357

Description: 500ml Sterile Nalgene

Affix PCR Instruction Label to container

Analysis

PCR-FILTER

Description

Preparation of Samples by Filtration and held for qPCR Analysis

Container ID: BG-500ML

Qty: 1 Preservation: CH2ClCOOH Pre-Preserved

Lot # 00073513

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CARB-AA

Description

Carbamates in water matrices by HPLC/MS/MS

Container ID: BG-500ML

Qty: 4 Preservation: ICE

Lot # 00073513

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CT-Cl-R

W-PCL-SQ-R

Description

Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

Organochlorine pesticides in water matrices by GC/MS-SIM

Container ID: BG-500ML

Qty: 1 Preservation: ICE

Lot # 00073513

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

AnalysisDescription

W-E8321-DI
W-E8321-MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: P-500ML

Qty: 1 Preservation: HNO3

Lot # 00073297

Description: Plastic Bottle 500 mL

Affix RED nitric acid dot to container.

Analysis

W-ICP

W-ICPMS

Description

Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Container ID: P-500ML

Qty: 1 Preservation: ICE And H2SO4

Lot # 00073297

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3

W-NO2NO3

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 1 Preservation: FILTER-ICE

Lot # 00073850

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Container ID: BG-1L

Qty: 4 Preservation: ICE

Lot # 00073854

Description: Brown Glass Bottle 1L

Affix BLUE dot to container.

Analysis

W-PSNP-TQ

Description

Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Bottle Group: B

of Sites: 1

Container ID: P-1L

Qty: 1 Preservation: ICE

Lot # 00073854

Description: Plastic Bottle 1L

Analysis

Description

ALKALINITY	Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Turbidity in aqueous matrices
W-CL-IC	Chloride in aqueous matrices
W-COLOR	True Color measured at 450 nm
W-F	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Sulfate in aqueous matrices
W-TDS	Total Dissolved Solids in aqueous matrices
W-TSS	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 1 Preservation: ICE

Lot # 1248230

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-250ML-WO-THI

Qty: 1 Preservation: ICE

* Lot # 7B05-TN

Description: 250 ml Sterilized no tablet

Analysis

ECOLI-18QT

Description

Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Container ID: QPCR-P-500ML

Qty: 1 Preservation: ICE

Lot # 00071451

Description: 500ml Sterile Nalgene

Affix PCR Instruction Label to container

Analysis

PCR-BACR

PCR-HF183

Description

Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction

Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Container ID: BG-500ML

Qty: 1 Preservation: ICE

Lot # 00073513

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: P-500ML

Qty: 1 Preservation: HNO3

Lot # 00073297

Description: Plastic Bottle 500 mL

Affix RED nitric acid dot to container.

Analysis

W-ICP

W-ICPMS

Description

Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Container ID: P-500ML

Qty: 1 Preservation: ICE And H2SO4

Lot # 00073297

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3

W-NO2NO3

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 1 Preservation: FILTER-ICE

Lot # 00073850

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group: C

of Sites: 6

Container ID: P-1L

Qty: 6 Preservation: ICE

Lot # 00073854

Description: Plastic Bottle 1L

Analysis

ALKALINITY

TURBIDITY

W-CL-IC

W-COLOR

W-F

W-SO4-IC

W-TDS

W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO3/L

Turbidity in aqueous matrices

Chloride in aqueous matrices

True Color measured at 450 nm

Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)

Sulfate in aqueous matrices

Total Dissolved Solids in aqueous matrices

Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 6 Preservation: ICE

Lot # 1248230

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-250ML-WO-THI

Qty: 6 Preservation: ICE

* Lot # 7805-TN

Description: 250 ml Sterilized no tablet

Analysis

ECOLI-18QT

Description

Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Container ID: QPCR-P-500ML

Qty: 6 Preservation: ICE

Lot # 00071457

Description: 500ml Sterile Nalgene

Affix PCR Instruction Label to container

Analysis

PCR-BACR

PCR-HF183

Description

Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction

Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Container ID: BG-500ML

Qty: 6 Preservation: ICE

Lot # 00073513

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: P-500ML

Qty: 6 Preservation: ICE And H2SO4

Lot # 00073297

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3

W-NO2NO3

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 6 Preservation: FILTER-ICE

Lot # 00073850

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group: D

of Sites: 1

Container ID: P-1L

Qty: 1 Preservation: ICE

Lot # 00073854

Description: Plastic Bottle 1L

Analysis

ALKALINITY

TURBIDITY

W-CL-IC

W-COLOR

W-F

W-SO4-IC

W-TDS

W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO3/L

Turbidity in aqueous matrices

Chloride in aqueous matrices

True Color measured at 450 nm

Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)

Sulfate in aqueous matrices

Total Dissolved Solids in aqueous matrices

Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 1 Preservation: ICE

Lot # 1248230

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-250ML-WO-THI

Qty: 1 Preservation: ICE

* Lot # 7805-TN

Description: 250 ml Sterilized no tablet

Analysis

ECOLI-18QT

Description

Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Container ID: QPCR-P-500ML

Qty: 1 Preservation: ICE

Lot # 00073849

Description: 500ml Sterile Nalgene

Affix PCR Instruction Label to container

Analysis

PCR-BACR

Description

Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction

Container ID: BG-500ML

Qty: 1 Preservation: ICE

Lot # 00073513

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: P-500ML

Qty: 1 Preservation: HNO3

Lot # 00073297

Description: Plastic Bottle 500 mL

Affix RED nitric acid dot to container.

Analysis

W-ICP

W-ICPMS

DescriptionTotal Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples
supporting Clean Water Act ProjectsTotal Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water
Act Projects

Container ID: P-500ML

Qty: 1 Preservation: ICE And H2SO4

Lot # 00073297

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3

W-NO2NO3

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 1 Preservation: FILTER-ICE

Lot # 00073850

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group: E# of Sites: 1

Container ID: P-1L

Qty: 1 Preservation: ICE

Lot # 00073854

Description: Plastic Bottle 1L

AnalysisDescription

ALKALINITY	Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Turbidity in aqueous matrices
W-CL-IC	Chloride in aqueous matrices
W-COLOR	True Color measured at 450 nm
W-F	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Sulfate in aqueous matrices
W-TDS	Total Dissolved Solids in aqueous matrices
W-TSS	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 1 Preservation: ICE

Lot # 1248230

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-250ML-WO-THI

Qty: 1 Preservation: ICE

* Lot # 7805-TN

Description: 250 ml Sterilized no tablet

Analysis

ECOLI-18QT

Description

Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Container ID: QPCR-P-500ML

Qty: 1 Preservation: ICE

Lot # 00073819

Description: 500ml Sterile Nalgene

Affix PCR Instruction Label to container

Analysis

PCR-BACR

PCR-HF183

Description

Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction

Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Container ID: BG-500ML

Qty: 1 Preservation: ICE

Lot # 00073513

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: P-500ML

Qty: 1 Preservation: HNO₃Lot # 00073297

Description: Plastic Bottle 500 mL

Affix RED nitric acid dot to container.

Analysis

W-ICP

W-ICPMS

Description

Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Container ID: P-500ML

Qty: 1 Preservation: ICE And H₂SO₄Lot # 00073297

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

AnalysisW-NH₃W-NO₂NO₃

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 1 Preservation: FILTER-ICE

Lot # 00073850

Description: Plastic Bottle 125 mL

AnalysisW-PO₄-FDescription

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Cooler Packed By: KKNumber of Coolers: 5Date: 5-29-19

Kit must also include:

- ☒ Field Sheets
- ☒ Temperature Control Bottle
- ☐ FedEx Bills, if applicable
- ☐ Plastic Bags/Zip Ties
- ☐ Acid Labels (sets of 24)

If Preservation Included:

ID <u>MCAA Buffer soln</u>	Exp <u>11.1.20</u>	Lot # <u>98739</u>
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____

PLEASE RETURN ALL COOLERS FOR RQ-2019-06-03-27

Date of Request: 06-MAY-2019
 Created By: MUSSON_C On: 06-MAY-2019
 Modified By: JASROTIA_P On: 14-MAY-2019
 Customer: WAS-SECT
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District:
 Sampling Event: NWQI - Alligator Creek

Send Coolers To:

Phone: 850-245-8453
 2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Curtis Musson

Program Module Number:

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 14-MAY-2019
 Biology Request Reviewed By: JASROTIA_P On: 14-MAY-2019
 Sampling Kit Required: YES Ship on: 30-MAY-2019
 Sampling Kit Shipped: YES On: 29-MAY-2019
 Sampling Kit Packed By: KLUG_K
 Preservatives Needed: NO
 Date to Receive Samples: 05-JUN-2019
 Received By: SHAIK_A On: 05-JUN-2019

Send Final Report To:

2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Curtis Musson

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: Nutrients, Metals, PCR-FILTER, Pesticides, E. coli
 WBID 130 Minnow Creek

Group B: Nutrients, Metals, PCR (HF183, BacR), Tracers, E. coli
 WBID123. Alligator Creek at SR 273

Group C x 6
 Nutrients, PCR (HF183, BacR), Tracers, E. coli
 WBIDs 123x2, 195, 233A, 235, 262A

Group D: QC DUP
 Nutrients, Metals, PCR (HF183, BacR), Tracers, E. coli
 WBID123. Alligator Creek at SR 273

Group E: QC Blank
 Nutrients, Metals, PCR (HF183, BacR), Tracers, E. coli

Packing Notes:
 No FedEx labels
 No Trash Bags

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2CICOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium		
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
*Boron		
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium		
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
*Boron		
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 6 Samples:

Bottle Type: P-1L	Number of Bottles: 6	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices

Bottle Group C (Water) With 6 Samples:

Bottle Type: P-1L W-TSS	Template: DEFAULT	Number of Bottles: 6 (SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	Preserved With: ICE
Bottle Type: BP-1L CHLSUITE-W	Template: DEFAULT	Number of Bottles: 6 (SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry	Preserved With: ICE
Bottle Type: P-250ML-WO-THI ECOLI-18QT	Template: DEFAULT	Number of Bottles: 6 (SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems	Preserved With: ICE
Bottle Type: QPCR-P-500ML PCR-BACR	Template: DEFAULT	Number of Bottles: 6 (SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction	Preserved With: ICE
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction	
Bottle Type: BG-500ML W-E8321-DI	Template: DEFAULT	Number of Bottles: 6 (EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	Preserved With: ICE
W-E8321-MS	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	
Bottle Type: P-500ML W-NH3	Template: DEFAULT	Number of Bottles: 6 (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L	Preserved With: ICE And H2SO4
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L	
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L	
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices	
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices	
Bottle Type: P-125ML W-PO4-F	Template: DEFAULT	Number of Bottles: 6 (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	Preserved With: FILTER-ICE

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L ALKALINITY	Template: DEFAULT	Number of Bottles: 1 (SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L	Preserved With: ICE
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices	
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices	
W-COLOR Color (true)	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm	
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices	
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices	
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	
Bottle Type: BP-1L CHLSUITE-W	Template: DEFAULT	Number of Bottles: 1 (SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry	Preserved With: ICE
Bottle Type: P-250ML-WO-THI ECOLI-18QT	Template: DEFAULT	Number of Bottles: 1 (SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems	Preserved With: ICE
Bottle Type: QPCR-P-500ML PCR-BACR	Template: DEFAULT	Number of Bottles: 1 (SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction	Preserved With: ICE
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction	
Bottle Type: BG-500ML W-E8321-DI	Template: DEFAULT	Number of Bottles: 1 (EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	Preserved With: ICE
W-E8321-MS	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	
Bottle Type: P-500ML W-ICP	Template:	Number of Bottles: 1 (EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	Preserved With: HNO3

Barium
Calcium
Iron
Magnesium
Potassium
Sodium
Zinc

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

*Boron
Aluminum
Antimony
Arsenic
Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group E (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Barium
Calcium
Iron
Magnesium
Potassium
Sodium
Zinc

Bottle Group E (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

*Boron
Aluminum
Antimony
Arsenic
Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.