

Log-in Checklist

RQ- 2019-07-08-19

Login Station ID: #2

Shipping Method: FedEx | UPS | (HD) Greyhound

Date/Time of Receipt: 7.10.19 14:02

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
4.7				13		✓			
2.5				16		✓			

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.**

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes No ✓

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No ✓ If yes, is it intact? Yes No
 **Caps on tight? Yes ✓ No **Containers intact? Yes ✓ No
 **Sufficient Sample Volume: Yes ✓ No

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes No ✓ Init: HK

Chlorine detected? (One container checked per Field ID) Yes No Init:

If "YES", list affected Field IDs and Test IDs below.

Field ID	List Test ID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ✓ No NA Init: HK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA ✓ Init: HK

Coolers Unpacked/Checked by: HK Date: 7.10.19 NCRs (Y/N)? N

Event ID: Tallahassee Lakes
WAS-SECT-2019-07-10-01 (SMP) NCR #

Log-in Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle Test ID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_02_2018 EXP:4-29-2020
pH Test Strips 0 – 6 Lot #	213316VEXP:05-15-2019
pH Paper 0 – 3 Lot #	220416A EXP:07-30-20
pH Paper 0 – 13 Lot #	222516 EXP:08-15-2019
Chlorine Test Strips Lot #	9080 EXP:01-2022

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Tallahassee Lakes

Central Laboratory Submittal Form

last revised Jan 25, 2018

Customer: WAS-SECT

Requester: Curtis Musson

Field Report Prepared By: Blake Spencer

Project ID: SMP

Collected By: Blake Spencer & Will LasleySampling Agency: FREP

Location	WIN ID / FILED ID →  G1WA0043	☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>7/10/19</u> Time <u>0847</u>	<u>Eastern</u> Central	Composite end Date _____ Time _____	Bottle Group(s) (See pg 2)
Field ID		Matrix (type, e.g., Salt, Fresh, etc) <u>Fresh</u>	Diss. Oxygen <u>68.9</u>	☐ mg/L ☒ % sat	Total Res. Chlorine (mg/L) <u>—</u>	A
WIN/STORET #	Location  Lake Tom John Middle	Temp (C) <u>30.0</u>	pH <u>6.4</u>	Sample Depth <u>0.3</u>	Sp. Conductance (umho/cm) <u>72</u>	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) <u>0.03</u>	Comments	
Location	WIN ID / FILED ID →  G1WA0041	☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>7/10/19</u> Time <u>1005</u>	<u>Eastern</u> Central	Composite end Date _____ Time _____	Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc) <u>Fresh</u>	Diss. Oxygen <u>93.9</u>	☐ mg/L ☒ % sat	Total Res. Chlorine (mg/L) <u>—</u>	A
WIN/STORET #	Location  Upper Dianne Lake Middle	Temp (C) <u>30.9</u>	pH <u>6.7</u>	Sample Depth <u>0.3</u>	Sp. Conductance (umho/cm) <u>91</u>	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) <u>0.04</u>	Comments	
Location	WIN ID / FILED ID →  G1WA0040	☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>7/10/19</u> Time <u>1055</u>	<u>Eastern</u> Central	Composite end Date _____ Time _____	Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc) <u>Fresh</u>	Diss. Oxygen <u>112.1</u>	☐ mg/L ☒ % sat	Total Res. Chlorine (mg/L) <u>—</u>	A
WIN/STORET #	Location  Lower Dianne Lake Middle	Temp (C) <u>31.1</u>	pH <u>7.0</u>	Sample Depth <u>0.3</u>	Sp. Conductance (umho/cm) <u>90</u>	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) <u>0.04</u>	Comments	
Location	WIN ID / FILED ID →  G1WA0054	☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>7/10/19</u> Time <u>1139</u>	<u>Eastern</u> Central	Composite end Date _____ Time _____	Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc) <u>Fresh</u>	Diss. Oxygen <u>53.5</u>	☐ mg/L ☒ % sat	Total Res. Chlorine (mg/L) <u>—</u>	A
WIN/STORET #	Location  Pine Hill Lake Middle	Temp (C) <u>31.8</u>	pH <u>8.4</u>	Sample Depth <u>0.3</u>	Sp. Conductance (umho/cm) <u>54</u>	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) <u>0.02</u>	Comments	

Relinquished By: <u>Blake Spencer</u>	Date/Time: <u>7/10/19 1402</u>	Shipping Method: <u>Hand Delivered</u>	Number of Coolers Shipped: <u>2</u>	Received By: <u>SR</u>	Date/Time: <u>7-10-19 / 2:02</u>
---------------------------------------	--------------------------------	--	-------------------------------------	------------------------	----------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 5	Preservative:	ICE	Enter Number of Bottles Sent to Lab	5
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 5	Preservative:	ICE	Enter Number of Bottles Sent to Lab	5
	CHLSUITE-W						
Group: A	Bottle Type:	P-500ML	# of Bottles: 5	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	5
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 5	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	5
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: B	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						

Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
----------	--------------	---------	-----------------	-----------------------------	-------------------------------------	---

W-TKN
W-TOC

Group: B	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	1
----------	--------------	---------	-----------------	--------------------------	-------------------------------------	---

W-PO4-F

Group: C	Bottle Type:	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
----------	--------------	------	-----------------	-------------------	-------------------------------------	---

ALKALINITY
TURBIDITY
W-CL-IC
W-COLOR
W-F
W-SO4-IC
W-TDS
W-TSS

Group: C	Bottle Type:	BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
----------	--------------	-------	-----------------	-------------------	-------------------------------------	---

CHLSUITE-W

Group: C	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
----------	--------------	---------	-----------------	-----------------------------	-------------------------------------	---

W-NH3
W-NO2NO3
W-S-A-TP
W-TKN
W-TOC

Group: C	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	1
----------	--------------	---------	-----------------	--------------------------	-------------------------------------	---

W-PO4-F

Tallahassee Lakes

Central Laboratory Submittal Form

last revised Jan 25, 2018

Customer: WAS-SECT


Requester: Curtis Musson

Field Report Prepared By: Blake Spencer

Project ID: SMP

Collected By: Blake Spencer + Will Lasley

Sampling Agency: FDEP

Location	WIN ID / FILED ID →  G1WA0004	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 7/10/19 Time 1203	Eastern Central	Composite end Date Time	Bottle Group(s) (See pg 2)
Field ID	Location Lake Arrowhead at boat dock at Turtle Crk Ln near outlet	Matrix (type, e.g., Salt, Fresh, etc) Fresh	Diss. Oxygen 134.6	☐ mg/L ☒ % sat	Total Res. Chlorine (mg/L)	A
WIN/STORET #	Temp (C) 31.5 pH 6.8	Sample Depth 0.3	☐ ft ☒ m	Sp. Conductance (umho/cm) 80		
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 0.04	Comments	
Location	WIN ID  G1WA0004	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 7/10/19 Time 1210	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID	Location Lake Arrowhead at boat dock at Turtle Crk Ln near outlet	Matrix (type, e.g., Salt, Fresh, etc) Fresh	Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	C
WIN/STORET #	Field ID  G1WA0004_DUP	Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments Field Duplicate	
Location	Location Lake Arrowhead at boat dock at Turtle Crk Ln near outlet	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 7/10/19 Time 1225	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID	FILED ID  FB_07102019	Matrix (type, e.g., Salt, Fresh, etc) Fresh	Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	B
WIN/STORET #	Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments Field Blank	
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN/STORET #		Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments	

Relinquished By: 	Date/Time 7/10/19 1402	Shipping Method Hand Delivered	Number of Coolers Shipped: 2	Received By: SR	Date/Time 7-10-19 / 2:02
---	------------------------	--------------------------------	------------------------------	-----------------	--------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 5	Preservative:	ICE	Enter Number of Bottles Sent to Lab	5
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 5	Preservative:	ICE	Enter Number of Bottles Sent to Lab	5
	CHLSUITE-W						
Group: A	Bottle Type:	P-500ML	# of Bottles: 5	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	5
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 5	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	5
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: B	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						

Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	_____ / _____
	W-TKN					
	W-TOC					

Group: B	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	_____ / _____
	W-PO4-F					

Group: C	Bottle Type:	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	_____ / _____
	ALKALINITY					
	TURBIDITY					
	W-CL-IC					
	W-COLOR					
	W-F					
	W-SO4-IC					
	W-TDS					
	W-TSS					

Group: C	Bottle Type:	BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	_____ / _____
	CHLSUITE-W					

Group: C	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	_____ / _____
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					

Group: C	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	_____ / _____
	W-PO4-F					

CALIBRATION AND VERIFICATION LOG (FDEP SOP FT 1000-FT 1500, FD 1000-FD 4000)

Boldly "X" this box if there are qualified data on this page.

Meter ID: Pro DSS 195104543

RQ: 2019-07-08

Project: SMP

Notes: (1) Always wait for meter to stabilize before recording any readings.

(2) Report all digits displayed. Do not round before reporting measurements. (See special instructions for depth).

(3) For Calibrations, record calibrated meter reading. Do not record initial meter reading before calibration.

Temperature (Quarterly) FT 1400

Date of Last Temperature Verification

DO DEP SOP FT 1500	Name	Date	Time CT-ET	Temp °C	Baro-meter mmHg	D.O. Chart mg/L	Meter D.O. mg/L	% DO	Probe Charge	Probe Gain	Pass / Fail	Lab / Field
Calibr.	Blake Spencer	7/10/19	0719	20.9	755.6	8.9	8.88	99.5	—	—	P / F	L / F
ICV	Blake Spencer	7/10/19	0720	21.0	755.7	8.9	8.90	100.0	—	—	P / F	L / F
CCV	Blake Spencer	7/10/19	1341	26.3	756.1	8.01	8.28	102.7	—	—	P / F	L / F
CCV											P / F	L / F

DO Acceptance criteria from Table ± 0.3 mg/L.

Rapid-Pulse Sensors: DO Gain Range 0.7 to 1.4; DO Charge Range 25-75.

Optical: DO gain range 0.85 to 1.15 (Pro DSS 0.75 to 1.50); DO charge N/A. Steady-state & Galvanic Sensors: DO Gain & Charge N/A.

Spec. Cond. FT 1200	Name	Date	Time CT-ET	Lot #	Expir. Date	Standard μ mhos/cm	Meter Reading μ mhos/cm	Pass / Fail	Lab / Field
Calibr.	Blake Spencer	7/10/19	0724	190618F	06/2020	1000	1000	P / F	L / F
ICV	Blake Spencer	7/10/19	0725	190619F	06/2020	1000	998	P / F	L / F
CCV	Blake Spencer	7/10/19	1345	2808884	7/2020	100	101.5	P / F	L / F
CCV								P / F	L / F

Conductivity Acceptance criteria $\pm 5\%$

pH DEP SOP FT 1100	Name	Date	Time CT-ET	Lot #	Expir. Date	pH Buffer SU	Temp °C	Meter reading SU	mV	Pass / Fail	Lab / Field
Calibr.	Blake Spencer	7/10/19	0728	190621E	01/2020	7.01	22.2	7.01	-39.9	P / F	L / F
Calibr.	Blake Spencer	7/10/19	0730	190405B	10/2020	4.00	22.1	4.00	146.6	P / F	L / F
Calibr.	Blake Spencer	7/10/19	0733	190621F	01/2020	10.03	22.2	10.03	198.6	P / F	L / F
ICV	Blake Spencer	7/10/19	0735	190621F	01/2020	10.03	22.2	10.03	199.2	P / F	L / F
CCV	Blake Spencer	7/10/19	1450	190405B	10/2020	4.00	23.6	4.05	143.5	P / F	L / F
CCV										P / F	L / F

pH Acceptance criteria ± 0.2 SU; mV pH 7 Range 0 ± 50 ;

mV pH 4 Range $+180 \pm 50$;

mV pH 10 Range -180 ± 50 ;

If mV are recorded: slope from 7 to 10 _____, slope from 4 to 7 _____ (both must be between 165 and 180 mV)

Does meter have a depth sensor that will be used to measure total depth & sample depth? YES / NO / NA (not surf. water project)

If YES, complete daily Calibr. & ICV below and list date of last quarterly depth verification: _____

If NO, what will be used? (circle one) Secchi Disk Line / Sonar Unique ID: _____; Date of last verification: _____

Depth Sensor (Daily Calibration & ICV)	Name	Date	Time CT-ET	Calibrated Value (0.00 or Offset), meters	ICV Value, meters	Pass / Fail	Lab / Field
Pressure mode in air	Blake Spencer	7/10/19	0737	0.00	0.00	P / F	L / F

Report two decimal places. Round numbers ≤ 4 down, ≥ 5 up. ICV acceptance criteria $\pm 5\%$ or ± 0.05 m, whichever is greater.

COMMENTS:

Date of Request: 03-JUN-2019
 Created By: MUSSON_C On: 03-JUN-2019
 Modified By: WATTS_J On: 18-JUN-2019
 Customer: WAS-SECT
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District:
 Sampling Event: Tallahassee Lakes

Send Coolers To:

Phone: 850-245-8453
 2600 Blair Stone Rd
 Tallahassee, FL 32399
 Attn: Curtis Musson

Program Module Number:

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 18-JUN-2019
 Biology Request Reviewed By: JASROTIA_P On: 18-JUN-2019
 Sampling Kit Required: YES Ship on: 05-JUL-2019
 Sampling Kit Shipped: YES On: 01-JUL-2019
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 10-JUL-2019
 Received By:

Send Final Report To:

2600 Blair Stone Rd
 Tallahassee, FL 32399
 Attn: Curtis Musson

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: Nutrients x5
 WBIDs: 546A, 546B, 564A, 564B, 647A

Group B: Nutrient QC Blank
 Group C: Nutrient QC DUP

Packing Notes:
 No FedEx Labels
 No Trash Bags

Bottle Group A (Water) With 5 Samples:

Bottle Type: P-1L	Number of Bottles: 5	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 5	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 5	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 5	Preserved With: FILTER-ICE

Bottle Group A (Water) With 5 Samples:

Bottle Type: P-125ML Number of Bottles: 5 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L Number of Bottles: 1 Preserved With: ICE
 ALKALINITY Template: DEFAULT (SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
 TURBIDITY Template: DEFAULT (EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
 W-CL-IC Template: DEFAULT (EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
 W-COLOR Template: DEFAULT (SM 2120 B) True Color measured at 450 nm
 Color (true)
 W-F Template: DEFAULT (SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
 W-SO4-IC Template: DEFAULT (EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
 W-TDS Template: DEFAULT (SM 2540 C-97) Total Dissolved Solids in aqueous matrices
 W-TSS Template: DEFAULT (SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: BP-1L Number of Bottles: 1 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10200 H (mod.)) Phytoplankton: chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
 W-TOC Template: DEFAULT (SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 1 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 1 Samples:

Bottle Type: BP-1L Number of Bottles: 1 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10200 H (mod.)) Phytoplankton: chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
 W-TOC Template: DEFAULT (SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 1 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Type: P-1L Number of Bottles: 1 Preserved With: ICE
 ALKALINITY Template: DEFAULT (SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
 TURBIDITY Template: DEFAULT (EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
 W-CL-IC Template: DEFAULT (EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
 W-COLOR Template: DEFAULT (SM 2120 B) True Color measured at 450 nm
 Color (true)
 W-F Template: DEFAULT (SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
 W-SO4-IC Template: DEFAULT (EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
 W-TDS Template: DEFAULT (SM 2540 C-97) Total Dissolved Solids in aqueous matrices
 W-TSS Template: DEFAULT (SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Cooler Packing Worksheet for Request: RQ-2019-07-08-19

Tallahassee Lakes

Ship Cooler On: 7/5/2019

Customer/Project: WAS-SECT/SMP

Assigned To: REYNOLDS_T

Requester: Curtis Musson

Priority: 3

850-245-8453

2600 Blair Stone Rd

Tallahassee, FL 32399

Attn: Curtis Musson

Comments:

No preservatives needed.

Group A: Nutrients x5

WBIDs: 546A, 546B, 564A, 564B, 647A

Group B: Nutrient QC Blank

Group C: Nutrient QC DUP

Packing Notes:

No FedEx Labels

No Trash Bags

Requested Analyses:

Bottle Group: A

of Sites: 5

Container ID: P-1L

Qty: 5 Preservation: ICE

Lot # 00073852

Description: Plastic Bottle 1L

Analysis

ALKALINITY

TURBIDITY

W-CL-IC

W-COLOR

W-F

W-SO4-IC

W-TDS

W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO3/L

Turbidity in aqueous matrices

Chloride in aqueous matrices

True Color measured at 450 nm

Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)

Sulfate in aqueous matrices

Total Dissolved Solids in aqueous matrices

Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 5 Preservation: ICE

Lot # 1248230

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-500ML

Qty: 5 Preservation: ICE And H2SO4

Lot # 00073854

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3
W-NO2NO3
W-S-A-TP
W-TKN
W-TOC

Description

Ammonia in aqueous matrices as mg N/L
Nitrite/Nitrate in aqueous matrices as mg N/L
Total Phosphorus in aqueous matrices as mg P/L
Total Kjeldahl Nitrogen in aqueous matrices
Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 5 Preservation: FILTER-ICE

Lot # 00073850

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group: B

of Sites: 1

Container ID: P-1L

Qty: 1 Preservation: ICE

Lot # 00073852

Description: Plastic Bottle 1L

Analysis

ALKALINITY
TURBIDITY
W-CL-IC
W-COLOR
W-F
W-SO4-IC
W-TDS
W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO3/L
Turbidity in aqueous matrices
Chloride in aqueous matrices
True Color measured at 450 nm
Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Sulfate in aqueous matrices
Total Dissolved Solids in aqueous matrices
Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 1 Preservation: ICE

Lot # 1248230

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-500ML

Qty: 1 Preservation: ICE And H2SO4

Lot # 00673854

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3
W-NO2NO3
W-S-A-TP
W-TKN
W-TOC

Description

Ammonia in aqueous matrices as mg N/L
Nitrite/Nitrate in aqueous matrices as mg N/L
Total Phosphorus in aqueous matrices as mg P/L
Total Kjeldahl Nitrogen in aqueous matrices
Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 1 Preservation: FILTER-ICE

Lot # 00673850

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group: C

of Sites: 1

Container ID: P-1L

Qty: 1 Preservation: ICE

Lot # 00673852

Description: Plastic Bottle 1L

Analysis

ALKALINITY
TURBIDITY
W-CL-IC
W-COLOR
W-F
W-SO4-IC
W-TDS
W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO3/L
Turbidity in aqueous matrices
Chloride in aqueous matrices
True Color measured at 450 nm
Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Sulfate in aqueous matrices
Total Dissolved Solids in aqueous matrices
Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 1 Preservation: ICE

Lot # 1248230

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-500ML

Qty: 1 Preservation: ICE And H2SO4

Lot # 00073854

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3

W-NO2NO3

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 1 Preservation: FILTER-ICE

Lot # 00073850

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Cooler Packed By: Tyler Reynolds Number of Coolers: 2 Date: 07/01/19

Kit must also include:

- ☒ Field Sheets
- ☒ Temperature Control Bottle
- ☒ FedEx Bills, if applicable
- ☒ Plastic Bags/Zip Ties
- ☒ Acid Labels (sets of 24)

If Preservation Included:

ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____

PLEASE RETURN ALL COOLERS FOR RQ-2019-07-08-19