

Login Checklist

RQ- 2020-06-08-35

Login Station ID: #5

Shipping Method: (FedEx) | UPS | HD | Greyhound

Date/Time of Receipt: 6/ 26 /20 @ 10:50

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.2				17		✓			1278 4011 5136

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 °C (above 10.0 °C for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ✓

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ✓ No _____

Caps on tight?

Yes ✓ No _____

Sufficient Sample Volume:

Yes ✓ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ✓ Init: KK

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ✓ No _____ NA _____ Init: KK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ✓ Init: KK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: KK

Date: 6/ 26 /20

Event contains NCRs (Y/N)? N

Event ID:

Nassau West 1 2020

NE-DIST-2020-06-26-01 (SMP)

Date Received: 26-JUN-2020 10:50

Login Checklist

Login Preservation Equipment

Infrared Thermometer ID:	IR TEMP GUN #5
pH Test Strips 0 – 6 Lot #	213316BV EXP:5-15-21
pH Paper 0 – 3 Lot #	
pH Paper 0 – 13 Lot #	231019 EXP:11-1-22
Chlorine Test Strips Lot #	8261 EXP:07-2021

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection Central Laboratory Submittal Form

Customer: NE-DIST

Requester: Jeremy M. Parrish

Field Report Prepared By: K. McDonald

Project ID: SMP

Collected By: J. Parrish, K. McDonald

Sampling Agency: FDEP NE ROC

Location		☐ Comp	Collection (comp begin or grab)		Eastern	Composite end		Bottle Group(s) (See pg 2)
File WIN ID/Field ID: 19010048 DEEP CREEK AT CR 121		☒ Grab	Date 6/25/20	Time 0920	Central	Date	Time	
Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L	Total Res. Chlorine		B	
Fresh		4.21		☒ % sat	(mg/L)			
Temp (C) 24.4		pH 3.97		Sample Depth 0.1	☒ ft	Sp. Conductance (umho/cm) 70.2		
☐ dd Salinity (ppt) 0.03		Comments		☒ m				
Location		☐ Comp	Collection (comp begin or grab)		Eastern	Composite end		Bottle Group(s)
File WIN ID/Field ID: 19010083 Tributary to Deep Creek @ Kinard Rd.		☒ Grab	Date 6/25/20	Time 0945	Central	Date	Time	
Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L	Total Res. Chlorine		D	
Fresh		1.99		☒ % sat	(mg/L)			
Temp (C) 24.1		pH 5.39		Sample Depth 0.10	☐ ft	Sp. Conductance (umho/cm) 73.9		
☐ dd Salinity (ppt) 0.03		Comments		☒ m				
Location		☐ Comp	Collection (comp begin or grab)		Eastern	Composite end		Bottle Group(s)
File WIN ID/Field ID: 19010127 UNNAMED STREAM @ CR 121		☒ Grab	Date 6/25/20	Time 10:05	Central	Date	Time	
Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L	Total Res. Chlorine		B	
Fresh		1.38		☐ % sat	(mg/L)			
Temp (C) 24.2		pH 4.00		Sample Depth 0.10	☐ ft	Sp. Conductance (umho/cm) 41.8		
☐ dd Salinity (ppt) 0.02		Comments		☒ m				
Location		☐ Comp	Collection (comp begin or grab)		Eastern	Composite end		Bottle Group(s)
File WIN ID/Field ID: 19010027 ST MARYS R SR 2 EAST		☒ Grab	Date 6/25/20	Time 1020	Central	Date	Time	
Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L	Total Res. Chlorine		A	
Fresh		4.58		☐ % sat	(mg/L)			
Temp (C) 26.0		pH 4.33		Sample Depth 0.3	☐ ft	Sp. Conductance (umho/cm) 61.5		
☐ dd Salinity (ppt) 0.03		Comments		☒ m				

Relinquished By: K. McDonald	Date/Time 6/25/20 1030	Shipping Method FedEx	Number of Coolers Shipped: 1	Received By: HK	Date/Time 6-26-20 / 1050
------------------------------	------------------------	-----------------------	------------------------------	-----------------	--------------------------

* Collection time taken from bottle

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY					
	TURBIDITY					
	W-CL-IC					
	W-COLOR					
	W-F					
	W-SO4-IC					
	W-TDS					
	W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: A	Bottle Type:	P-250ML-WI-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	NE-ALS-ECQ					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	HNO3	Enter Number of Bottles Sent to Lab _____
	W-HARD					
	W-ICP					
	W-ICPMS					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab _____
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY					
	TURBIDITY					
	W-CL-IC					
	W-COLOR					
	W-F					
	W-SO4-IC					
	W-TDS					
	W-TSS					

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: NE-DIST

Requester: Jeremy M. ParrishField Report Prepared By: K. McDonald

Project ID: SMP

Collected By: J. Parrish, K. McDonaldSampling Agency: FDEP NEROC

Location		☐ Comp ☒ Grab		Collection (comp begin or grab) Date <u>6/25/20</u> Time <u>1055</u>		☒ Eastern ☐ Central		Composite end Date <u>—</u> Time <u>—</u>		Bottle Group(s) (See pg 2)	
Field ID WIN ID/Field ID:  G4NE0302		Matrix (type, e.g., Salt, Fresh, etc) <u>Fresh</u>		Diss. Oxygen <u>2.67</u>		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L) <u>—</u>		<u>C</u>	
WIN Unnamed Drain to Brandy Branch at US301		Temp (C) <u>24.5</u>		pH <u>3.84</u>		Sample Depth <u>0.3</u>		☐ ft ☒ m		Sp. Conductance (umho/cm) <u>82.2</u>	
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt) <u>0.04</u>		Comments					

Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date <u>—</u> Time <u>—</u>		☐ Eastern ☐ Central		Composite end Date <u>—</u> Time <u>—</u>		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen ☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)					
WIN/STORET #		Temp (C)		pH		Sample Depth ☐ ft ☐ m		Sp. Conductance (umho/cm)			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments					

Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date <u>—</u> Time <u>—</u>		☐ Eastern ☐ Central		Composite end Date <u>—</u> Time <u>—</u>		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen ☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)					
WIN/STORET #		Temp (C)		pH		Sample Depth ☐ ft ☐ m		Sp. Conductance (umho/cm)			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments					

Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date <u>—</u> Time <u>—</u>		☐ Eastern ☐ Central		Composite end Date <u>—</u> Time <u>—</u>		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen ☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)					
WIN/STORET #		Temp (C)		pH		Sample Depth ☐ ft ☐ m		Sp. Conductance (umho/cm)			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments					

Relinquished By: <u>K. McDonald</u>	Date/Time <u>6/25/20</u>	Shipping Method <u>FedEx</u>	Number of Coolers Shipped: <u>1</u>	Received By: <u>KK</u>	Date/Time <u>6-26-20/1050</u>
--	-----------------------------	---------------------------------	--	---------------------------	----------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>1</u>
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>1</u>
	CHLSUITE-W					
Group: A	Bottle Type:	P-250ML-WI-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>1 to ALS</u>
	NE-ALS-ECQ					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	HNO3	Enter Number of Bottles Sent to Lab <u>1</u>
	W-HARD W-ICP W-ICPMS					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>1</u>
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab <u>1</u>
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>2</u>
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS					

4/4

Group: B	Bottle Type: BP-1L	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab
CHLSUITE-W				
Group: B	Bottle Type: P-250ML-WI-THI	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab
NE-ALS-ECQ				
Group: B	Bottle Type: P-500ML	# of Bottles: 2	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab
W-NH3				
W-NO2NO3				
W-S-A-TP				
W-TKN				
W-TOC				
Group: B	Bottle Type: P-125ML	# of Bottles: 2	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab
W-PO4-F				
Group: C	Bottle Type: P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab
ALKALINITY				
TURBIDITY				
W-CL-IC				
W-COLOR				
W-F				
W-SO4-IC				
W-TDS				
W-TSS				
Group: C	Bottle Type: P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab
W-NH3				
W-NO2NO3				
W-S-A-TP				
W-TKN				
W-TOC				
Group: C	Bottle Type: P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab
W-PO4-F				
Group: D	Bottle Type: P-250ML-WI-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab
NE-ALS-ECQ				

CHAIN OF CUSTODY / LABORATORY ANALYSIS REQUEST FORM

9143 Philips Highway, Suite 200 Jacksonville, FL 32256 / Ph(904) 739-2277 / FAX (904) 739-2011

SR #

ALS Contact:

Page 1 of 1

[illegible]

Date of Request: 04-JUN-2020
 Created By: PARRISH_J On: 04-JUN-2020
 Modified By: JASROTIA_P On: 04-JUN-2020
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Event Description: Nassau West 1 2020

Send Coolers To:

Phone: 904-256-1700
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Cooler Ship EMail: Jeremy.M.Parrish@dep.state.fl.us

Priority: 3
 Event Status: A
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 04-JUN-2020
 Biology Request Reviewed By: JASROTIA_P On: 04-JUN-2020
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 08-JUN-2020
 Logged In By:

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Report Notification EMail: Jeremy.M.Parrish@dep.state.fl.us

Comments: Group A: (Surf.Fresh)Nutrients, Metals, Bacteria
 Group B:(Surf. Fresh)Nutrients, Bacteria
 Group C:(Surf.Fresh) Nutrients
 Group D:(surf.Fresh)Bacteria

Packing Notes:
 None

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-ALS-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by ALS in Jacksonville
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO ₃
W-HARD	Template: DEFAULT	(SM 2340B) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO ₃
Hardness		
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium		
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
*Boron		
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 2 Samples:

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 2	Preserved With: ICE
NE-ALS-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by ALS in Jacksonville

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
-------------------	----------------------	---------------------

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-ALS-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by ALS in Jacksonville

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.