

RQ-2020-08-17-49

Login Checklist

Login Station ID: #4

Shipping Method: FedEx UPS | HD | GreyhoundDate/Time of Receipt: 09/18/2020 @ 9:40

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.6°C				4		x			9117 6381 7768

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 °C (above 10.0 °C for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes TR No X Init: Tyler

Chlorine detected? (One container checked per Field ID)

Yes _____ No TR Init: Tyler

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No _____ NA _____ Init: Tyler

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA X Init: Tyler

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: Tyler ReynoldsDate: 09/18/2020Event contains NCRs (Y/N)? None

Event ID: _____ Continuous Monitoring Event
 NE-DIST-2020-09-18-01 (SMP)
 Date Received: 18-SEP-2020 09:40

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	#4 Temp Gun EXP:11/05/2020
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	231019 EXP:11/01/2022
Chlorine Test Strips	8261 EXP:07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 9/17/2020
Customer: NE-DIST
RQ: RQ-2020-08-17-49
Collected By: Kimberly Appleby, Brian Davis
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Unnamed Drain South Entrance	 G5NE0591
Plummer Creek @ Second Island	 G4NE0301

RELINQUISHED BY(SIGNATURE): *Kimberly Appleby*

DATE/TIME:

9/17/2020

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *Tyler Reynolds*

Rec'd/Inspected Date: *09/18/2020*

CALIBRATION AND VERIFICATION LOG (FDEP SOP FT 1000-FT 1500, FD 1000-FD 4000)

Boldly "X" this box if there are qualified data on this page.

Meter ID: 5+itc6

RQ: 2020-08-17-49

Project: CM Purmance

- Notes: (1) Always wait for meter to stabilize before recording any readings.
 (2) Report all digits displayed. Do not round before reporting measurements. (See special instructions for depth).
 (3) For Calibrations, record calibrated meter reading. Do not record initial meter reading before calibration.

Temperature (Quarterly) FT 1400

Date of Last Temperature Verification 6/18/20

DO DEP SOP FT 1500	Name	Date	Time CT-ET	Temp °C	Baro- meter mmHg	D.O. Chart mg/L	Meter D.O. mg/L	% DO	Probe Charge	Probe Gain	Pass / Fail	Lab / Field
Calibr.	Brian Davis	9/17/20	749	22.7	757.1	8.6	8.54	99.6	✓	1.02	(P) F	(L) F
ICV	↓	↓	750	23.0	757.1	8.5	8.54	99.5	✓	1.02	(P) F	(L) F
CCV	Kim Appleby	✓	7428	23.2	755.9	8.5	8.44	98.8	✓	1.02	(P) F	(L) F
CCV											P/F	L/F

DO Acceptance criteria from Table ± 0.3 mg/L.

Rapid-Pulse Sensors: DO Gain Range 0.7 to 1.4; DO Charge Range 25-75.

Optical: DO gain range 0.85 to 1.15 (Pro DSS 0.75 to 1.50); DO charge N/A. Steady-state & Galvanic Sensors: DO Gain & Charge N/A.

Spec. Cond. FT 1200	Name	Date	Time CT-ET	Lot #	Expir. Date	Standard µmhos/cm	Meter Reading µmhos/cm	Pass / Fail	Lab / Field
Calibr.	Brian Davis	9/17/20	753	200407c	4/21	1000	1000	(P) F	(L) F
ICV	↓	↓	755	20190258	11/22	20,000	19750	(P) F	(L) F
CCV	Kim Appleby	↓	1430	200407c	4/2021	100	98.3	(P) F	(L) F
CCV								P/F	L/F

Conductivity Acceptance criteria $\pm 5\%$

pH DEP SOP FT 1100	Name	Date	Time CT-ET	Lot #	Expir. Date	pH Buffer SU	Temp °C	Meter reading SU	mV	Pass / Fail	Lab / Field
Calibr.	Brian Davis	9/17/20	805	2001C31	1/22	7.01	23.7	7.01	-33.5	(P) F	(L) F
Calibr.	↓	↓	808	290629	10/21	4.0	24.5	4.0	142.8	(P) F	(L) F
Calibr.	↓	↓	811	2008911	8/21	10.01	24.7	9.99	-20.6	(P) F	(L) F
ICV	↓	↓	813	2001C31	1/22	7.0	24.5	7.07	-34.1	(P) F	(L) F
CCV	Kim Appleby	↓	1432	2910629	10/21	4.00	24.6	4.68	142.8	(P) F	(L) F
CCV										P/F	L/F

pH Acceptance criteria ± 0.2 SU; mV pH 7 Range 0 ± 50 ; mV pH 4 Range $+180 \pm 50$; mV pH 10 Range -180 ± 50 .
 If mV are recorded: slope from 7 to 10 _____, slope from 4 to 7 _____ (both must be between 165 and 180 mV)

Does meter have a depth sensor that will be used to measure total depth & sample depth? YES / NO / NA (not surf. water protect)

If YES, complete daily Calibr. & ICV below and list date of last quarterly depth verification:

If NO, what will be used? (circle one) Secchi Disk Line / Sonar Unique ID: _____; Date of last verification: _____

Depth Sensor (Daily Calibration & ICV)	Name	Date	Time CT-ET	Calibrated Value (0:00 or Offset), meters	ICV Value, meters	Pass / Fail	Lab / Field
Pressure mode in air	Brian Davis	9/17/20	815	0.00	0.00	(P) F	(L) F

Report two decimal places. Round numbers ≤ 4 down, ≥ 5 up. ICV acceptance criteria $\pm 5\%$ or ± 0.05 m, whichever is greater.

COMMENTS:



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION STRATEGIC MONITORING PROGRAM FIELD SHEET

January 2020

Meter Passed End
of Day CCV
Yes / No

WIN Station Name: Plummer Creek @ Second Island

Date: 9/17/2020

WIN/Field ID: G4NE0301

WBID: 2130

ENR:

Latitude: 30.5796

County: NASSAU

Org ID: 21FLA

Longitude: -81.6564

Receiving Body of Water: Nassau - St. Marys

RQ- 2020-08-17-49

Sampling Team Members		WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check
☒	Kimberly Appleby		x		x	x
☒	Brian Davis	x		x		
☐						
☐						

Sampling Equipment	
☒ Sample Container	☐ Carboy
☐ Dipper	☐ Van Dorn
☐ Syringe	☐ Pole
Depth measured with: Sonar	
Secchi Equipment ID:	
Collection Method	
☐ Wading	☐ Canoe/Kayak
☐ From Shore	☐ Electric Motor
☐ Other	☒ Gasoline Motor

Water Level: ☒ Normal ☐ Low ☐ High ☐ Dry ☐ Pooled ☐ Flooded		Meter ID# STITCH	
Photos: No	Flow: FLOW	Tide: RISING	Tide Times: High: Low:
Biological Samples Collected: ☒ None ☐ HA ☐ SCI ☐ RPS ☐ Algae ID ☐ LVS ☐ LVI Other:			
SBIO ID Numbers:			
Notes:			

Duplicate Sample

Time Zone: EST	Time: N/A	Field ID: N/A	(WIN ID_DUP)
WIN DMT Activity ID:			

Blank

Time Zone:	Time: N/A	Field ID: N/A	(Blank Type_DDDMMYYY)
DI Source: N/A	Location: N/A		
DI Type: N/A	Equipment ID: N/A		

LIMS EVENT ID: WIN Import ID:

Enter Field Parameters, Verify Station ID In LIMS DMT: QC Station ID, Field Parameters In LIMS DMT:

Scan/Save Field Sheets Migrate Data to WIN: Verify Data in WIN:



RQ-2020-08-17-49

Customer: WQAP

Project ID: SMP

Collected By: Kimberly Appleby, Brian Davis

Field Report Prepared By: Kimberly Appleby

Sampling Agency: FDEP

Place Label Here						Comments: Microbiology sample(s) submitted to contract laboratory				
WIN ID/Field ID: 										
G4NE0301										
Location: Plummer Creek @ Second Island										
Matrix: Marine						(Check one) ☒ GRAB ☐ COMPOSITE				
Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
9/17/2020	11:10 EST	1.7	21.4	26.1	5.76	0.3	0.3 ☐ VOB (S)	2.9	111	0.05
Central Lab please use top row for login purposes										
	11:12 EST	1.54	19	26	5.7	2.1			110.9	0.05
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				☒ Ice ☒ H2SO4*		☒ <2	1	B
		Lot #		SA9354059		Exp:		12/20/20		
Metals (P-500ML)		☐ W-ICPMS ☐ W-ICP ☐ W-HARD				☐ Ice ☐ HNO3*		☐ <2		
		Lot #				Exp:				
Filtered Nutrients (P125ML)		☒ W-P04-F ☒ Field Filtered 0.45 µm Filter				☒ Ice			1	B
		Filter Lot #		R9BA86875						
		Syringe Lot #								
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	B
Physical/Aggregate (Fresh) (P-1L)		☐ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-C / W-COLOR / W-SO4-IC / W-TDS				☐ Ice				
Physical/Aggregate (Marine) (P-1L)		☒ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				☒ Ice			1	B
Macroinvertebrates (PJ-2L)		☐ MI-FW-QLDC				☐ Formalin				
Periphyton (PT-50ML)		☐ ALGAE-ID				☐ Ice				
Microbiology (Contract Lab Bottle)		☐ E Coli ☐ F Coli ☒ Enterococci				☒ Ice			1	B
		☒ Contract Lab								
Molecular (QPCR-P-500ML)		☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3				☐ Ice				
		☐ PCR-GULL2 ☐ PCR-GFD ☐								
Tracers (BG-500ML)		☐ W-E8321-DI ☐ W-E8321-MS				☐ Ice				
Pesticides (BG-500ML) (BG-1L)		☐ W-E8321-DI ☐ W-E8321-MS ☐ W-PSNP-TQ ☐ W-CT-CL-R				☐ Ice				
		☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution)				☐ Ice				
						☐ Ice				
Name: Kimberly Appleby Brian Davis				Signature: 				Date: 9/17/2020		

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution



SR #
ALS Contact

9143 Phillips Highway, Suite 200, Jacksonville, FL 32256
Phone (904) 739-2277 / 800-695-7222 x06 / FAX (904) 739-2011

Page _____ of _____

Project Name CM Plumber		Project Number PA-2020-08-17-19		ANALYSIS REQUESTED (include Method Number and Container Preservative)	
Report To J Lewis		Report CC DEPARTMENTAL		Preservative Key	
Company/Address 8800 Bryn Mawr Hwy W Suite 100		Custodian DEPT. ST. FL. US		0. None	
Phone # 904-256-1700		FAX #		1. HCL	
Sample Signature J Lewis		Sampler's Printed Name J Lewis		2. HNO3	
CLIENT SAMPLE ID GYNEO301		LAB ID		3. H2SO4	
SAMPLING DATE 9/17/20		TIME 11:05		4. NaOH	
Matrix SW		Matrix		5. Zn, Acetate	
NUMBER OF CONTAINERS 1		NUMBER OF CONTAINERS 1		6. MeOH	
PRESERVATIVE ELUTION		PRESERVATIVE		7. NaHSO4	
THERMAL STABILITY STABLE		THERMAL STABILITY		8. Other	
REPORT REQUIREMENTS 1. Results Only		REPORT REQUIREMENTS		REMARKS ICE	
2. Results - QC Summary		2. Results - QC Summary		FRESH	
3. Results - QC Summary as required		3. Results - QC Summary as required			
4. Results - QC and Calibration Summary		4. Results - QC and Calibration Summary			
5. Data Validation Report with Raw Data		5. Data Validation Report with Raw Data			
6. Data		6. Data			
7. Yes		7. Yes			
8. No		8. No			
Signature J Lewis		Signature J Lewis		Signature J Lewis	
Printed Name J Lewis		Printed Name J Lewis		Printed Name J Lewis	
Firm FL. US		Firm FL. US		Firm FL. US	
Date/Time 9/17/20 13:43		Date/Time 9/17/20 13:43		Date/Time 9/17/20 13:43	

Date of Request: 03-AUG-2020
 Created By: DAVIS_B On: 03-AUG-2020
 Modified By: JASROTIA_P On: 03-AUG-2020
 Customer: NE-DIST
 Project: SMP
 Division:
 District: Northeast District
 Event Description: Continuous Monitoring Event

Send Coolers To:

Phone: 904-256-1568
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Brian G Davis
 Cooler Ship EMail: Brian.G.Davis@floridadep.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 03-AUG-2020
 Biology Request Reviewed By: JASROTIA_P On: 03-AUG-2020
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 17-AUG-2020
 Logged In By: KLUG_K On: 26-AUG-2020

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Brian G Davis
 Report Notification EMail: Brian.G.Davis@floridadep.gov

Comments: Continuous Monitoring SMP
 All Groups MARINE, do not send coolers.
 Group A: Nutrients, Bacteria (Enterococci + Fecal Coli)
 Group B: Nutrients, Bacteria

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-ALS-ENQ	Template: DEFAULT	(ASTM D650399) Enterococci by Enterolert/QT by ALS in Jacksonville
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-ALS-FC	Template: DEFAULT	(SM 9222 D) Fecal coliforms by MF by ALS in Jacksonville
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L	
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L	
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L	
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices	
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices	
Bottle Type: P-125ML		Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	
Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L	
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices	
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices	
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	
Bottle Type: BP-1L		Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry	
Bottle Type: P-250ML-WI-THI		Number of Bottles: 1	Preserved With: ICE
NE-ALS-ENQ	Template: DEFAULT	(ASTM D650399) Enterococci by Enterolert/QT by ALS in Jacksonville	