

RQ-2020-10-26-25

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 10/27/2020 9:55

*Cooler Temperature	Samples Frozen? YES	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
		HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
2.6				7			✓		92938007418

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☐ NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IM

Date: 10/27/2020

Event contains NCRs (Y/N)? ☒

Event ID:

Turtle spring
NE-DIST-2020-10-27-01 (SMP)
Date Received: 27-OCT-2020 09:55

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:11/5/20
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	231019 exp: 11/1/22
Chlorine Test Strips	8261 exp: 07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 10/26/2020 **Collected By:** Jeremy Parrish, Kelly McDonald
Customer: NE-DIST **Sampling Agency:** FDEP
RQ: RQ-2020-10-26-25 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1n

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Turtle Spring Head	 22051013
EqB	 EB102620

RELINQUISHED BY(SIGNATURE): Kelly A McDonald

DATE/TIME: 10/26/2020 1600

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

IM

Rec'd/Inspected Date: 10/27/20

CALIBRATION AND VERIFICATION LOG (FDEP SOP FT 1000-FT 1500, FD 1000-FD 4000)

Boldly "X" this box if there are qualified data on this page.

Meter ID:

YSE DSS

RQ:

2020-10-26-25

Project:

Turkey Spring

Notes: (1) Always wait for meter to stabilize before recording any readings.

(2) Report all digits displayed. Do not round before reporting measurements. (See special instructions for depth).

(3) For Calibrations, record calibrated meter reading. Do not record initial meter reading before calibration.

Temperature (Quarterly) FT 1400

Date of Last Temperature Verification

10/14/2020

DO DEP SOP FT 1500	Name	Date	Time CT-ET	Temp °C	Baro-meter mmHg	D.O. Chart mg/L	Meter D.O. mg/L	% DO	Probe Charge	Probe Gain	Pass / Fail	Lab / Field
Calibr.	J. Parnish	10/26/20	831	23.1	761.5	8.5	8.5	100.2	-	1.06	P/F	I/F
ICV	J	L	832	23.2	761.5	8.5	8.57	100.2	-	1.06	P/F	I/F
CCV	K. McDonald	10/26	1501	24.2	761.2	8.4	8.39	100.1	-	1.06	P/F	I/F
CCV											P/F	L/F

DO Acceptance criteria from Table ± 0.3 mg/L.

Rapid-Pulse Sensors: DO Gain Range 0.7 to 1.4; DO Charge Range 25-75.

Optical: DO gain range 0.85 to 1.15 (Pro DSS 0.75 to 1.50); DO charge N/A. Steady-state & Galvanic Sensors: DO Gain & Charge N/A.

Spec. Cond. FT 1200	Name	Date	Time CT-ET	Lot #	Expir. Date	Standard μ hos/cm	Meter Reading μ hos/cm	Pass / Fail	Lab / Field
Calibr.	J. Parnish	10/26/20	833	2004070	9/21	1000	1000	P/F	I/F
ICV	J	L	834	2004070	4/21	100	102.7	P/F	I/F
CCV	K. McDonald	10/26	1503	191025A	11/20	1413	1386	P/F	I/F
CCV								P/F	L/F

Conductivity Acceptance criteria $\pm 5\%$

pH DEP SOP FT 1100	Name	Date	Time CT-ET	Lot #	Expir. Date	pH Buffer SU	Temp °C	Meter reading SU	mV	Pass / Fail	Lab / Field
Calibr.	J. Parnish	10/26/20	835	2001C51	1/22	7.	23.9	7.01	29.2	P/F	I/F
Calibr.	J	L	836	2006B06	5/22	4.	23.8	4.00	149.3	P/F	I/F
Calibr.	J	L	837	2002911	8/21	10.	23.9	10.01	19.7	P/F	I/F
ICV	J	L	838	2006B06	5/22	4.	23.9	4.05	146	P/F	I/F
CCV	K. McDonald	10/26	1506	2002911	8/21	10.01	23.8	10.01	-20.4	P/F	I/F
CCV										P/F	L/F

pH Acceptance criteria ± 0.2 SU; mV pH 7 Range 0 ± 50 ;

mV pH 4 Range $+180 \pm 50$;

mV pH 10 Range -180 ± 50 ;

If mV are recorded: slope from 7 to 10 _____, slope from 4 to 7 _____ (both must be between 165 and 180 mV)

Does meter have a depth sensor that will be used to measure total depth & sample depth? YES / NO / NA (not surf. water project)

If YES, complete daily Calibr. & ICV below and list date of last quarterly depth verification: _____

If NO, what will be used? (circle one) Secchi Disk Line / Sonar Unique ID: _____; Date of last verification: _____

Depth Sensor (Daily Calibration & ICV)	Name	Date	Time CT-ET	Calibrated Value (0.00 or Offset), meters	ICV Value, meters	Pass / Fail	Lab / Field
Pressure mode in air	J. Parnish	10/26/20	841	0.00	0.00	P/F	I/F

Report two decimal places. Round numbers ≤ 4 down, ≥ 5 up. ICV acceptance criteria $\pm 5\%$ or ± 0.05 m, whichever is greater.

COMMENTS:



RQ-2020-10-26-25

Customer: WQAP

Project ID: SMP

Collected By: Jeremy Parrish, Kelly McDonald

Field Report Prepared By: Jeremy Parrish

Sampling Agency: FDEP

Place Label Here							Comments:			
WIN ID/Field ID:  22051013							J CODE TOTAL DEPTH. MAX YSI CORD LENGTH. CODE R FOR RECENT RAIN			
Location: Turtle Spring Head										
Matrix: Fresh							(Check one) ☒ GRAB ☐ COMPOSITE			
Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPTH)
10/26/2020	11:35 EST	0.66	7.8	22.3	7.05	2.0	3.967 ☒ VOB (S)	3.967	410.2	0.2
Central Lab please use top row for login purposes										
	11:40 EST	0.59	6.8	22.3	7.05	3.4			410.4	0.2
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # Sa9354050 Exp: 12.20.20				☒ Ice ☒ H2SO4* ☒ <2			1	A
Metals (P-500ML)		☐ W-ICPMS ☐ W-ICP ☐ W-HARD Lot # Exp:				☐ Ice ☐ HNO3* ☐ <2				
Filtered Nutrients (P125ML)		☒ W-P04-F ☒ Field Filtered 0.45 µm Filter Filter Lot # R9ba86875 Syringe Lot #				☒ Ice			1	A
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	A
Physical/Aggregate (Fresh) (P-1L)		☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-SO4-IC / W-TDS				☒ Ice			1	A
Physical/Aggregate (Marine) (P-1L)		☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				☐ Ice				
Macroinvertebrates (PJ-2L)		☐ MI-FW-QLDC				☐ Formalin				
Periphyton (PT-50ML)		☐ ALGAE-ID				☐ Ice				
Microbiology (Contract Lab Bottle)		☐ E Coli ☐ F Coli ☐ Enterococci ☐ Contract Lab				☐ Ice				
Molecular (QPCR-P-500ML)		☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD				☐ Ice				
Tracers (BG-500ML)		☐ W-E8321-DI ☐ W-E8321-MS				☐ Ice				
Pesticides (BG-500ML) (BG-1L)		☐ W-E8321-DI ☐ WE8321-MS ☐ W-PSNP-TQ ☐ W-CT-CL-R ☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution)				☐ Ice				
						☐ Ice				
Name: Kelly McDonald						Signature: Kelly A McDonald			Date: 10/26/2020	

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION STRATEGIC MONITORING PROGRAM FIELD SHEET

January 2020

Meter Passed End

of Day CCV

Yes / No

WIN Station Name: Turtle Spring Head

Date: 10/26/2020

WIN/Field ID: 22051013

WBID: 3422M

ENR:

Latitude: 29.8474

County: LAFAYETTE

Org ID: 21FLA

Longitude: -82.8903

Receiving Body of Water: Suwannee

RQ- 2020-10-26-25

Sampling Team Members		WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check
☒	Jeremy Parrish		☒		☒	☒
☒	Kelly McDonald	☒		☒	☒	☒
☐						
☐						

Sampling Equipment	
☒ Sample Container	☐ Carboy
☐ Dipper	☒ Van Dorn He-man
☐ Syringe	☐ Pole
Depth measured with: Meter	
Secchi Equipment ID:	
Collection Method	
☒ Wading	☐ Canoe/Kayak
☐ From Shore	☐ Electric Motor
☐ Other	☐ Gasoline Motor

Water Level: ☒ Normal ☐ Low ☐ High ☐ Dry ☐ Pooled ☐ Flooded		Meter ID# DESI	
Photos: NO	Flow: FLOW	Tide:	Tide Times: High: Low:
Biological Samples Collected: ☒ None ☐ HA ☐ SCI ☐ RPS ☐ Algae ID ☐ LVS ☐ LVI Other:			
SBIO ID Numbers:			
Notes: J CODE TOTAL DEPTH. MAX YSI CORD LENGTH. CODE R FOR RECENT RAIN			

Duplicate Sample

Time Zone: EST	Time: N/A	Field ID: N/A	(WIN ID_DUP)
WIN DMT Activity ID:			

Blank

Time Zone: EST	Time: 11:40	Field ID: EB102620	(Blank Type_DDMMYYYY)
DI Source: Ne roc	Location: Turtle spring head		
DI Type: EqB	Equipment ID: He-man		

LIMS EVENT ID: WIN Import ID:

Enter Field Parameters, Verify Station ID In LIMS DMT: QC Station ID, Field Parameters In LIMS DMT:

(Initials/Date)

(Initials/Date)

Scan/Save Field Sheets Migrate Data to WIN: Verify Data In WIN:

(Initials/Date)

(Initials/Date)

(Initials/Date)



RQ- 2020-10-26-25

Customer: WQAP

Project ID: SMP

Collected By: Jeremy Parrish, Kelly McDonald

Field Report Prepared By: Jeremy Parrish, Kelly McDonald

Sampling Agency: FDEP

BLANK

Field ID: EB102620

Comments:

Bottles labelled with FB102620
instead of EB102620.
EB label is correct.

Matrix: EqB

(Check one) ☐ COMPOSITE ☒ GRAB

Date

Time

DI Source: Ne roc

10/26/2020

11:40

EST / CST

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # sa9354050 Exp:	☒ Ice ☒ H2SO4	☐ <2	1	B
Metals (P-500ML)	☐ W-ICPMS ☐ W-ICP Lot # Exp:	☐ Ice ☐ H2SO4	☐ <2		
Filtered Nutrients (P125ML)	☒ W-PO4-F Filter ☒ Field Filtered 0.45 µm Filter Lot # R9ba86875 Syringe Lot #	☒ Ice		1	B
Physical/Aggregate (Fresh) (P-1L)	☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-4C / TDS	☒ Ice		1	B
Physical/Aggregate (Marine) (P-1L)	☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	☐ Ice			
Tracers (BG-500ML)	☐ W-E8321-DI ☐ W-E8321-MS	☐ Ice			
Pesticides (BG-500ML) (BG-1L)	☐ W-E8321-DI ☐ WE8321-MS ☐ W-PSNP-TQ ☐ W-CT-CL-R ☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution)	☐ Ice			
Name: Jeremy Parrish Kelly McDonald		Signature: <i>Kelly A McDonald</i>		Date: 10/26/2020	

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution

Date of Request: 02-OCT-2020
 Created By: PARRISH_J On: 02-OCT-2020
 Modified By: JASROTIA_P On: 07-OCT-2020
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Event Description: Turtle spring

Send Coolers To:

Phone: 904-256-1700
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Cooler Ship EMail: Jeremy.M.Parrish@dep.state.fl.us

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: JASROTIA_P On: 07-OCT-2020
 Biology Request Reviewed By: JASROTIA_P On: 07-OCT-2020
 Sampling Kit Required: YES Ship on: 16-OCT-2020
 Sampling Kit Shipped: YES On: 13-OCT-2020
 Sampling Kit Packed By: KLUG_K
 Preservatives Needed: NO
 Date to Receive Samples: 26-OCT-2020
 Logged In By:

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Report Notification EMail: Jeremy.M.Parrish@dep.state.fl.us

Comments: Group A: (Surf-Fresh)Nutrients
 Group B:(blank) nutrients

Packing Notes:**Bottle Group A (Water) With 1 Samples:**

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices	
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices	
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)	
Color (true)			
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices	
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices	
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L	
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L	
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L	
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices	
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices	
Bottle Type: P-125ML		Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	