

RQ-2020- 12-28-03

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 12/23/2020 11:23

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler <i>IM 12/23/20</i>	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
<i>0.4</i>				<i>7</i>		<i>✓</i>			<i>929380088339</i>

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☒ NA ☐ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IM

Date: 12/23/2020

Event contains NCRs (Y/N)? ☒

Event ID: Pellicer Creek and Pringle makeup
 NE-DIST-2020-12-23-01 (SMP)
 Date Received: 23-DEC-2020 11:23

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Infrared Thermometer ID:	IR TEMP GUN #2 exp:10/28/21
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	231019 exp: 11/1/22
Chlorine Test Strips	0129 exp: 03/2023

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 12/22/2020 **Collected By:** Jeremy Parrish, Brian Davis
Customer: NE-DIST **Sampling Agency:** FDEP
RQ: RQ-2020-12-28-03 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

FIELD ID (Labels) submitted under this RO for this collection date.

Site Location	Field ID/WIN ID
NA	NA
Pringle Br Unnamed Dirt Rd 0.5mi S Dave Br	 27010203
FB	 FB_122220

RELINQUISHED BY(SIGNATURE):

Jeremy Parrish

DATE/TIME: 12/22/2020

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

IM

Rec'd/Inspected Date:

12/23/20

CALIBRATION AND VERIFICATION LOG (FDEP SOP FT 1000-FT 1500, FD 1000-FD 4000)

Boldly "X" this box if there are qualified data on this page.

Meter ID: **5776h**

RQ: **2020-12-28-03**

Project: **Pringle Mokeup**

Notes: (1) Always wait for meter to stabilize before recording any readings.

(2) Report all digits displayed. Do not round before reporting measurements. (See special instructions for depth).

(3) For Calibrations, record calibrated meter reading. Do not record initial meter reading before calibration.

Temperature (Quarterly) FT 1400

Date of Last Temperature Verification

10/14/20

DO DEP SOP FT 1500	Name	Date	Time CT-ET	Temp °C	Baro-meter mmHg	D.O. Chart mg/L	Meter D.O. mg/L	% DO	Probe Charge	Probe Gain	Pass / Fail	Lab / Field
Calibr.	J. Parnell	12/22/20	747	20.0	767.6	9.2	9.2	101	-	1.028	P/F	F
ICV	J. Parnell	12/22/20	748	20.1	767.7	9.2	9.16	100.9	-	1.028	P/F	F
CCV	Brian Davis	↓	1241	19.3	767.3	9.3	9.10	101.0	✓	1.03	P/F	F
CCV											P/F	L/F

DO Acceptance criteria from Table ± 0.3 mg/L

Rapid-Pulse Sensors: DO Gain Range 0.7 to 1.4; DO Charge Range 25-75.

Optical: DO gain range 0.85 to 1.15 (Pro DSS 0.75 to 1.50); DO charge N/A. Steady-state & Galvanic Sensors: DO Gain & Charge N/A.

Spec. Cond. FT 1200	Name	Date	Time CT-ET	Lot #	Expir. Date	Standard µmhos/cm	Meter Reading µmhos/cm	Pass / Fail	Lab / Field
Calibr.	J. Parnell	12/22/20	749	2009020	9/21	1000	1000	P/F	F
ICV	↓	↓	750	2009020	9/21	100	103	P/F	F
CCV	Brian Davis	↓	1243	2009020	9/21	1413	1415	P/F	F
CCV								P/F	L/F

Conductivity Acceptance criteria ± 5%

pH DEP SOP FT 1100	Name	Date	Time CT-ET	Lot #	Expir. Date	pH Buffer SU	Temp °C	Meter reading SU	mV	Pass / Fail	Lab / Field
Calibr.	J. Parnell	12/22/20	754	2001C34	1/22	7.02	21.2	7.02	70.0	P/F	F
Calibr.	↓	↓	755	2006B06	5/22	4.00	21.5	4.00	165.6	P/F	F
Calibr.	↓	↓	756	2006E28	12/21	10.14	21.8	10.14	154.5	P/F	F
ICV	↓	↓	757	2006B06	5/22	4.00	21.4	4.09	161.4	P/F	F
CCV	Brian Davis	↓	1246	2001C31	1/22	7.01	22.4	7.04	-11.0	P/F	F
CCV										P/F	L/F

pH Acceptance criteria ± 0.2 SU; mV pH 7 Range 0 ± 50; mV pH 4 Range +180 ± 50; mV pH 10 Range -180 ± 50; If mV are recorded: slope from 7 to 10 _____, slope from 4 to 7 _____ (both must be between 165 and 180 mV)

Does meter have a depth sensor that will be used to measure total depth & sample depth? YES / NO / NA (not surf. water project)

If YES, complete daily Calibr. & ICV below and list date of last quarterly depth verification:

If NO, what will be used? (circle one) Secchi Disk Line / Sonar Unique ID: _____; Date of last verification: _____

Depth Sensor (Daily Calibration & ICV)	Name	Date	Time CT-ET	Calibrated Value (0.00 or Offset), meters	ICV Value, meters	Pass / Fail	Lab / Field
Pressure mode in air	J. Parnell	12/22/20	804	0.00	0.00	P/F	F

Report two decimal places. Round numbers ≤ 4 down, ≥ 5 up. ICV acceptance criteria ± 5 % or ± 0.05m, whichever is greater.

COMMENTS:



RQ-2020-12-28-03

Customer: WQAP

Project ID: SMP

Collected By: Jeremy Parrish, Brian Davis

Field Report Prepared By: Jeremy Parrish

Sampling Agency: FDEP

Place Label Here

WIN ID/Field ID:



27010203

Location: Pringle Br Unnamed Dirt Rd 0.5mi S Dave Br

Comments: Microbiology sample(s) submitted to contract laboratory

Matrix: Fresh

(Check one)

☒ GRAB☐ COMPOSITE

Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
12/22/2020	1025 EST	7.71	74.7	13.9	6.76	0.3	0.4 ☒ VOB (S)	0.4	180.8	0.09

Central Lab please use top row for login purposes

EST										
-----	--	--	--	--	--	--	--	--	--	--

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # Sa0293040 Exp: 10/19/21	☒ Ice ☒ H2SO4*	☒ <2	1	C
Metals (P-500ML)	☐ W-ICPMS ☐ W-ICP ☐ W-HARD Lot # Exp:	☐ Ice ☐ HNO3* ☐ <2			
Filtered Nutrients (P125ML)	☒ W-PO4-F ☒ Field Filtered 0.45 µm Filter Filter Lot # Rocb48607 Syringe Lot #	☒ Ice		1	C
Chlorophyll (BP-1L)	☒ CHLSUITE-W	☒ Ice		1	C
Physical/Aggregate (Fresh) (P-1L)	☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-SO4-IC / W-TDS	☒ Ice		1	C
Physical/Aggregate (Marine) (P-1L)	☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	☐ Ice			
Macroinvertebrates (PJ-2L)	☐ MI-FW-QLDC	☐ Formalin			
Periphyton (PT-50ML)	☐ ALGAE-ID	☐ Ice			
Microbiology (Contract Lab Bottle)	☒ E Coli ☐ F Coli ☐ Enterococci ☒ Contract Lab	☒ Ice		1	C
Molecular (QPCR-P-500ML)	☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD	☐ Ice			
Tracers (BG-500ML)	☐ W-E8321-DI ☐ W-E8321-MS	☐ Ice			
Pesticides (BG-500ML) (BG-1L)	☐ W-E8321-DI ☐ WE8321-MS ☐ W-PSNP-TQ ☐ W-CT-CL-R ☐ W-PCL-SQ-R ☐ W-CAR8-AA (5 ml of MCAA** Buffer Solution)	☐ Ice			
Name: Jeremy Parrish	Signature: <i>Jeremy Parrish</i>	Date: 12/22/2020			

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION STRATEGIC MONITORING PROGRAM FIELD SHEET

January 2020

Meter Passed End
of Day CCV
Yes / No

WIN Station Name: Pringle Br Unnamed Dirt Rd 0.5mi S Dave Br

Date: 12/22/2020

WIN/Field ID: 27010203

WBID: 2577

ENR:

Latitude: 29.6327

County: FLAGLER

Org ID: 21FLA

Longitude: -81.3114

Receiving Body of Water: Upper East Coast

RQ- 2020-12-28-03

Sampling Team Members		WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check
☒	Jeremy Parrish	☒	☒	☒		
☒	Brian Davis		☒		☒	☒
☐						
☐						

Sampling Equipment	
☒ Sample Container	☐ Carboy
☐ Dipper	☐ Van Dorn
☐ Syringe	☒ Pole
Depth measured with: Meter	
Secchi Equipment ID:	
Collection Method	
☐ Wading	☐ Canoe/Kayak
☒ From Shore	☐ Electric Motor
☐ Other	☐ Gasoline Motor

Water Level: ☒ Normal ☐ Low ☐ High ☐ Dry ☐ Pooled ☐ Flooded		Meter ID# STITCH	
Photos: YES	Flow: FLOW	Tide:	Tide Times: High: Low
Biological Samples Collected: ☒ None ☐ HA ☐ SCI ☐ RPS ☐ Algae ID ☐ LVS ☐ LVI Other:			
SBIO ID Numbers:			
Notes:			

Duplicate Sample

Time Zone: EST Time: N/A Field ID: N/A (WIN ID_DUP)

WIN DMT Activity ID:

Blank

Time Zone: EST	Time: 1608656400000	Field ID: FB 122220 (Blank Type_DDMMYYYY)
DI Source: Neroc		Location: Pringle branch
DI Type: FB		Equipment ID:
DI Container (Name/ID):		DI Container Type:

LIMS EVENT ID: WIN Import ID:

Enter Field Parameters, Verify Station ID In LIMS DMT: (Initials/Date) QC Station ID, Field Parameters In LIMS DMT: (Initials/Date)

Scan/Save Field Sheets (Initials/Date) Migrate Data to WIN: (Initials/Date) Verify Data In WIN: (Initials/Date)



Lab Page _____ of _____

RQ- 2020-12-28-03

Customer: WQAP

Project ID: SMP

Collected By: Jeremy Parrish, Brian Davis

Field Report Prepared By: Jeremy Parrish, Brian Davis

Sampling Agency: FDEP

BLANK



Field ID: FB 122220

Comments:

Matrix: FB

(Check one) ☐ COMPOSITE ☒ GRAB

Date

Time

DI Source: Neroc

12/22/2020

1030

EST

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP	☒ Ice ☒ H2SO4	☐ <2	1	D
	Lot # _____ Exp: 10/19/21				
Metals (P-500ML)	☐ W-ICPMS ☐ W-ICP	☐ Ice ☐ H2SO4	☐ <2		
	Lot # _____ Exp: _____				
Filtered Nutrients (P125ML)	☒ W-PO4-F Filter ☒ Field Filtered 0.45 µm	☒ Ice		1	D
	Filter Lot # Rocb48607				
	Syringe Lot # _____				
Physical/Aggregate (Fresh) (P-1L)	☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-IC / TDS	☒ Ice		1	D
Physical/Aggregate (Marine) (P-1L)	☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	☐ Ice			
Tracers (BG-500ML)	☐ W-E8321-DI ☐ W-E8321-MS	☐ Ice			
Pesticides (BG-500ML) (BG-1L)	☐ W-E8321-DI ☐ WE8321-MS ☐ W-PSNP-TQ ☐ W-CT-CL-R	☐ Ice			
	☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution)				
Name: Jeremy Parrish Brian Davis		Signature: <i>Jeremy Parrish</i>		Date: 12/22/2020	

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution

[illegible]

Date of Request: 02-DEC-2020
 Created By: PARRISH_J On: 02-DEC-2020
 Modified By: WATTS_J On: 23-DEC-2020
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Event Description: Pellicer Creek and Pringle makeup

Send Coolers To:

Phone: 904-256-1693
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Cooler Ship EMail: Jeremy.M.Parrish@dep.state.fl.us

Priority: 3
 Event Status: A
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 23-DEC-2020
 Biology Request Reviewed By: WATTS_J On: 23-DEC-2020
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped: YES On: 15-DEC-2020
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 28-DEC-2020
 Logged In By: .

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Report Notification EMail: Jeremy.M.Parrish@floridadep.gov

Comments: Group A:(Surf.Salt) Nutrients, Metals,Tracer, Bacteria
 Group B:(Surf.Salt) Nutrients,Bacteria

Group C:(Surf.Fresh)Nutrients, Bacteria
 Group D:(blank)Nutrients

NE-ALS-ENQ
 NE-ALS-FC
 NE-ALS-ECQ

Packing Notes:

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-ALS-ENQ	Template: DEFAULT	(ASTM D650399) Enterococci by Enterolert/QT by ALS in Jacksonville
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-ALS-FC	Template: DEFAULT	(SM 9222 D) Fecal coliforms by MF by ALS in Jacksonville
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO ₃

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Iron		
Magnesium		
Manganese		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Beryllium		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-ALS-ENQ	Template: DEFAULT	(ASTM D650399) Enterococci by Enterolert/QT by ALS in Jacksonville
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-ALS-FC	Template: DEFAULT	(SM 9222 D) Fecal coliforms by MF by ALS in Jacksonville
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-ALS-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by ALS in Jacksonville
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.