

Login Checklist

RQ- 2020-08-31-43

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 9/ 3 /20 @ 10:00

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.5				12		✓			9117 6381 7698

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 °C (above 10.0 °C for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included? Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA ☒ Evidence Tape intact? Yes _____ No _____
 If Criminal, photographs taken? Yes _____ No _____ Containers intact? Yes ☒ No _____
 Caps on tight? Yes ☒ No _____
 Sufficient Sample Volume: Yes ☒ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes _____ No ☒ Init: KK

Chlorine detected? (One container checked per Field ID) Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0? Yes ☒ No _____ NA _____ Init: KK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes _____ No _____ NA ☒ Init: KK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: KK Date: 9/ 3 /20 Event contains NCRs (Y/N)? N

Event ID: Puzzle Lake Drain
CEN-DIST-2020-09-03-02 (SMP)
 Date Received: 03-SEP-2020 10:00

Login Checklist

Login Preservation Equipment

Infrared Thermometer ID:	IR TEMP GUN #5
pH Test Strips 0 – 6 Lot #	213316BV EXP:5-15-21
pH Paper 0 – 3 Lot #	
pH Paper 0 – 13 Lot #	231019 EXP:11-1-22
Chlorine Test Strips Lot #	8261 EXP:07-2021

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 9/2/2020 **Collected By:** Terry Riordan, Victoria Schwartz
Customer: CEN-DIST **Sampling Agency:** FDEP
RQ: RQ-2020-08-31-43 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Boggy Creek 1100m S Of Boggy Creek Road	 G4CE0127

RELINQUISHED BY(SIGNATURE): *Victoria Schwartz*

DATE/TIME: 09/02/2020

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *KK*

Rec'd/Inspected Date: *9-3-20/1000*



RQ-2020-08-31-43

Customer: WQAP

Project ID: SMP

Collected By: Terry Riordan, Victoria Schwartz

Field Report Prepared By: Terry Riordan

Sampling Agency: FDEP

Place Label Here						Comments:				
WIN ID/Field ID: 										
G4CE0127										
Location: Boggy Creek 1100m S Of Boggy Creek Road										
Matrix: Fresh						(Check one) ☒ GRAB ☐ COMPOSITE				
Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
9/2/2020	10:40 EST	5.33	66.9	26.9	6.97	0.3	0.9 ☐ VOB (S)	1.3	148.6	0.07
Central Lab please use top row for login purposes										
	EST									
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				☒ Ice ☒ H2SO4*		☒ <2	1	A
		Lot #		SA9354050		Exp:		12/20		
Metals (P-500ML)		☐ W-ICPMS ☐ W-ICP ☐ W-HARD				☐ Ice ☐ HNO3*		☐ <2		
		Lot #				Exp:				
Filtered Nutrients (P125ML)		☒ W-PO4-F ☒ Field Filtered 0.45 µm Filter				☒ Ice			1	A
		Filter Lot #		16930280						
		Syringe Lot #		9149785						
Chlorophyll (BP-1L)		☒ CHLUTE-W				☒ Ice			1	A
Physical/Aggregate (Fresh) (P-1L)		☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-SO4-IC / W-TDS				☒ Ice			1	A
Physical/Aggregate (Marine) (P-1L)		☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				☐ Ice				
Macroinvertebrates (PJ-2L)		☐ MI-FW-QLDC				☐ Formalin				
Periphyton (PT-50ML)		☐ ALGAE-ID				☐ Ice				
Microbiology (Contract Lab Bottle)		☒ E Coli ☐ F Coli ☐ Enterococci				☒ Ice			1	A
		☐ Contract Lab								
Molecular (QPCR-P-500ML)		☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3				☐ Ice				
		☐ PCR-GULL2 ☐ PCR-GFD ☐								
Tracers (BG-500ML)		☐ W-E8321-DI ☐ W-E8321-MS				☐ Ice				
Pesticides (BG-500ML) (BG-1L)		☐ W-E8321-DI ☐ WE8321-MS ☐ W-PSNP-TQ ☐ W-CT-CL-R				☐ Ice				
		☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution)								
						☐ Ice				
Name: Terry Riordan Victoria Schwartz						Signature: <i>Victoria Schwartz</i>			Date: 09/02/2020	

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution

Date of Request: 07-AUG-2020
 Created By: BOMAN_L On: 07-AUG-2020
 Modified By: JASROTIA_P On: 13-AUG-2020
 Customer: CEN-DIST
 Project: SMP
 Division:
 District: Central District
 Event Description: Puzzle Lake Drain

Send Coolers To:

Phone: 407-897-4178
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Natalie Ayala
 Cooler Ship EMail: natalie.ayala@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 12-AUG-2020
 Biology Request Reviewed By: JASROTIA_P On: 13-AUG-2020
 Sampling Kit Required: YES Ship on: 21-AUG-2020
 Sampling Kit Shipped: YES On: 18-AUG-2020
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 31-AUG-2020
 Logged In By: MCCOY_I On: 01-SEP-2020

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Kalina Warren
 Report Notification EMail: natalie.ayala@dep.state.fl.us

Comments:**Bottle Group A (Water) With 3 Samples:**

Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 3	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 3	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: HNO ₃
W-HARD	Template: DEFAULT	(SM 2340B) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO ₃
Hardness		
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium		
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		

Bottle Group A (Water) With 3 Samples:

Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: HNO3
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

*Boron
Aluminum
Antimony
Arsenic
Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 3	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.

Cooler Packing Worksheet for Request: RQ-2020-08-31-43

~~E. Lake Toxopneustes~~ ~~Puzzle Lake Drain~~

Ship Cooler On: 8/21/2020

Customer/Project: CEN-DIST/SMP

Assigned To: REYNOLDS_T

Requester: Leif Boman

Priority: 3

407-897-4178
FL Dept. of Environmental Protection
3319 Maguire Blvd., Suite 232
Orlando, FL 32803-3767

Attn: Natalie Ayala

Comments:

No preservatives needed.

Requested Analyses:

Bottle Group: A

of Sites: 3

Container ID: P-1L

Qty: 3 Preservation: ICE

Lot # 00077275

Description: Plastic Bottle 1L

Analysis

ALKALINITY
TURBIDITY
W-CL-IC
W-COLOR
W-F
W-SO4-IC
W-TDS
W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO3/L
Turbidity in aqueous matrices
Chloride in aqueous matrices
True Color measured at 450 nm (not valid for NPDES monitoring)
Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Sulfate in aqueous matrices
Total Dissolved Solids in aqueous matrices
Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 3 Preservation: ICE

Lot # 1287251

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-250ML-WO-THI

Qty: 3 Preservation: ICE

Lot # 119267

Description: 250 ml Sterilized no tablet

Analysis

Description

Container ID: P-500ML

Qty: 3 Preservation: HNO3

Lot # 00076643

Description: Plastic Bottle 500 mL

Affix RED nitric acid dot to container.

Analysis

W-HARD

W-ICP

W-ICPMS

Description

Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3

Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Container ID: P-500ML

Qty: 3 Preservation: ICE And H2SO4

Lot # 00076643

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3

W-NO2NO3

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 3 Preservation: FILTER-ICE

Lot # 00078144

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Cooler Packed By: TKNumber of Coolers: 1Date: 08/18/2020

Kit must also include:

- ☒ Field Sheets
- ☒ Temperature Control Bottle
- ☒ FedEx Bills, if applicable
- ☒ Plastic Bags/Zip Ties
- ☒ Acid Labels (sets of 24)

If Preservation Included:

ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____

PLEASE RETURN ALL COOLERS FOR RQ-2020-08-31-43