

Login Checklist

RQ-2020-11-30-12

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 12/09/2020 9:35

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.0°C				11		X			9293 8008 4274

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒

Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐

Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No ☐ Init: TJH

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☒ Init: TJH

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes ☒ No ☐ NA ☐ Init: TJH

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes ☐ No ☐ NA ☒ Init: TJH

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: TJH Reynolds

Date: 12/09/2020

Event contains NCRs (Y/N)? none

Event ID: Little Creek SCI
CEN-DIST-2020-12-09-01 (SMP)

Date Received: 09-DEC-2020 09:35

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	#4 Temp Gun EXP:10/28/2021
pH Test Strips 0 – 6	N/A
pH Paper 0 – 3	N/A
pH Paper 0 – 13	231019 EXP:11/01/2022
Chlorine Test Strips	8261 EXP:07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 12/8/2020 **Collected By:** Elizabeth Bates, Katie March
Customer: CEN-DIST **Sampling Agency:** FDEP
RQ: RQ-2020-11-30-12 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Sand Creek @ 100m Us Of Cr 415	 G5CE0094

RELINQUISHED BY(SIGNATURE):

Kathryn March

DATE/TIME: 12/8/20 1600

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

Tyler Reynolds

Rec'd/Inspected Date:

12/09/2020



RQ-2020-11-30-12

Customer: WQAP

Project ID: SMP

Collected By: Elizabeth Bates, Katie March

Field Report Prepared By: Elizabeth Bates

Sampling Agency: FDEP

Place Label Here						Comments:					
WIN ID/Field ID:  G5CE0094											
Location: Sand Creek @ 100m Us Of Cr 415											
Matrix: Marine						(Check one) ☒ GRAB ☐ COMPOSITE					
Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPTH)	
12/8/2020	1316 EST	7.34	69.9	13.2	4.45	0.2	0.4 ☒ VOB (S)	0.4	99.5	0.05	
Central Lab please use top row for login purposes											
EST											
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group	
Preserved Nutrients (P-500ML)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				☒ Ice ☒ H2SO4*		☒ <2	1	A	
		Lot #	Sa0293040		Exp:	10/19/21					
Metals (P-500ML)		☒ W-ICPMS ☒ W-ICP ☒ W-HARD				☒ Ice ☒ HNO3*		☒ <2	1	A	
		Lot #	Na9354060		Exp:	12/20/20					
Filtered Nutrients (P125ML)		☒ W-P04-F ☒ Field Filtered 0.45 µm Filter				☒ Ice			1	A	
		Filter Lot #	16930280								
		Syringe Lot #	9149785								
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	A	
Physical/Aggregate (Fresh) (P-1L)		☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-S04-IC / W-TDS				☒ Ice			1	A	
Physical/Aggregate (Marine) (P-1L)		☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				☐ Ice					
Macroinvertebrates (PJ-2L)		☐ MI-FW-QLDC				☐ Formalin					
Periphyton (PT-50ML)		☐ ALGAE-ID				☐ Ice					
Microbiology (Contract Lab Bottle)		☒ E Coli ☐ F Coli ☐ Enterococci				☒ Ice			1	A	
Molecular (QPCR-P-500ML)		☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD ☐				☐ Ice					
Tracers (BG-500ML)		☒ W-E8321-DI ☒ W-E8321-M5				☒ Ice			1	A	
Pesticides (BG-500ML) (BG-1L)		☐ W-E8321-DI ☐ WE8321-MS ☒ W-PSNP-TQ ☐ W-CT-CL-R ☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution)				☒ Ice			4	A	
						☐ Ice					
Name: Elizabeth Bates Katie March					Signature: <i>Kathryn March</i>					Date: 12/8/20	

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution

Date of Request: 03-NOV-2020
 Created By: BOMAN_L On: 03-NOV-2020
 Modified By: JASROTIA_P On: 24-NOV-2020
 Customer: CEN-DIST
 Project: SMP
 Division:
 District: Central District
 Event Description: Little Creek SCI

Send Coolers To:

Phone: 407-897-4178
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Natalie Ayala
 Cooler Ship EMail: natalie.ayala@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 24-NOV-2020
 Biology Request Reviewed By: JASROTIA_P On: 24-NOV-2020
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped: YES On: 16-NOV-2020
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: NO
 Date to Receive Samples: 07-DEC-2020
 Logged In By: REYNOLDS_T On: 24-NOV-2020

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Kalina Warren
 Report Notification EMail: natalie.ayala@dep.state.fl.us

Comments: Group A: Nutrients, Tracers, Pesticides, E. coli
 Group B: Algal_ID

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
Chloride		
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
Sulfate		
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
TDS		
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
TSS		
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Chlorophyll-a, Corrected		
Chlorophyll-a, Uncorrected		
Phaeophytin-a		
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI Number of Bottles: 1 Preserved With: ICE
 ECOLI-18QT Template: DEFAULT (SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Escherichia Coli-Quanti-Tray

Bottle Type: BG-500ML Number of Bottles: 1 Preserved With: ICE
 W-E8321-DI Template: DEFAULT (EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

*Acesulfame K

*AMPA

*Endothall

*Glufosinate

*Glyphosate

*Sucralose

W-E8321-MS Template: DEFAULT (EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

*Acetaminophen

*Acetamiprid

*Afidopyropen

*Benzovindiflupyr

*Carbamazepine

*Clothianidin

*Dinotefuran

*Fluridone

*Hydrocodone

*Ibuprofen

*Imazapyr

*Mandestrobin

*Naproxen

*Primidone

*Pyraclostrobin

*Thiamethoxam

*Tolfenpyrad

*Triclopyr

2,4-D

Bentazon

Diuron

Fenuron

Imidacloprid

Linuron

MCPP

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: HNO3
 W-HARD Template: DEFAULT (SM 2340B) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3

Hardness

W-ICP Template: S-METALS (EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Iron

Manganese

Zinc

W-ICPMS Template: (EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Aluminum

Antimony

Arsenic

Beryllium

Cadmium

Chromium

Copper

Lead

Nickel

Selenium

Silver

Thallium

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: ICE And H2SO4

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
O-Phosphate-P		
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
*Azoxystrobin		
*Carfentrazone Ethyl		
*Difenoconazole		
*Dimethenamid		
*Dithiopyr		
*Fenbuconazole		
*Fipronil Desulfinyl		
*Fluazifop-P-butyl		
*Fludioxonil		
*Flumioxazin		
*Flutolanil		
*Fluxapyroxad		
*Imazalil		
*Iprodione		
*Myclobutanil		
*Naled		
*Oxyfluorfen		
*Prodiamine		
*Pronamide		
*Propiconazole		
*Pyriproxyfen		
*Sulfentrazone		
*Tebuconazole		
Acetochlor		
Alachlor		
Ametryn		
Atrazine		
Atrazine Desethyl		
Azinphos Methyl		
Bromacil		
Butylate		
Carbophenothion		
Chlorpyrifos Ethyl		
Chlorpyrifos Methyl		
Cyanazine		
Demeton		
Diazinon		
Disulfoton		
EPTC		
Ethion		
Ethoprop		
Fenamiphos		
Fipronil		
Fipronil Sulfide		
Fipronil Sulfone		

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-1L Number of Bottles: 4 Preserved With: ICE
W-PSNP-TQ Template: DEFAULT (EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Fonofos
Hexazinone
Malathion
Metalaxyl
Metolachlor
Metribuzin
Mevinphos
Molinate
Norflurazon
Oxadiazon
Parathion Ethyl
Parathion Methyl
Pendimethalin
Phorate
Prometon
Prometryn
Simazine
Terbufos
Terbuthylazine

Bottle Group B (Biological) With 1 Samples:

Bottle Type: PJ-2L Number of Bottles: 2 Preserved With: Formalin
MI-FW-QLDC Template: DEFAULT (SOP-IZ06) No. Taxa of FW macroinverts, qual samp, 20 dipnets.
*Macroinvert-FW-Qual-DipnetX20-#Taxa-Rep2
*Stream Condition Index (SCI)
Bottle Type: PT-50ML Number of Bottles: 1 Preserved With: ICE
ALGAL_ID Template: DEFAULT (SOP-AB05) Qualitative assessment of algal taxa present without counts
*Dominant sample taxon

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.