

Login Checklist

RQ- 2020 - 04 - 13 - 15

Login Station ID: # 3

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 06-26-2020 / 10:50

*Cooler Temperature	Samples Frozen?	* All Samples In Cooler Preserved with		Number of Sample Containers In Cooler	Evidence Tape				Waybill Tracking #
		YES	HNO ₃		Formalin	Present?		*Intact?	
	Yes					No	Yes	No	
2.9C				8		X			1278 4013 4771

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included? Yes **X** No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes _____ No **X**

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA **X** Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken? Yes _____ No _____ Containers intact? Yes **X** No _____

Caps on tight? Yes **X** No _____

Sufficient Sample Volume: Yes **X** No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes **X** No _____ Init: **ABS**

Chlorine detected? (One container checked per Field ID) Yes _____ No **X** Init: **ABS**

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

Acid Preserved Samples: pH< 2.0? Yes **X No _____ NA _____ Init: **ABS/**

W-1-4-DIOX (Green dot on container) preserved to pH<4.0? Yes _____ No _____ NA **X Init: **ABS**

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: **ABS /** Date: **06-26-2020** Event contains NCRs (Y/N)? **N**

Event ID: **SO-DIST - 2020 - 06-26-04**

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IRTG # 3 EXP:11-05-2020
pH Test Strips 0 – 6	213316 BV EXP: 05/15/2021
pH Paper 0 – 3	XXXXXXXXXXXXXXXXXX
pH Paper 0 – 13	231019 EXP:NOV 01 2022
Chlorine Test Strips	9080 / 2022 / 01

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: ABS

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

2020 SMP : Peace River

Central Laboratory Submittal Form

last revised Jan 25, 2018

Customer: SO-DIST

Requester: Chris Hormuth

Field Report Prepared By:

Project ID: SMP

Collected By:

Sampling Agency:

Location	Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>6/25/20</u> Time <u>1015</u>	Eastern Central	Composite end Date _____ Time _____	Bottle Group(s) (See pg 2)
Field ID	Location	G3SD0085	Matrix (type, e.g., Salt, Fresh, etc) <u>Fresh</u>		Diss. Oxygen <u>3.39</u>	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)
WIN/STORE	BeeBranch@LoblollyBayRd		Temp (C) <u>27.1</u>	pH <u>5.02</u>	Sample Depth <u>0.3</u>	☐ ft ☒ m	Sp. Conductance (umho/cm) <u>96.2</u>
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) <u>0.04</u>	Comments		
Location	Field ID	WIN/STORET #	☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____	Eastern Central	Composite end Date _____ Time _____	Bottle Group(s)
Field ID	Location		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)
WIN/STORET #			Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments		
Location	Field ID	WIN/STORET #	☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____	Eastern Central	Composite end Date _____ Time _____	Bottle Group(s)
Field ID	Location		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)
WIN/STORET #			Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments		
Location	Field ID	WIN/STORET #	☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____	Eastern Central	Composite end Date _____ Time _____	Bottle Group(s)
Field ID	Location		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)
WIN/STORET #			Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments		

Relinquished By: <u>Miranda Carroll</u>	Date/Time <u>6/25/20 1500</u>	Shipping Method <u>FedEx</u>	Number of Coolers Shipped: <u>1</u>	Received By: <u>ASB</u>	Date/Time <u>6-26-20 1050</u>
--	----------------------------------	---------------------------------	--	----------------------------	----------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WI-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	SD-BES-ENQ						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	0
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	0
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0 0 MC
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS						
Group: B	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0 0 MC
	CHLSUITE-W						
Group: B	Bottle Type:	QPCR-P-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0 0 MC
	PCR-BACR PCR-DG3 PCR-HF183						

Group: B	Bottle Type: P-250ML-WI-THI SNP SD-BES-ECQ MC	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	0 = 1 e Sanders
Group: B	Bottle Type: BG-500ML W-E8321-DI W-E8321-MS	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	* 0 mc
Group: B	Bottle Type: P-500ML W-HARD W-ICP W-ICPMS	# of Bottles: 1	Preservative: HNO3 Lot # mc	Enter Number of Bottles Sent to Lab	* 0 mc
Group: B	Bottle Type: P-500ML W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	# of Bottles: 1	Preservative: ICE And H2SO4 Lot # SA9301030 mc	Enter Number of Bottles Sent to Lab	* 0 mc
Group: B	Bottle Type: P-125ML W-PO4-F	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	* 0 mc
Group: C	Bottle Type: P-1L ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	* 1 mc
Group: C	Bottle Type: BP-1L CHLSUITE-W	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	* 1 mc
Group: C	Bottle Type: QPCR-P-500ML PCR-BACR PCR-DG3 PCR-HF183	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	* 1 mc
Group: C	Bottle Type: P-250ML-WI-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	* 1

See next page

Group: C	Bottle Type: P-250ML-WI-THI SD-BES-ECQ	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	0 - 1 C Benchmark Sanders
Group: C	Bottle Type: BG-500ML W-E8321-DI W-E8321-MS	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1 mc
Group: C	Bottle Type: P-500ML W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	0 mc Lot # SA9301030
Group: C	Bottle Type: P-125ML W-PO4-F	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	0 mc
Group: D	Bottle Type: P-1L ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	0
Group: D	Bottle Type: BP-1L CHLSUITE-W	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	0
Group: D	Bottle Type: P-250ML-WI-THI SD-BES-ECQ	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	0
Group: D	Bottle Type: P-500ML W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	0
Group: D	Bottle Type: P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	0

Group: D	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab 0
Group: E	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab 1
Group: E	CHLSUITE-W	BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab 1
Group: E	W-HARD W-ICP W-ICPMS	P-500ML	# of Bottles: 1	Preservative: HNO3	Enter Number of Bottles Sent to Lab 1
Group: E	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab 1
Group: E	W-PO4-F	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab 1

Date of Request: 09-MAR-2020
 Created By: HORMUTH_C On: 09-MAR-2020
 Modified By: AYRES_J On: 26-JUN-2020
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Event Description: 2020 SMP : Peace River

Send Coolers To:

Phone: 239-344-5718
 FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Chris Hormuth
 Cooler Ship EMail: Chris.Hormuth@FloridaDEP.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 26-JUN-2020
 Biology Request Reviewed By: JASROTIA_P On: 26-JUN-2020
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped: YES On: 02-APR-2020
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 13-APR-2020
 Logged In By: SHAIK_A On: 26-JUN-2020

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Chris Hormuth
 Report Notification EMail:
 Nicole.Reistad@FloridaDEP.gov; Kirby.Wolfe@dep.state.fl.us; Gary.Snorek@dep.state.fl.us; Miranda.Carroll@FloridaDEP.gov; Chris.Hormuth@FloridaDEP.gov

Comments: Group A: (P Riv Estuary) Marine Nutrients, Entero
 Group B: (Bobcat) Freshwater Metals, E.coli, Markers, Tracers
 Group C: (Runoff to P Riv) Freshwater Nutrients, E. coli, Markers, Tracers
 Group D: (P Riv above Horse Creek) Freshwater Nutrients, E. coli
 Group E: Freshwater Metals BLANK

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-SND-ECQ	Template: DEFAULT	(Colilert-18) E. coli by Colilert-18/QT by Sanders in Fort Myers
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-HARD	Template: DEFAULT	(SM 2340B) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3
Hardness		
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium		
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
*Boron		
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-SND-ECQ	Template: DEFAULT	(Colilert-18) E. coli by Colilert-18/QT by Sanders in Fort Myers

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-SND-ECQ	Template: DEFAULT	(Colilert-18) E. coli by Colilert-18/QT by Sanders in Fort Myers
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-SND-ECQ	Template: DEFAULT	(Colilert-18) E. coli by Colilert-18/QT by Sanders in Fort Myers
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group E (Water) With 1 Samples:

Bottle Group E (Water) With 1 Samples:

Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L	
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices	
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices	
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)	
Color (true)			
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices	
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices	
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	
Bottle Type: BP-1L		Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry	
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: HNO ₃
W-HARD	Template: DEFAULT	(SM 2340B) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO ₃	
Hardness			
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	
Barium			
Calcium			
Iron			
Magnesium			
Potassium			
Sodium			
Zinc			
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects	
*Boron			
Aluminum			
Antimony			
Arsenic			
Cadmium			
Chromium			
Copper			
Lead			
Nickel			
Selenium			
Silver			
Thallium			
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L	
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L	
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L	
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices	
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices	
Bottle Type: P-125ML		Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.