

Login Checklist

RQ- 2020-06-29-48

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 7/ 1 /20 @ 10:50

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
-0.5				4		✓			1278 4013 0592

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 °C (above 10.0 °C for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included? Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes _____ No ✓

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA ✓ Evidence Tape intact? Yes _____ No _____
 If Criminal, photographs taken? Yes _____ No _____ Containers intact? Yes ✓ No _____
 Caps on tight? Yes ✓ No _____
 Sufficient Sample Volume: Yes ✓ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes _____ No ✓ Init: HK

Chlorine detected? (One container checked per Field ID) Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0? Yes ✓ No _____ NA _____ Init: HK

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0? Yes _____ No _____ NA ✓ Init: HK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: HK Date: 7/ 1 /20 Event contains NCRs (Y/N)? N

Event ID: 2020 SMP : Canals
SO-DIST-2020-07-01-01 (SMP)
Date Received: 01-JUL-2020 10:50

Login Checklist

Login Preservation Equipment

Infrared Thermometer ID:	IR TEMP GUN #5
pH Test Strips 0 – 6 Lot #	213316BV EXP:5-15-21
pH Paper 0 – 3 Lot #	
pH Paper 0 – 13 Lot #	231019 EXP:11-1-22
Chlorine Test Strips Lot #	8261 EXP:07-2021

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: SO-DIST

Project ID: SMP

Requester: Miranda Carroll

Field Report Prepared By:

Miranda Carroll

Collected By:

John Barrington

Sampling Agency:

FDEP SROC

Field ID/WIN ID				☐ Comp ☒ Grab	Collection (comp begin or grab) Date <i>6/30/20</i> Time <i>1045</i>		☒ Eastern ☐ Central	Composite end Date _____ Time _____		Bottle Group(s) (See pg 2) <i>A</i>
Location		<i>G4SD0170</i>		Matrix (type, e.g., Salt, Fresh, etc) <i>Fresh</i>		Diss. Oxygen <i>10.33</i>		☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
		<i>Bonnet Lake @ Middle</i>		Temp (C) <i>31.9</i>	pH <i>9.01</i>	Sample Depth <i>0.3</i>	☐ ft ☒ m	Sp. Conductance (umho/cm) <i>248.5</i>		
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt) <i>0.12</i>		Comments				

Location				☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____		☐ Eastern ☐ Central	Composite end Date _____ Time _____		Bottle Group(s)
Field ID				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen ☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		
WIN/STORET #				Temp (C)	pH	Sample Depth ☐ ft ☐ m	Sp. Conductance (umho/cm)			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments				

Location				☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____		☐ Eastern ☐ Central	Composite end Date _____ Time _____		Bottle Group(s)
Field ID				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen ☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		
WIN/STORET #				Temp (C)	pH	Sample Depth ☐ ft ☐ m	Sp. Conductance (umho/cm)			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments				

Location				☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____		☐ Eastern ☐ Central	Composite end Date _____ Time _____		Bottle Group(s)
Field ID				Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen ☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		
WIN/STORET #				Temp (C)	pH	Sample Depth ☐ ft ☐ m	Sp. Conductance (umho/cm)			
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments				

Relinquished By: <i>Miranda Carroll</i>	Date/Time <i>6/30/20 1430</i>	Shipping Method <i>FedEx</i>	Number of Coolers Shipped: <i>1</i>	Received By: <i>HK</i>	Date/Time <i>7.1.20 / 1050</i>
--	----------------------------------	---------------------------------	--	---------------------------	-----------------------------------

Group: A Bottle Type: # of Bottles: 0 Preservative: Enter Number of Bottles Sent to Lab _____

- ALKALINITY
- CHLSUITE-W
- TURBIDITY
- W-CL-IC
- W-COLOR
- W-F
- W-NH3
- W-NO2NO3
- W-PO4-F
- W-S-A-TP
- W-SO4-IC
- W-TDS
- W-TKN
- W-TOC
- W-TSS

MC

Group: A	Bottle Type:	P-1L	# of Bottles: 1 MC	Preservative:	ICE	Enter Number of Bottles Sent to Lab	
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 1 MC	Preservative:	ICE	Enter Number of Bottles Sent to Lab	
	CHLSUITE-W						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1 MC	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						Lot #5A9301030
Group: A	Bottle Type:	P-125ML	# of Bottles: 1 MC	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS						MC
Group: B	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	CHLSUITE-W						
Group: B	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	W-E8321-DI W-E8321-MS						

Date of Request: 30-JUN-2020
 Created By: CARROLL_M On: 30-JUN-2020
 Modified By: JASROTIA_P On: 30-JUN-2020
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Event Description: 2020 SMP : Canals

Send Coolers To:

Phone: 239-344-5718
 FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad
 Cooler Ship EMail: Nicole.Reistad@FloridaDEP.gov

Priority: 3
 Event Status: A
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 30-JUN-2020
 Biology Request Reviewed By: JASROTIA_P On: 30-JUN-2020
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 30-JUN-2020
 Logged In By:

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad
 Report Notification EMail:
 Nicole.Reistad@FloridaDEP.gov; Kirby.Wolfe@dep.state.fl.us; Gary.Snorek@dep.state.fl.us; Miranda.Carroll@FloridaDEP.gov; Chris.Hormuth@FloridaDEP.gov

Comments: Group A: Bonnet Lake

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L