

Login Checklist

RQ- 2020-09-21-43

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 9/ 23 /20 @ 9:30

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.3				8		✓			4385 5032 2201

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ☒ Init: KK

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes ☒ No _____ NA _____ Init: KK

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA ☒ Init: KK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: KK

Date: 9/ 23 /20

Event contains NCRs (Y/N)? N

Event ID: pearl lake
SO-DIST-2020-09-23-01 (SMP)

— Date Received: 23-SEP-2020 09:30

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	Temp Gun #5 EXP:11/05/2020
pH Test Strips 0 – 6	5/15/21 LOT#213316BV
pH Paper 0 – 3	
pH Paper 0 – 13	231019 EXP:11/01/2022
Chlorine Test Strips	8261 EXP:07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date:	9/22/2020	Collected By:	John Barrington, Miranda Carroll
Customer:	SO-DIST	Sampling Agency:	FDEP
RQ:	RQ-2020-09-21-43	Project ID:	SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Pearl Lake @ Center	 G4SD0137

RELINQUISHED BY(SIGNATURE):

DATE/TIME:

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

John Barrington
KK

Rec'd/Inspected Date:

09/22/2020

9-23-20/0930



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION STRATEGIC MONITORING PROGRAM FIELD SHEET

January 2020

Meter Passed End
of Day CCV
Yes / No

WIN Station Name: Pearl Lake @ Center

Date: 9/22/2020

WIN/Field ID: G4SD0137

WBID: 1932D

ENR:

Latitude: 27.28361

County: HIGHLANDS

Org ID: 21FLFTM

Longitude: -81.361223

Receiving Body of Water: Kissimmee River

RQ- 2020-09-21-43

Sampling Team Members		WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check
☒	John Barrington		☒		☒	☒
☒	Miranda Carroll		☒	☒		
☐						
☐						

Sampling Equipment	
☒ Sample Container	☐ Carboy
☐ Dipper	☐ Van Dorn
☒ Syringe	☐ Pole
Depth measured with: Secchi	
Secchi Equipment ID: DEEP BLUE	
Collection Method	
☐ Wading	☒ Canoe/Kayak
☐ From Shore	☐ Electric Motor
☐ Other	☐ Gasoline Motor

Water Level: ☒ Normal ☐ Low ☐ High ☐ Dry ☐ Pooled ☐ Flooded		Meter ID# PRO MOVE	
Photos: NO	Flow: NA	Tide:	Tide Times: High: Low:
Biological Samples Collected: ☒ None ☐ HA ☐ SCI ☐ RPS ☐ Algae ID ☐ LVS ☐ LVI Other:			
SBIO ID Numbers:			
Notes:			

Duplicate Sample

Time Zone: EST	Time: N/A	Field ID: N/A	(WIN ID_DUP)
WIN DMT Activity ID:			

Blank

Time Zone:	Time: N/A	Field ID: N/A	(Blank Type_DDMMYYYY)
DI Source: N/A	Location: N/A		
DI Type: N/A	Equipment ID: N/A		

LIMS EVENT ID: WIN Import ID:

Enter Field Parameters, Verify Station ID In LIMS DMT: QC Station ID, Field Parameters In LIMS DMT:

Scan/Save Field Sheets Migrate Data to WIN: Verify Data In WIN:



RQ-2020-09-21-43

Customer: WQAP

Project ID: SMP

Collected By: John Barrington, Miranda Carroll

Field Report Prepared By: John Barrington

Sampling Agency: FDEP

Place Label Here

WIN ID/Field ID:



G4SD0137

Location: Pearl Lake @ Center

Comments: Lake deeper than secchi line, bottom read is as deep as sonde cable

Matrix: Fresh

(Check one)

☒ GRAB☐ COMPOSITE

Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
9/22/2020	12:50 EST	7.27	94.1	28.7	6.62	0.3	4.5 ☐ VOB (S)	15	101.7	0.05

Central Lab please use top row for login purposes

	12:55 EST	7.2	93	28.6	6.49	8.5			101.7	0.05
--	--------------	-----	----	------	------	-----	--	--	-------	------

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # SA9354050 Exp: 12/20/20	☒ Ice ☐ H2SO4*	☒ <2	1	A
Metals (P-500ML)	☐ W-ICPMS ☐ W-ICP ☐ W-HARD Lot # Exp:	☐ Ice ☐ HNO3*	☐ <2		
Filtered Nutrients (P125ML)	☒ W-PO4-F ☒ Field Filtered 0.45 µm Filter Filter Lot # 17024971 Syringe Lot # 0007557	☒ Ice		1	A
Chlorophyll (BP-1L)	☒ CHLSUITE-W	☒ Ice		1	A
Physical/Aggregate (Fresh) (P-1L)	☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-SO4-IC / W-TDS	☒ Ice		1	A
Physical/Aggregate (Marine) (P-1L)	☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	☐ Ice			
Macroinvertebrates (PJ-2L)	☐ MI-FW-QLDC	☐ Formalin			
Periphyton (PT-50ML)	☐ ALGAE-ID	☐ Ice			
Microbiology (Contract Lab Bottle)	☐ E Coli ☐ F Coli ☐ Enterococci ☐ Contract Lab	☐ Ice			
Molecular (QPCR-P-500ML)	☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD	☐ Ice			
Tracers (BG-500ML)	☐ W-E8321-DI ☐ W-E8321-MS	☐ Ice			
Pesticides (BG-500ML) (BG-1L)	☐ W-E8321-DI ☐ WE8321-MS ☐ W-PSNP-TQ ☐ W-CT-CL-R ☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution)	☐ Ice			
		☐ Ice			

Name:
John Barrington
Miranda Carroll

Signature:

John Barrington

Date:

09/22/2020

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution

Date of Request: 08-SEP-2020
 Created By: SNOREK_G On: 08-SEP-2020
 Modified By: JASROTIA_P On: 08-SEP-2020
 Customer: SO-DIST
 Project: SMP
 Division:
 District: South District
 Event Description: pearl lake

Send Coolers To:

Phone: 239-344-5718
 FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Gary Snorek
 Cooler Ship EMail: Gary.Snorek@dep.state.fl.us

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 08-SEP-2020
 Biology Request Reviewed By: JASROTIA_P On: 08-SEP-2020
 Sampling Kit Required: YES Ship on: 11-SEP-2020
 Sampling Kit Shipped: YES On: 10-SEP-2020
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 21-SEP-2020
 Logged In By:

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad
 Report Notification EMail:
 Nicole.Reistad@dep.state.fl.us; Kirby.Wolfe@dep.state.fl.us; Gary
 .Snorek@dep.state.fl.us; Miranda.carroll@floridadep.gov; Chris.Ho
 rmth@floridadep.gov

Comments:

Group A: (LVI) Nutrients

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L