

Log-in Checklist

RQ- 2020-03-09-20

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 3/ 12 /20 @ 10:25

Cooler Temperature*	Samples Frozen YES	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
		HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
<u>0.7</u>				<u>9</u>		☒			<u>1278 4011 6116</u>

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes ☐ No ☒ If yes, is it intact? Yes ☐ No ☐
 **Caps on tight? Yes ☒ No ☐ **Containers intact? Yes ☒ No ☐
 **Sufficient Sample Volume: Yes ☒ No ☐

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No ☐ Init: kh

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☒ Init: kh

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ☒ No ☐ NA ☐ Init: kh

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☐ NA ☒ Init: kh

Coolers Unpacked/Checked by: kh Date: 3/ 12 /20

NCRs (Y/N)? N

Event ID: Eglin Run East
NW-DIST-2020-03-12-01 (SMP)
 Date Received: 12-MAR-2020 10:25

NCR #

Log-in Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle Test ID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #5 EXP:11-5-20
pH Test Strips 0 – 6 Lot #	
pH Paper 0 – 3 Lot #	
pH Paper 0 – 13 Lot #	208717 EXP:3/31/20
Chlorine Test Strips Lot #	8261 EXP:7/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Customer: NW-DIST

Requester: Christopher Slade

Field Report Prepared By: M. Clark

Project ID: SMP

Collected By: N. Mulkey

Sampling Agency: FLPNS

Location		☐ Comp ☒ Grab		Collection (comp begin or grab)		Eastern ☒ Central ☒		Composite end		Bottle Group(s)		
Field	Field/WIN ID			Date	3/11/20	Time	9:00	Date		Time	(See pg 2)	
WIN	Location:		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		C	
Latitud	Titi Creek above SR 285		Temp (C)	17.2	pH	4.37	Sample Depth	0.2	ft ☐ m ☒	Sp. Conductance (umho/cm)		16.1
☐ dms		☐ dd ☐ dms		Salinity (ppt)		0.01		Comments				
Location		☐ Comp ☒ Grab		Collection (comp begin or grab)		Eastern ☒ Central ☒		Composite end		Bottle Group(s)		
Field	Field/WIN ID			Date	3/11/20	Time	9:30	Date		Time	(See pg 2)	
WIN	Location:		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		O	
Latitud	Little Rocky Creek abv Eglin Rd 515		Temp (C)	17.9	pH	4.70	Sample Depth	0.1	ft ☐ m ☒	Sp. Conductance (umho/cm)		14.0
☐ dms		☐ dd ☐ dms		Salinity (ppt)		0.01		Comments				
Location		☐ Comp ☒ Grab		Collection (comp begin or grab)		Eastern ☒ Central ☒		Composite end		Bottle Group(s)		
Field	Field/WIN ID			Date	3/11/20	Time	9:50	Date		Time	(See pg 2)	
WIN	Location:		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		A	
Latitud	Shaw Still Branch upstream E College Blvd		Temp (C)	19.9	pH	6.71	Sample Depth	0.1	ft ☐ m ☒	Sp. Conductance (umho/cm)		209.7
☐ dms		☐ dd ☐ dms		Salinity (ppt)		0.10		Comments				
Location		☐ Comp ☒ Grab		Collection (comp begin or grab)		Eastern ☒ Central ☒		Composite end		Bottle Group(s)		
Field	Field/WIN ID			Date	3/11/20	Time	10:30	Date		Time	(See pg 2)	
WIN	Location:		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		B	
Latitud	Eagle Creek upstream of Hwy 20		Temp (C)	18.9	pH	4.95	Sample Depth	0.2	ft ☐ m ☒	Sp. Conductance (umho/cm)		31.8
☐ dms		☐ dd ☐ dms		Salinity (ppt)		0.01		Comments				

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
M. Clark	3/11/20 16:00	FedEx	1	KK	3-11-20 1025

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: A	Bottle Type:	TEST HAS NO BOTTLE	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	NW-UWF-ECQ <i>Sent to Contract Lab</i>						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	W-E8321-DI W-E8321-MS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	1
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS						
Group: B	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: B	Bottle Type:	P-250ML-WI-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	

Group: B	Bottle Type: P-250ML-WI-THI NW-TA-FC	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>0</u> <i>Sent to contract lab</i>
Group: B	Bottle Type: TEST HAS NO BOTTLE NW-UWF-ENQ	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>0</u> <i>Sent to contract lab</i>
Group: B	Bottle Type: P-500ML W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>1</u>
Group: B	Bottle Type: P-125ML W-PO4-F	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: C	Bottle Type: TEST HAS NO BOTTLE NW-UWF-ECQ	# of Bottles: 3	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>0</u> <i>Sent to Contract Lab</i>
Group: D	Bottle Type: P-1L ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>0</u>
Group: D	Bottle Type: BP-1L CHLSUITE-W	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>0</u>
Group: D	Bottle Type: TEST HAS NO BOTTLE NW-UWF-ECQ	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>0</u>
Group: D	Bottle Type: P-500ML W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>0</u>

Group: D

Bottle Type:

P-125ML

of Bottles: 1

Preservative:

FILTER-ICE

Enter Number of Bottles Sent to Lab

0

W-PO4-F

Chain of Custody Record



Environment Testing
TestAmerica

TestAmerica Laboratories, Inc. d/b/a Eurofins TestAmerica

Regulatory Program: ☐ DW ☐ NPDES ☐ RCRA ☒ Other: TMDL[illegible]

Document Reference # 05.1.0

Sampler's initials : *MC & NV*

Page 1 of 1

Date/Time: 3/11/20 1251

Date/Time: 3/11/20 11251

If a field log or other chain of custody is attached, that information may be referenced on this form and the log or COC attached.

[illegible]

Comments sample container lot# L19229

RQ-2020-03-09-20

Phone: (850) 595-8300

Sampler's name: N. Mulken

M. Clark

³ Recorded using IRT-2

Date of Request: 10-FEB-2020
 Created By: SLADE_C On: 10-FEB-2020
 Modified By: JASROTIA_P On: 11-FEB-2020
 Customer: NW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northwest District
 Sampling Event: Eglin Run East

Send Coolers To:

Phone: 850-595-0567
 160 Government Center
 Suite 208
 Pensacola, FL 32502-5794
 Attn: Christopher Slade

Program Module Number:

Priority: 3
 Event Status: A
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 11-FEB-2020
 Biology Request Reviewed By: JASROTIA_P On: 11-FEB-2020
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 09-MAR-2020
 Received By:

Send Final Report To:

160 Government Center
 Suite 208
 Pensacola, FL 32502-5794
 Attn: Cheryl Bunch

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: Freshwater
 (WBID 658) Nutrients, Tracers, Contract Lab Bacteria

Group B: Marine
 (WBID 751) Nutrients, Contract Lab Bacteria

Group C: Freshwater
 (WBID 476, 445, 321) Contract Lab Bacteria

Group D: Freshwater
 (WBID 361) Nutrients, Contract Lab Bacteria

** Labels only **

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: TEST HAS NO	Number of Bottles: 1	Preserved With: ICE
NW-UWF-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert-18/QT by UWF in Pensacola
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: TEST HAS NO	Number of Bottles: 1	Preserved With: ICE
NW-UWF-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert/QT by UWF in Pensacola
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NW-TA-FC	Template: DEFAULT	(SM 9222 D) Fecal coliforms by MF by Test America in Pensacola

Bottle Group C (Water) With 3 Samples:

Bottle Type: TEST HAS NO	Number of Bottles: 3	Preserved With: ICE
NW-UWF-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert-18/QT by UWF in Pensacola

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: TEST HAS NO	Number of Bottles: 1	Preserved With: ICE
NW-UWF-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert-18/QT by UWF in Pensacola
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.