

RQ- 2020-07-20-54

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 7/21/2020 10:40

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.3 3.3				10 ⁹		☒			1190 3161 7105 1190 3161 7090

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No _____ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes _____ No ☒ Init: IM

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes ☒ No _____ NA _____ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IM

Date: 7/21/2020 Event contains NCRs (Y/N)? N

Event ID: Eglin Run West
NW-DIST-2020-07-21-01 (SMP)

Date Received: 21-JUL-2020 10:40

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:11/5/20
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	231019 exp: 11/1/22
Chlorine Test Strips	8261 exp: 07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: NW-DIST

Project ID: SMP

Requester: Michael King

Field Report Prepared By: H Schimdo

Collected By: M Clark

Sampling Agency: NW ROC

Location		☐ Comp	Collection (comp begin or grab)		Eastern	Composite end		Bottle Group(s) (See pg 2)
Field/WIN ID →  G3NW0170		☒ Grab	Date 7/20/2020	Time 1043	Central	Date	Time	
Location: Juniper Creek upstream of Eglin Rd 221		Matrix (type, e.g., Salt, Fresh, etc) Fresh		Diss. Oxygen 8.47	☒ mg/L	Total Res. Chlorine (mg/L)		C
		Temp (C) 22.9	pH 6.22	Sample Depth 0.1	☐ ft	Sp. Conductance (umho/cm) 1410		
☐ dms		☐ dd	Salinity (ppt) 0.01	Comments				
Location		☐ Comp	Collection (comp begin or grab)		Eastern	Composite end		Bottle Group(s)
Field/WIN ID →  G3NW0093		☒ Grab	Date 7/20/2020	Time 1105	Central	Date	Time	
Location: Turkey Creek upstream of Eglin Road 232		Matrix (type, e.g., Salt, Fresh, etc) Fresh		Diss. Oxygen 8.46	☒ mg/L	Total Res. Chlorine (mg/L)		D
		Temp (C) 22.3	pH 6.57	Sample Depth 0.15	☐ ft	Sp. Conductance (umho/cm) 15.0		
☐ dms		☐ dd	Salinity (ppt) 0.01	Comments				
Location		☐ Comp	Collection (comp begin or grab)		Eastern	Composite end		Bottle Group(s)
Field/WIN ID  G3NW0095		☒ Grab	Date 7/20/2020	Time 1125	Central	Date	Time	
Location: Juniper Creek above Hwy 85		Matrix (type, e.g., Salt, Fresh, etc) Fresh		Diss. Oxygen 8.22	☒ mg/L	Total Res. Chlorine (mg/L)		B
		Temp (C) 23.5	pH 6.04	Sample Depth 0.3	☐ ft	Sp. Conductance (umho/cm) 14.3		
☐ dms		☐ dd	Salinity (ppt) 0.01	Comments				
Location		☐ Comp	Collection (comp begin or grab)		Eastern	Composite end		Bottle Group(s)
Field/WIN ID  G3NW0162		☒ Grab	Date 7/20/2020	Time 1150	Central	Date	Time	
Location: Shaw Still Branch upstream E College Blvd		Matrix (type, e.g., Salt, Fresh, etc) Fresh		Diss. Oxygen 7.78	☒ mg/L	Total Res. Chlorine (mg/L)		A
		Temp (C) 23.3	pH 6.92	Sample Depth 0.1	☐ ft	Sp. Conductance (umho/cm) 2235		
☐ dms		☐ dd	Salinity (ppt) 0.10	Comments				

Relinquished By: M. Clark	Date/Time 7/20/20 16:00	Shipping Method FedEx	Number of Coolers Shipped: 2	Received By: IM	Date/Time 7/21/20 10:40
------------------------------	----------------------------	--------------------------	---------------------------------	--------------------	----------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>1</u>
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>1</u>
	CHLSUITE-W					
Group: A	Bottle Type:	TEST HAS NO BOTTLE	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>0</u>
	NW-UWF-ECQ					
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>1</u>
	W-E8321-DI W-E8321-MS					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>1</u>
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab <u>1</u>
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>1</u>
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS					

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: NW-DIST

Requester: Michael King

Field Report Prepared By:

H Schenck

Project ID: SMP

Collected By:

M Clark

Sampling Agency:

NWRAC

Field/WIN ID  G3NW0151		☐ Comp ☒ Grab		Collection (comp begin or grab) Date <i>7/20/2020</i> Time <i>1220</i>		Eastern ☒ Central		Composite end Date _____ Time _____		Bottle Group(s) (See pg 2)	
Location: Eagle Creek upstream of Hwy 20		Matrix (type, e.g., Salt, Fresh, etc) <i>Fresh</i>		Diss. Oxygen <i>4.48</i>		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
Temp (C) <i>30.5</i> pH <i>5.71</i>		Sample Depth <i>0.3</i>		☐ ft ☒ m		Sp. Conductance (umho/cm) <i>44.1</i>					
Latitude ☐ dd ☐ dms Longitude ☐ dd ☐ dms		Salinity (ppt) <i>0.02</i>		Comments							

Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date _____ Time _____		Eastern ☐ Central		Composite end Date _____ Time _____		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		☐ ft ☐ m			
Latitude ☐ dd ☐ dms Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments							

Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date _____ Time _____		Eastern ☐ Central		Composite end Date _____ Time _____		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		☐ ft ☐ m			
Latitude ☐ dd ☐ dms Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments							

Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date _____ Time _____		Eastern ☐ Central		Composite end Date _____ Time _____		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		☐ ft ☐ m			
Latitude ☐ dd ☐ dms Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments							

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
				<i>IM</i>	<i>7/21/20 10:40</i>

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY					
	TURBIDITY					
	W-CL-IC					
	W-COLOR					
	W-F					
	W-SO4-IC					
	W-TDS					
	W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: A	Bottle Type:	TEST HAS NO BOTTLE	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	NW-UWF-ECQ					
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	W-E8321-DI					
	W-E8321-MS					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab _____
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY					
	TURBIDITY					
	W-CL-IC					
	W-COLOR					
	W-F					
	W-SO4-IC					
	W-TDS					
	W-TSS					

Group: B	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
Group: B	Bottle Type: NW-UWF-ECQ	TEST HAS NO BOTTLE	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	<u>0</u>
Group: B	Bottle Type: W-ICP W-ICPMS	P-500ML	# of Bottles: 1	Preservative: HNO3	Enter Number of Bottles Sent to Lab	<u>1</u>
Group: B	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>1</u>
Group: B	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
Group: C	Bottle Type: ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
Group: C	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
Group: C	Bottle Type: NW-UWF-ECQ	TEST HAS NO BOTTLE	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	<u>0</u>
Group: C	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>1</u>

Group: C	Bottle Type: W-TOC	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>1</u>
Group: C	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: D	Bottle Type: NW-UWF-ECQ	TEST HAS NO BOTTLE	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>0</u>
Group: E	Bottle Type: ALKALINITY TURBIDITY W-BR-IC W-F W-SO4-IC W-TSS	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: E	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: E	Bottle Type: NW-TA-FC	P-250ML-WI-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: E	Bottle Type: NW-UWF-ENQ	TEST HAS NO BOTTLE	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>0</u>
Group: E	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>1</u>
Group: E	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab <u>1</u>

Document Reference # 05.1.0

Project: FDEP

Method of transport: Drop off on ice by automobile

Samples delivered by: M. C. 12-11 of FDEP

Sample received by: John Doe of WRL

Laboratory: Wetlands Research Laboratory

Sampler's initials: ML

Page 1 of 1

Date/Time: 7/20/20 11617

Date/Time: 07/20/2020 11:017

Instructions: Fill in all fields except "Lab ID" on sample transport form completely. Each sample container must use a separate line. Place this form in a waterproof bag and place it with the samples for transport. If a field log or other chain of custody is attached, that information may be referenced on this form and the log or COC attached.

[illegible]

Comments sample container lot# 220020

RQ-2020- 07-20-59

Contact organization FDEP

Address 160 W Governmental Street, suite 208, Pensacola, FL 32502

¹Matrix: SW = surface water, PW = pore water, GW = ground water, S = soil/sediment, X =

²Type codes: G = grab, C = composite, X =

Contact name Michael King

Phone: (850) 595-8300

Sampler's name: M Cwe

³ Recorded using IRT-2

Date of Request: 05-JUL-2020
 Created By: KING_M On: 05-JUL-2020
 Modified By: JASROTIA_P On: 20-JUL-2020
 Customer: NW-DIST
 Project: SMP
 Division:
 District: Northwest District
 Event Description: Eglin Run West

Send Coolers To:

Phone: 850-595-0506
 160 Government Center
 Suite 208
 Pensacola, FL 32502-5794
 Attn: Michael King
 Cooler Ship EMail: Michael.King@dep.state.fl.us

Priority: 3
 Event Status: A
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 20-JUL-2020
 Biology Request Reviewed By: JASROTIA_P On: 20-JUL-2020
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped: YES On: 13-JUL-2020
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 20-JUL-2020
 Logged In By:

Send Final Report To:

160 Government Center
 Suite 208
 Pensacola, FL 32502-5794
 Attn: Cheryl Bunch
 Report Notification EMail:
 Michael.King@dep.state.fl.us;Cheryl.Bunch@dep.state.fl.us

Comments: Group A: (WBID 658) Nutrients, Tracers Contract Lab Bacteria
 Group B: (WBID 468A) Nutrients, Metals, Contract Lab Bacteria
 Group C: (WBID 468) Nutrients, Contract Lab Bacteria
 Group D: (WBID 495) Contract Lab Bacteria
 Group E: (WBID 751) Marine Nutrients, Contract Lab Bacteria
 Packing Notes:
 4 - cases of Sulfuric acid/4 sets of labels
 1 - case of Nitric acid/1 set of labels

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: TEST HAS NO	Number of Bottles: 1	Preserved With: ICE
NW-UWF-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert-18/QT by UWF in Pensacola
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium		
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
*Boron		
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: TEST HAS NO	Number of Bottles: 1	Preserved With: ICE
NW-UWF-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert-18/QT by UWF in Pensacola

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: TEST HAS NO	Number of Bottles: 1	Preserved With: ICE
NW-UWF-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert-18/QT by UWF in Pensacola

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group D (Water) With 1 Samples:

Bottle Type: TEST HAS NO	Number of Bottles: 1	Preserved With: ICE
NW-UWF-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert-18/QT by UWF in Pensacola

Bottle Group E (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
FCOLI-MF	Template: DEFAULT	(SM 9222 D) Fecal coliforms by membrane filter method - non-chlorinated water systems
Bottle Type: TEST HAS NO	Number of Bottles: 1	Preserved With: ICE
NW-UWF-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert/QT by UWF in Pensacola
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.