

RQ-2020-10-12-54

Login Checklist

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 10/16/2020 @ 10:40

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.6°C				8		x			12 NR 217849727

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 °C (above 10.0 °C for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No ☐ Init: Tyler

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☒ Init: Tyler

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: Tyler

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☐ NA ☒ Init: Tyler

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: Tyler ReynoldsDate: 10/16/2020Event contains NCRs (Y/N)? None

Event ID: SMP Bioassessment

NW-DIST-2020-10-16-01 (SMP)

Date Received: 16-OCT-2020 10:40

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	#4 Temp Gun EXP:11/05/2020
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	231019 EXP:11/01/2022
Chlorine Test Strips	8261 EXP:07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 10/15/2020
Customer: NW-DIST
RQ: RQ-2020-10-12-54
Collected By: Heather Schmuki, Nathan Mulkey
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
RELINQUISHED BY(SIGNATURE): <i>Heather Schmuki</i>	DATE/TIME: 10/15/2020; 13:00

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *TX*

Rec'd/Inspected Date: *10/16/2020*

CALIBRATION AND VERIFICATION LOG (1000-1000 FT 1000-1000 FT 1000-1000)

Meter ID: 55077

NO: 2020-10-1254

Project: 5442

Expiry: 1 year
Note: If this log
is not filled out
the meter is
out of service

Notes: (1) Always wait for meter to stabilize before recording any readings.

(2) Report all digits displayed. Do not round before reporting measurements. (See special instructions for depth).

(3) For Calibrations, record calibrated meter reading. Do not record initial meter reading before calibration.

Temperature (Quarterly) FT 1000

Date of Last Temperature Verification: 10/13/20

DO	Name	Date	Time CT-ET	Temp °C	Baro- meter mmHg	D.O. Chart mg/L	Meter D.O. mg/L	% DO	Probe Charge	Probe Gain	Pass /	Lab /
DEP SOP FT 1000												
Calibr.	M. Clark	10/15/20	7:47	24.1	740	8.4	9.10	100.0			Pass	Field
ICV	↓	↓	7:59	22.7	760	8.7	8.63	99.8			Pass	Field
CCV	H. Schmidt	10/15/20	14:24	26.7	760	8.0	8.03	100.2			Pass	Field
CCV											Pass	Field

DO Acceptance criteria from Table ± 0.3 mg/L.

Rapid-Response Sensors: DO Gain Range 0.7 to 1.6; DO Charge Range 25-75.

Optical: DO gain range 0.83 to 1.25 (Pro DSS 0.75 to 1.50); DO charge N/A. Steady-state & Galvanic Sensors: DO Gain & Charge N/A.

Spec. Cond. FT 1200	Name	Date	Time CT-ET	Lot #	Expir. Date	Standard µmhos/cm	Meter Reading µmhos/cm	Pass /	Lab /
Calibr.	M. Clark	10/15/20	7:50	200124B	3/21	1,000	1001	Pass	Field
ICV	↓	↓	7:52	200124A	3/21	100	103.4	Pass	Field
CCV	H. Schmidt	10/15/20	14:23	200124B	3/21	1000	990.1	Pass	Field
CCV								Pass	Field

Conductivity Acceptance criteria ± 5%

pH DEP SOP FT 1100	Name	Date	Time CT-ET	Lot #	Expir. Date	pH Buffer SU	Temp °C	Meter Reading SU	mV	Pass /	Lab /
Calibr.	M. Clark	10/15/20	7:54	2004352	3/21	7.0	22.9	10.2	7.0	Pass	Field
Calibr.	↓	↓	7:56	203620	4/22	4.0	24.2	14.01	14.2	Pass	Field
Calibr.	↓	↓	7:57	201473	5/22	10.0	23.0	9.98	10.15	Pass	Field
Calibr.	↓	↓	7:58	203620	4/22	4.0	23.9	3.93	10.95	Pass	Field
ICV	↓	↓	7:59	203620	4/22	10	23.7	10.13	10.6	Pass	Field
CCV	H. Schmidt	10/15/20	14:24	201473	5/22	10	23.7	10.13	10.6	Pass	Field
CCV										Pass	Field

pH Acceptance criteria ± 0.2 SU, mV pH 7 Range 0 ± 50;

mV pH 4 Range +180 ± 50;

mV pH 10 Range +180 ± 50;

if mV is recorded slope from 7 to 10

slope from 4 to 7

both must be between 165 and 185 mV

Does meter have a depth sensor that will be used to measure total depth & sample depth? YES / NO / N/A (if not, water level)

If YES, complete daily Calibr. & ICV below and list date of last quarterly depth verification: 10/13/20

If NO, what will be used? Secchi Disk Line / Sonar Unique ID: _____

Depth Sensor (Daily Calibration & ICV)	Name	Date	Time CT-ET	Calibrated Value (0.00 or Offset), meters	ICV Value, meters	Pass/ Fail	Lab/ Field
Pressure mode in air	M. Clark	10/15/20	7:59	0.00	0.00	Pass	Field

Report two decimal places. Round numbers ≤ 4 down, ≥ 5 up. ICV acceptance criteria ± 5% or ± 0.05m, whichever is less.

COMMENTS:

Form #B-10-1 (Rev. 1-2017)



RQ-2020-10-12-54

Customer: WQAP

Project ID: SMP

Collected By: Heather Schmuki, Nathan Mulkey

Field Report Prepared By: Heather Schmuki

Sampling Agency: FDEP

Place Label Here

Comments:

WIN ID/Field ID:



G4NW0455

Location: Graveyard Branch Downstream Of Tradewinds Dr.

Matrix: Fresh

(Check one)

☒ GRAB☐ COMPOSITE

Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
10/15/2020	08:53 CEN	7.57	86.4	21.9	7.09	0.1	0.2 ☒ VOB (S)	0.2	129.3	0.06

Central Lab please use top row for login purposes

	CEN									

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP	☒ Ice ☒ H2SO4*	☒ <2	1	A
	Lot # Sa9354050 Exp: 12/20/20				
Metals (P-500ML)	☒ W-ICPMS ☒ W-ICP ☒ W-HARD	☒ Ice ☒ HNO3*	☒ <2	1	A
	Lot # Na9354060 Exp: 12/20/20				
Filtered Nutrients (P125ML)	☐ W-PO4-F ☐ Field Filtered 0.45 µm Filter	☐ Ice			
	Filter Lot # Syringe Lot #				
Chlorophyll (BP-1L)	☐ CHLSUITE-W	☐ Ice			
Physical/Aggregate (Fresh) (P-1L)	☐ Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W-TDS	☐ Ice			
Physical/Aggregate (Marine) (P-1L)	☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	☐ Ice			
Macroinvertebrates (PJ-2L)	☒ MI-FW-QLDC	☒ Formalin		2	
Periphyton (PT-50ML)	☐ ALGAE-ID	☐ Ice			
Microbiology (Contract Lab Bottle)	☒ E Coli ☐ F Coli ☐ Enterococci ☐ Contract Lab	☒ Ice		1	A
Molecular (QPCR-P-500ML)	☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD	☐ Ice			
Tracers (BG-500ML)	☒ W-E8321-DI ☒ W-E8321-MS	☒ Ice		1	A
Pesticides (BG-500ML) (BG-1L)	☐ W-E8321-DI ☐ WE8321-MS ☒ W-PSNP-TQ ☐ W-CT-CL-R ☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution)	☒ Ice		2	A
		☐ Ice			

Name:
Heather Schmuki
Nathan Mulkey

Signature:

Date:

10/15/2020

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION STRATEGIC MONITORING PROGRAM FIELD SHEET

January 2020

Meter Passed End
of Day CCV
☒ Yes / ☐ No

WIN Station Name: Graveyard Branch Downstream Of Tradewinds Dr. **Date:** 10/15/2020
WIN/Field ID: G4NW0455 **WBID:** 639 **ENR:** **Latitude:** 30.5098
County: ESCAMBIA **Org ID:** 21FLPNS **Longitude:** -87.1732
Receiving Body of Water: Pensacola **RQ:** 2020-10-12-54

Sampling Team Members		WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check
☒	Heather Schmuki	x		x		
☒	Nathan Mulkey		x		x	x
☐						
☐						

Sampling Equipment	
☒ Sample Container	☐ Carboy
☐ Dipper	☐ Van Dorn
☒ Syringe	☐ Pole
Depth measured with: Sonar	
Secchi Equipment ID:	
Collection Method	
☒ Wading	☐ Canoe/Kayak
☐ From Shore	☐ Electric Motor
☐ Other	☐ Gasoline Motor

Water Level: ☐ Normal ☐ Low ☒ High ☐ Dry ☐ Pooled ☐ Flooded		Meter ID# 155077 (ProDSS)
Photos: No	Flow: FLOW	Tide:
Biological Samples Collected: ☐ None ☒ HA ☒ SCI ☒ RPS ☐ Algae ID ☒ LVS ☐ LVI Other:		Tide Times: High: Low:
SBIO ID Numbers:		
Notes:		

Duplicate Sample

Time Zone: CEN	Time: N/A	Field ID: N/A (WIN_ID_DUP)
WIN DMT Activity ID:		

Blank

Time Zone:	Time: N/A	Field ID: N/A (Blank Type_DDDMMYYYY)
DI Source: N/A	Location: N/A	
DI Type: N/A	Equipment ID: N/A	

LIMS EVENT ID: **WIN Import ID:**
Enter Field Parameters, Verify Station ID In LIMS DMT: (Initials/Date) **QC Station ID, Field Parameters In LIMS DMT:** (Initials/Date)
Scan/Save Field Sheets (Initials/Date) **Migrate Data to WIN:** (Initials/Date) **Verify Data In WIN:** (Initials/Date)

For more information, call 1-800-368-6272

3. *Barroetia* *Barroetia*

Date of Request: 09-OCT-2020
 Created By: KING_M On: 09-OCT-2020
 Modified By: JASROTIA_P On: 12-OCT-2020
 Customer: NW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northwest District
 Event Description: SMP Bioassessment

Send Coolers To:

Phone: 850-595-0605
 160 Government Center
 Suite 308
 Pensacola, FL 32502-5794
 Attn: Michael King
 Cooler Ship EMail: Michael.king@dep.state.fl.us

Priority: 3
 Event Status: A
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 09-OCT-2020
 Biology Request Reviewed By: JASROTIA_P On: 12-OCT-2020
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 12-OCT-2020
 Logged In By:

Send Final Report To:

160 Government Center
 Suite 308
 Pensacola, FL 32502-5794
 Attn: Cheryl Bunch
 Report Notification EMail:
 Michael.King@dep.state.fl.us;Cheryl.Bunch@dep.state.fl.us

Comments:
 Group A: SCI Kit
 Nutrients, Metals, Pesticides
 Group B: Biologicals

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: TEST HAS NO	Number of Bottles: 2	Preserved With: ICE
NW-UWF-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert-18/QT by UWF in Pensacola
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO ₃
W-HARD	Template: DEFAULT	(SM 2340B) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO ₃
Hardness		
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Barium
Calcium
Iron
Magnesium
Potassium
Sodium
Zinc

W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
---------	-----------	---

*Boron
Aluminum
Antimony
Arsenic
Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Type: BG-1L	Number of Bottles: 6	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Bottle Group B (Biological) With 2 Samples:

Bottle Type: PJ-2L	Number of Bottles: 4	Preserved With: Formalin
MI-FW-QLDC	Template: DEFAULT	(SOP-IZ06) No. Taxa of FW macroinverts, qual samp, 20 dipnets.
Bottle Type: PT-50ML	Number of Bottles: 2	Preserved With: ICE
ALGAL_ID	Template: DEFAULT	(SOP-AB05) Qualitative assessment of algal taxa present without counts

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.