

Klug, Kyle

From: Harden, Benjamin E
Sent: Wednesday, August 26, 2020 7:35 AM
To: Klug, Kyle
Subject: Re: RQ-2020-07-13-32

Correct, I don't know how they got mixed up since that is completely automated. It should be collected on the 25.

Thank you,

Ben Harden

From: Klug, Kyle <Kyle.Klug@FloridaDEP.gov>
Sent: Tuesday, August 25, 2020 3:15 PM
To: Harden, Benjamin E <Benjamin.E.Harden@FloridaDEP.gov>
Cc: Watts, John <John.Watts@FloridaDEP.gov>; Ayres, Joshua <Joshua.Ayres@dep.state.fl.us>
Subject: RE: RQ-2020-07-13-32

Another question for that site. The paperwork says it was collected at 21:55 on the 24th, however the test label on the bottle says it was collected today on the 25th at 9:55. Can you please confirm when that site was collected?

From: Klug, Kyle
Sent: Tuesday, August 25, 2020 2:31 PM
To: Harden, Benjamin E <Benjamin.E.Harden@FloridaDEP.gov>
Subject: RQ-2020-07-13-32

I'm guessing the location and field ID got mixed up on the paperwork for site G1TLHR0081?

From: Harden, Benjamin E <Benjamin.E.Harden@FloridaDEP.gov>
Sent: Tuesday, August 25, 2020 12:42 PM
To: Lab.Receiving <Lab.Receiving@floridadep.gov>
Subject: RQ-2020-06-29-34 & 2020-07-13-32

Get [Outlook for Android](#)

Login Checklist

RQ- 2020-07-13-32

Login Station ID: #5

Shipping Method: FedEx | UPS |  | Greyhound

Date/Time of Receipt: 8/ 25 /20 @ 14:10

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.9				13		✓			
0.8				14		✓			

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 °C (above 10.0 °C for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles? Yes ☐ No ☐ NA ☒ Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken? Yes ☐ No ☐ Containers intact? Yes ☒ No ☐

Caps on tight? Yes ☒ No ☐

Sufficient Sample Volume: Yes ☒ No ☐

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes ☒ No ☐ Init: KK

Chlorine detected? (One container checked per Field ID) Yes ☐ No ☒ Init: KK

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0? Yes ☒ No ☐ NA ☐ Init: KK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☐ NA ☒ Init: KK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: KK Date: 8/ 25 /20 Event contains NCRs (Y/N)? N

Run 3
Event ID: TLH-ROC-2020-08-25-01 (SMP)
Date Received: 25-AUG-2020 14:10

Login Checklist

Login Preservation Equipment

Infrared Thermometer ID:	IR TEMP GUN #5
pH Test Strips 0 – 6 Lot #	213316BV EXP:5-15-21
pH Paper 0 – 3 Lot #	
pH Paper 0 – 13 Lot #	231019 EXP:11-1-22
Chlorine Test Strips Lot #	8261 EXP:07-2021

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 8/24/2020 **Collected By:** Ben Harden, Paul Blair
Customer: TLH-DIST **Sampling Agency:** FDEP
RQ: RQ-2020-07-13-32 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 2

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Moore Branch @ Cody Church Rd	 G1TLHR0041
G1TLHR0081	 Bailey Mill Creek @ Wilson Rd

RELINQUISHED BY(SIGNATURE):

DATE/TIME:

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *HK*

Rec'd/Inspected Date: 8-25-20/1410

Paul Blair

8-25-20



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION STRATEGIC MONITORING PROGRAM FIELD SHEET

January 2020

Meter Passed End
of Day CCV
Yes / No

WIN Station Name: Moore Branch @ Cody Church Rd

Date: 8/25/2020

WIN/Field ID: G1TLHR0041

WBID: 977

ENR:

Latitude: 30.37471

County: JEFFERSON

Org ID: 21FTLHR

Longitude: -84.05292

Receiving Body of Water: Ochlockonee - St. Marks

RQ- 2020-07-13-32

Sampling Team Members		WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check
☒	Ben Harden		x		x	x
☒	Paul Blair	x		x		
☐						
☐						

Sampling Equipment	
☒ Sample Container	☐ Carboy
☐ Dipper	☐ Van Dorn
☒ Syringe	☐ Pole
Depth measured with: Secchi	
Secchi Equipment ID: #3	
Collection Method	
☒ Wading	☐ Canoe/Kayak
☐ From Shore	☐ Electric Motor
☐ Other	☐ Gasoline Motor

Water Level: ☒ Normal ☐ Low ☐ High ☐ Dry ☐ Pooled ☐ Flooded		Meter ID#	
Photos: No	Flow: FLOW	Tide:	Tide Times: High: Low:
Biological Samples Collected: ☒ None ☐ HA ☐ SCI ☐ RPS ☐ Algae ID ☐ LVS ☐ LVI Other:			
SBIO ID Numbers:			
Notes: YSI EXO 14G10108			

Duplicate Sample			
Time Zone: EST	Time: N/A	Field ID: N/A	(WIN ID_DUP)
WIN DMT Activity ID:			

Blank			
Time Zone:	Time: N/A	Field ID: N/A	(Blank Type_DDDMMYYYY)
DI Source: N/A		Location: N/A	
DI Type: N/A		Equipment ID: N/A	

LIMS EVENT ID: WIN Import ID:

Enter Field Parameters, Verify Station ID In LIMS DMT: (Initials/Date) QC Station ID, Field Parameters In LIMS DMT: (Initials/Date)

Scan/Save Field Sheets (Initials/Date) Migrate Data to WIN: (Initials/Date) Verify Data In WIN: (Initials/Date)



RQ-2020-07-13-32

Customer: WQAP

Project ID: SMP

Collected By: Ben Harden, Paul Blair

Field Report Prepared By: Ben Harden

Sampling Agency: FDEP

Place Label Here						Comments:				
WIN ID/Field ID: 										
G1TLHR0041										
Location: Moore Branch @ Cody Church Rd										
Matrix: Fresh						(Check one) ☒ GRAB ☐ COMPOSITE				
Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPTH)
8/25/2020	08:40 EST	7.6	90.6	24.1	4.55	0.2	0.4 ☒ VOB (S)	0.4	37.9	0.02
Central Lab please use top row for login purposes										
	EST									
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				☒ Ice ☒ H2SO4*		☒ <2	1	A
		Lot # 0038220		Exp: 2-7-21						
Metals (P-500ML)		☒ W-ICPMS ☒ W-ICP ☒ W-HARD				☒ Ice ☒ HNO3*		☒ <2	1	A
		Lot # 9301040		Exp: 10-28-20						
Filtered Nutrients (P125ML)		☒ W-PO4-F ☐ Field Filtered 0.45 µm Filter				☒ Ice			1	A
		Filter Lot # NA								
		Syringe Lot # 7086795								
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	A
Physical/Aggregate (Fresh) (P-1L)		☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-SO4-IC / W-TDS				☒ Ice			1	A
Physical/Aggregate (Marine) (P-1L)		☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				☐ Ice				
Macroinvertebrates (PJ-2L)		☐ MI-FW-QLDC				☐ Formalin				
Periphyton (PT-50ML)		☐ ALGAE-ID				☐ Ice				
Microbiology (Contract Lab Bottle)		☒ E Coli ☐ F Coli ☐ Enterococci ☐ Contract Lab				☒ Ice			1	A
Molecular (QPCR-P-500ML)		☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD ☐				☐ Ice				
Tracers (BG-500ML)		☒ W-E8321-DI ☒ W-E8321-MS				☒ Ice			1	A
Pesticides (BG-500ML) (BG-1L)		☐ W-E8321-DI ☐ WE8321-MS ☒ W-PSNP-TQ ☐ W-CT-CL-R ☒ W-PCL-SQ-R ☒ W-CARB-AA (5 ml of MCAA** Buffer Solution)				☒ Ice			9	A
						☐ Ice				
Name: Ben Harden Paul Blair				Signature:				Date:		

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION STRATEGIC MONITORING PROGRAM FIELD SHEET

January 2020

Meter Passed End
of Day CCV
Yes / No

WIN Station Name: G1TLHR0081

Date: 8/24/2020

WIN/Field ID: Bailey Mill Creek @ Wilson Rd WBID: 3419A

ENR:

Latitude:

County: Jefferson

Org ID: 21FLTLHR

Longitude:

Receiving Body of Water: Wacissa River

RQ- 2020-07-13-32

Sampling Team Members		WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check
☒	Ben Harden		x		x	x
☒	Paul Blair	x		x		
☐						
☐						

Sampling Equipment	
☒ Sample Container	☐ Carboy
☐ Dipper	☐ Van Dorn
☒ Syringe	☐ Pole
Depth measured with: Sonar	
Secchi Equipment ID:	
Collection Method	
☒ Wading	☐ Canoe/Kayak
☐ From Shore	☐ Electric Motor
☐ Other	☐ Gasoline Motor

Water Level: ☒ Normal ☐ Low ☐ High ☐ Dry ☐ Pooled ☐ Flooded		Meter ID#	
Photos: No	Flow: FLOW	Tide:	Tide Times: High: Low:
Biological Samples Collected: ☒ None ☐ HA ☐ SCI ☐ RPS ☐ Algae ID ☐ LVS ☐ LVI Other:			
SBIO ID Numbers:			
Notes: YSI EXO 14G101018			

Duplicate Sample

Time Zone: EST	Time: N/A	Field ID: N/A	(WIN ID_DUP)
WIN DMT Activity ID:			

Blank

Time Zone:	Time: N/A	Field ID: N/A	(Blank Type_DDMMYYYY)
DI Source: N/A	Location: N/A		
DI Type: N/A	Equipment ID: N/A		

LIMS EVENT ID: WIN Import ID:

Enter Field Parameters, Verify Station ID In LIMS DMT: QC Station ID, Field Parameters In LIMS DMT:

Scan/Save Field Sheets Migrate Data to WIN: Verify Data In WIN:



RQ-2020-07-13-32

Customer: WQAP

Project ID: SMP

Collected By: Ben Harden, Paul Blair

Field Report Prepared By: Ben Harden

Sampling Agency: FDEP

Place Label Here						Comments:				
WIN ID/Field ID:  Location: G1TLHR0081										
Matrix: Fresh						(Check one) ☒ GRAB ☐ COMPOSITE				
Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
25 8/24/2020	09:55 21:55 EST	4.11	49.8	25	6.79	0.15	0.3 ☒ VOB (S)	0.3	138	0.06
Central Lab please use top row for login purposes										
EST										
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				☒ Ice ☒ H2SO4*		☒ <2	1	B
		Lot # 0038110		Exp: 2-7-21						
Metals (P-500ML)		☐ W-ICPMS ☐ W-ICP ☐ W-HARD				☐ Ice ☐ HNO3*		☐ <2		
		Lot #		Exp:						
Filtered Nutrients (P125ML)		☒ W-PO4-F ☒ Field Filtered 0.45 µm Filter				☒ Ice			1	B
		Filter Lot #								
		Syringe Lot # 7086795								
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	B
Physical/Aggregate (Fresh) (P-1L)		☐ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-SO4-4C / W-TDS				☐ Ice				
Physical/Aggregate (Marine) (P-1L)		☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				☐ Ice				
Macroinvertebrates (PJ-2L)		☐ MI-FW-QLDC				☐ Formalin				
Periphyton (PT-50ML)		☐ ALGAE-ID				☐ Ice				
Microbiology (Contract Lab Bottle)		☒ E Coli ☐ F Coli ☐ Enterococci ☐ Contract Lab				☒ Ice			1	B
Molecular (QPCR-P-500ML)		☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD ☐				☐ Ice				
Tracers (BG-500ML)		☒ W-E8321-DI ☒ W-E8321-MS				☒ Ice			1	B
Pesticides (BG-500ML) (BG-1L)		☐ W-E8321-DI ☐ WE8321-MS ☐ W-PSNP-TQ ☐ W-CT-CL-R ☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution)				☐ Ice				
						☐ Ice				
Name: Ben Harden Paul Blair				Signature:				Date:		

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution

Date of Request: 25-JUN-2020
 Created By: ECKLES_M On: 25-JUN-2020
 Modified By: WATTS_J On: 14-JUL-2020
 Customer: TLH-ROC
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Not Applicable
 Event Description: Run 3

Send Coolers To:

Phone: 850-245-7586
 2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Michael Eckles
 Cooler Ship EMail: michael.eckles@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 30-JUN-2020
 Biology Request Reviewed By: JASROTIA_P On: 30-JUN-2020
 Sampling Kit Required: YES Ship on: 16-JUL-2020
 Sampling Kit Shipped: YES On: 14-JUL-2020
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 27-JUL-2020
 Logged In By: KLUG_K On: 27-JUL-2020

Send Final Report To:

2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Michael Eckles
 Report Notification EMail: michael.eckles@dep.state.fl.us

Comments: Group A WBID 977
 Group B WBID 3419A
 Group C WBID 3310A
 Group D WBID 3473A1
 Group E 3473A1 & 3310A
 No fedex labels

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2CICOOH Pre-Preserved

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2CICOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCL-SQ-R	Template:	(EPA 8270E) Organochlorine pesticides in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-HARD	Template: DEFAULT	(SM 2340B) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3
Hardness		
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium		
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
*Boron		
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template: S-METALS	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Iron		
Manganese		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group E (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.