

RQ-2020-10-19-52

Login Checklist

Login Station ID: #1

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 11/9/2020 1420

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
					Yes	No	Yes	No	
3.3		HNO ₃	Formalin	11		✓			

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ✓

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ✓

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ✓ No _____

Caps on tight?

Yes ✓ No _____

Sufficient Sample Volume:

Yes ✓ No _____If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ✓ No _____ Init: [Signature]

Chlorine detected? (One container checked per Field ID)

Yes _____ No ✓ Init: [Signature]

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ✓ No _____ NA _____ Init: [Signature]

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ✓ Init: [Signature]

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: [Signature]

Date: 11/9/2020

Event contains NCRs (Y/N)? N

Event ID:

Run 7

TLH-ROC-2020-11-09-01 (SMP)

Page 1 of 1

Date Received: 09-NOV-2020 14:20

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	#1 Temp Gun EXP:10/28/2021
pH Test Strips 0 – 6	N/A
pH Paper 0 – 3	N/A
pH Paper 0 – 13	231019 EXP:11/01/2022
Chlorine Test Strips	8261 EXP:07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Request Number: ~~RQ-2020-08-24-10~~ CB

Florida Department of Environmental Protection

Page 1 of 4

Central Laboratory Submittal Form

last revised Jan 25, 2018

Customer: TLH-ROC

Requester: Michael Eckles

Field Report Prepared By: J. Burchett

Project ID: SMP

Collected By: B. Harden, J. BurchettSampling Agency: 8034

Location	☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>11/9/20</u> Time <u>1230</u>	Eastern Central	Composite end Date <u>-</u> Time <u>-</u>	Bottle Group(s) (See pg 2)
Field ID	Matrix (type, e.g., Salt, Fresh, etc) <u>Fresh</u>		Diss. Oxygen <u>7.88</u>	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)
WIN/STORE #	Temp (C) <u>21.1</u>	pH <u>6.30</u>	Sample Depth <u>0.3</u>	☐ ft ☒ m	Sp. Conductance (umho/cm) <u>90.7</u>
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Comments	
ALAPHA RIVER TREND SITE					
G1TLHR0136					

Location	☐ Comp ☐ Grab	Collection (comp begin or grab) Date <u>-</u> Time <u>-</u>	Eastern Central	Composite end Date <u>-</u> Time <u>-</u>	Bottle Group(s)
Field ID	Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)
WIN/STORE #	Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Comments	

Location	☐ Comp ☐ Grab	Collection (comp begin or grab) Date <u>-</u> Time <u>-</u>	Eastern Central	Composite end Date <u>-</u> Time <u>-</u>	Bottle Group(s)
Field ID	Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)
WIN/STORE #	Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Comments	

Location	☐ Comp ☐ Grab	Collection (comp begin or grab) Date <u>-</u> Time <u>-</u>	Eastern Central	Composite end Date <u>-</u> Time <u>-</u>	Bottle Group(s)
Field ID	Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)
WIN/STORE #	Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Comments	

Relinquished By: <u>BH, JB</u>	Date/Time <u>11/9/20: 1415</u>	Shipping Method <u>HO</u>	Number of Coolers Shipped: <u>1</u>	Received By: <u>[Signature]</u>	Date/Time <u>11/9/20 1420</u>
-----------------------------------	-----------------------------------	------------------------------	--	------------------------------------	----------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WO-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	ECOLI-18QT						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	HNO3	Enter Number of Bottles Sent to Lab	1
	W-HARD W-ICP W-ICPMS						
	9354060 12/20/20						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
	Pest. WE 8321-DI WE 8321-MS W-PSNP-TQ						
	W-CT-CL-R W-PCL-SQ-R W-CARB-AA						
	106+15						
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 5	Preservative:	ICE	Enter Number of Bottles Sent to Lab	
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS						

Date of Request: 12-OCT-2020
 Created By: ECKLES_M On: 12-OCT-2020
 Modified By: JASROTIA_P On: 12-OCT-2020
 Customer: TLH-ROC
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Not Applicable
 Event Description: Run 7

Send Coolers To:

Phone: 850-245-7586
 2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Michael Eckles
 Cooler Ship EMail: michael.eckles@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 12-OCT-2020
 Biology Request Reviewed By: JASROTIA_P On: 12-OCT-2020
 Sampling Kit Required: YES Ship on: 22-OCT-2020
 Sampling Kit Shipped: YES On: 20-OCT-2020
 Sampling Kit Packed By: KLUG_K
 Preservatives Needed: NO
 Date to Receive Samples: 19-OCT-2020
 Logged In By: REYNOLDS_T On: 04-NOV-2020

Send Final Report To:

2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Michael Eckles
 Report Notification EMail: michael.eckles@dep.state.fl.us

Comments: Group A WBID 512

No fedex labels

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: MASTERLIST	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML		Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: HNO3
W-HARD	Template: DEFAULT	(SM 2340B)	Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3
Hardness			
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	
Barium			
Calcium			
Iron			
Magnesium			
Potassium			
Sodium			
Zinc			
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects	
*Boron			
Aluminum			
Antimony			
Arsenic			
Beryllium			
Cadmium			
Chromium			
Copper			
Lead			
Nickel			
Selenium			
Silver			
Thallium			
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0)	Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011)	Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML		Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.