

Login Checklist

RQ: 2020-02-17-29

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 02/20/2020 @ 9:50

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.7				15		X			1278 4010 1622
2.6				12		X			1278 4010 1611

*All samples received on ice unless otherwise noted. If the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), received without ice, or if Evidence Seal is damaged; identify the containers in the affected cooler(s) on back of this form. HNO3 and Formalin preserved samples do **NOT** have a temperature requirement. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation; An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ✓ No ✗

**Note: If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No X If yes, is it intact? Yes No

**Caps on tight? Yes ✓ No **Containers intact? Yes ✓ No

**Sufficient Sample Volume: Yes ✓ No

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes ✓ No Init: Tyler K

Chlorine detected? (One container checked per Field ID) Yes No X Init: Tyler K

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0? Yes ✓ No NA Init: Tyler K

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA X Init: Tyler K

Coolers Unpacked/Checked by: Tyler Reynolds Date: 02/20/2020 NCRs (Y/N)? NONE

Event ID: Mizelle, Owens, McDonald, Chito, G NCR #
SW-DIST-2020-02-20-01 (SMP)

Date Received: 20-FEB-2020 09:50

Samples with Incorrect pH Preservation

Field ID	Bottle Test ID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #4 EXP: 11/05/2020
pH Test Strips 0 – 6 Lot #	213316AV EXP: 05/15/2020
pH Paper 0 – 3 Lot #	N/A
pH Paper 0 – 13 Lot #	215517 EXP: 06/01/2020
Chlorine Test Strips Lot #	8261 EXP: 07/30/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Request Number: RQ-2020-02-17-29

Mizelle, Owens, McDonald, Chito, Gilley

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Page 1 of 4

last revised Jan 25, 2018

Customer: SW-DIST

Project ID: SMP

Requester: Judy Ashton

Field Report Prepared By: BP

Collected By: Ben Paswater, Kelly Callahan

Sampling Agency: SWRDC

Location		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 2/19/20 Time 1220	Eastern Central	Composite end Date Time	Bottle Group(s) (See pg 2)
Field ID/WIN G2SW0133		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen 5.06, 57.4	☒ mg/L ☒ % sat	Total Res. Chlorine (mg/L)
Site Name: Chito Branch in Park		Temp (C) 21.5	pH 7.40	Sample Depth 0.3	☐ ft ☒ m	Sp. Conductance (umho/cm) 259.1
☐ dd ☐ dms		Salinity (ppt) 0.12	Comments			
Location		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 2/19/20 Time 1330	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID/WIN G2SW0024		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen 8.14, 95.8	☒ mg/L ☒ % sat	Total Res. Chlorine (mg/L)
Site Name: Gilley Creek @ Stricklands		Temp (C) 23.4	pH 7.34	Sample Depth 0.35	☐ ft ☒ m	Sp. Conductance (umho/cm) 155.6
☐ dd ☐ dms		Salinity (ppt) 0.07	Comments			
Location		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 2/19/20 Time 1000	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID/WIN G2SW0093		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen 6.82, 76.3	☒ mg/L ☒ % sat	Total Res. Chlorine (mg/L)
Site Name: McDonald Branch @ Thompson Rd		Temp (C) 20.8	pH 7.00	Sample Depth 0.25	☐ ft ☒ m	Sp. Conductance (umho/cm) 253
☐ dd ☐ dms		Salinity (ppt) 0.12	Comments			
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)
WIN/STORET #		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms	Salinity (ppt) ☐ dd ☐ dms	Comments		

Relinquished By: Ben Parr	Date/Time: 2/19/20 4pm	Shipping Method: Fed Ex	Number of Coolers Shipped: 2	Received By: Tyler R.	Date/Time: 02/20/2020 @ 9:50
---------------------------	------------------------	-------------------------	------------------------------	-----------------------	------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	CHLSUITE-W						
Group: A	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	PCR-BACR						
	PCR-DG3						
	PCR-HF183						
Group: A	Bottle Type:	TEST HAS NO BOTTLE	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2 to BEA
	SW-BEA-ECQ						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	W-E8321-DI						
	W-E8321-MS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	2
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	2
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	3
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						

Request Number: RQ-2020-02-17-29

Mizelle, Owens, McDonald, Chito, Gilley

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Page 2 of 3

last revised Jan 25, 2018

Customer: SW-DIST

Project ID: SMP

Requester: Judy Ashton

Field Report Prepared By:

Collected By:

Sampling Agency:

Location		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 2/19/2020 Time 1130		Eastern Central		Composite end Date Time		Bottle Group(s) (See pg 2)	
Field ID/WIN G2SW0132		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen 7.82, 8.91		☒ mg/L ☒ % sat		Total Res. Chlorine (mg/L)		A	
Site Name: Owens Branch in Park		Temp (C) 21.8		pH 7.48		Sample Depth 0.3		☐ ft ☒ m		Sp. Conductance (umho/cm) 198.8	
☐ dd ☐ dms		Salinity (ppt) 0.09		Comments							
Location		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 2/19/20 Time 1045		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID/WIN G2SW0131		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen 8.22, 9.34		☐ mg/L ☒ % sat		Total Res. Chlorine (mg/L)		A	
Site Name: Mizelle Creek in Park		Temp (C) 21.6		pH 7.38		Sample Depth 0.3		☐ ft ☒ m		Sp. Conductance (umho/cm) 260.6	
☐ dd ☐ dms		Salinity (ppt)		Comments							
Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		☐ ft ☐ m		Sp. Conductance (umho/cm)	
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments					
Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		☐ ft ☐ m		Sp. Conductance (umho/cm)	
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt)		Comments					

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
				TLR R.	02/20/2020 9:50

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: A	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	PCR-BACR PCR-DG3 PCR-HF183					
Group: A	Bottle Type:	TEST HAS NO BOTTLE	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	SW-BEA-ECQ					
Group: A	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	W-E8321-DI W-E8321-MS					
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab _____
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY TURBIDITY W-CL-IC W-COLOR					

4 of 4

Group: B	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	3
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: B	Bottle Type:	BP-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	3
	CHLSUITE-W						
Group: B	Bottle Type:	TEST HAS NO BOTTLE	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	3 to BEA
	SW-BEA-ECQ						
Group: B	Bottle Type:	BG-500ML	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	3
	W-E8321-DI						
	W-E8321-MS						
Group: B	Bottle Type:	P-500ML	# of Bottles: 3	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	3
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: B	Bottle Type:	P-125ML	# of Bottles: 3	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	3
	W-PO4-F						

Benchmark EnviroAnalytical, Inc
1711 12th Street East
Palmetto, FL 34221
941-723-9986
941-723-6061 Fax

PO# B578C6

Client Information: FDEP

Address: 13051 N. Telecom Parkway

Tampa FL 33604

Phone # 815-470-5772

Report to: Judy.ashton@dep.state.fl.us, DEP-Overflomicro@dep.state

Invoice to: FDEP Micro Overflow

Project Name: RQ-2020- 02-17-29

Laboratory Submission #

20020984

Sample Name	Sample Type ¹ / Sample Matrix ²	Collection		Container			Preservative ⁴	Parameters for Analysis	Laboratory Sample #
		Date	Time	Qty	Capacity	Type ³			
G2SW 0132	SW	2/19/20 ↓	1130	1	120mL	P	Plain (on Ice)	E.coli	1
G2SW 0131	SW		1045	1	120mL	P	Plain (on Ice)	E. Coli	2
G2SW 0133	SW		1220	1	120mL	P	Plain (on Ice)	E. Coli	3
G2SW 0024	SW		1330	1	120mL	P	Plain (on Ice)	E. Coli	4
G2SW 0093	SW		1000	1	120mL	P	Plain (on Ice)	E. Coli	5
	SW				120mL	P	Plain (on Ice)		
	SW				120mL	P	Plain (on Ice)		

¹ "Sample Type" is used to indicate whether the sample was a grab (G) or whether it was a composite (C).
² "Sample Matrix" is used to indicate whether the sample is being discharged to drinking water (DW), groundwater (GW), surface water (SW), fresh surface water (FSW), saline surface water (SSW), soil, sediment (SDMNT), or sludge (SLDG).
³ "Container Type" is used to indicate whether the container is plastic (P) or glass (G).
⁴ Sample must be refrigerated or stored in wet ice after collection. The temperature during storage should be less than or equal to 5°C (42.8°F).
Under "Preservative," list any preservatives that were added to the sample container.

Instructions:
1. Each bottle has a label identifying sample ID, preservative contained in the bottle, sample type, client ID, and parameters for analysis.
2. The following information should be added to each bottle label after collection with permanent black ink: date and time of collection, sampler's name or initials, and any field number or ID.
3. All bottles not containing preservative may be rinsed with appropriate sample prior to collection.
4. The client is responsible for documentation of the sampling event. Please note special sampling events on the sample custody form.

Laboratory Sample Acceptability:

Temperature: 24°C

1	Collected / Relinquished By: <u>Be Pant</u>	Date 2/19/20	Time 1:41	Received By: <u>[Signature]</u>	Date 2-19-20	Time 1443
2	Relinquished By:	Date	Time	Received By:	Date	Time

Date of Request: 23-JAN-2020
 Created By: ASHTON_J On: 23-JAN-2020
 Modified By: JASROTIA_P On: 27-JAN-2020
 Customer: SW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southwest District
 Sampling Event: Mizelle, Owens, McDonald, Chito, Gilley

Send Coolers To:

Phone: 813-470-5772
 FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Judy Ashton

Program Module Number:

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 27-JAN-2020
 Biology Request Reviewed By: JASROTIA_P On: 27-JAN-2020
 Sampling Kit Required: YES Ship on: 07-FEB-2020
 Sampling Kit Shipped: YES On: 06-FEB-2020
 Sampling Kit Packed By: KLUG_K
 Preservatives Needed: NO
 Date to Receive Samples: 17-FEB-2020
 Received By:

Send Final Report To:

FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Judy Ashton

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments:

Group A: Freshwater Nutrients, E.coli, Tracers & markers
 Group B: Freshwater Nutrients, E.coli, Tracers

PLEASE DO NOT SEND BACTERIA BOTTLES

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: QPCR-P-500ML	Number of Bottles: 2	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: TEST HAS NO	Number of Bottles: 2	Preserved With: ICE
SW-BEA-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by BEA in Palmetto
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 3 Samples:

Bottle Type: TEST HAS NO	Number of Bottles: 3	Preserved With: ICE
SW-BEA-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by BEA in Palmetto
Bottle Type: BG-500ML	Number of Bottles: 3	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 3	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 3	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.