

Login Checklist

RQ-2020-06-15-13

Login Station ID: #4

Shipping Method: ☒ FedEx | ☐ UPS | ☐ HD | ☐ Greyhound

Date/Time of Receipt: 07/07/2020 @ 11:40

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
3.2				15		x			12784013 1989

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No _____ Init: Jylup

Chlorine detected? (One container checked per Field ID)

Yes _____ No ☒ Init: Jylup

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes ☒ No _____ NA _____ Init: Jylup

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA ☒ Init: Jylup

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: Jylup

Date: 07/07/2020

Event contains NCRs (Y/N)? None

Event ID:

Run 7 Whitaker Creek
SW-DIST-2020-07-07-01 (SMP)

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	#4 Temp Gun EXP:11/05/2020
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	231019 EXP:11/01/2022
Chlorine Test Strips	8261 EXP:07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: SW-DIST

Requester: Benjamin Paswater

Field Report Prepared By: S Meyer

Project ID: SMP

Collected By: M Bearden & S Meyer

Sampling Agency: FDEP SW ROC

Location		☐ Comp	Collection (comp begin or grab)		☒ Grab	Date	Time	Eastern	Composite end	Bottle Group(s)
Field ID/WIN		Date		Time		Date		Time		A*
G3SW0059		07/06/2020		0955		07/06/2020		0955		
WIN/STORET #		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		mg/L		Total Res. Chlorine (mg/L)		
Site Name: Whitaker Bayou @ Museum Office Pier		Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)		
Latitude		Salinity (ppt)		Comments		dd		dms		
G3SW0060		31.07		* ENTERED ONLY - DROPPED NT @ BENCHMARK						
Field ID/WIN		Date		Time		Date		Time		A
G3SW0060		07/06/2020		1010		07/06/2020		1010		
WIN/STORET #		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		mg/L		Total Res. Chlorine (mg/L)		
Site Name: Whitaker Bayou @ Ringling College of Art		Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)		
Latitude		Salinity (ppt)		Comments		dd		dms		
30.13		ENTERED DROPPED NT @ BENCHMARK								
Field ID		Date		Time		Date		Time		
WIN/STORET #		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		mg/L		Total Res. Chlorine (mg/L)		
Latitude		Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)		
Longitude		Salinity (ppt)		Comments		dd		dms		
Field ID		Date		Time		Date		Time		
WIN/STORET #		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		mg/L		Total Res. Chlorine (mg/L)		
Latitude		Temp (C)		pH		Sample Depth		Sp. Conductance (umho/cm)		
Longitude		Salinity (ppt)		Comments		dd		dms		

Relinquished By: Sarah Meyer	Date/Time: 07/06/2020 1500	Shipping Method: FedEx	Number of Coolers Shipped: 1	Received By: Tyler Reynolds	Date/Time: 07/07/2020
------------------------------	----------------------------	------------------------	------------------------------	-----------------------------	-----------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WI-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	SW-AEL-ENG SW-BBA-END						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	CH2CICOOH Pre-Preserved	Enter Number of Bottles Sent to Lab	1
	W-CARB-AA						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	W-CT-CI-R W-PCL-SQ-R						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	W-E8321-DI W-E8321-MS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	HNO3	Enter Number of Bottles Sent to Lab	1
	W-ICP W-ICPMS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	1
	W-PO4-F						
Group: A	Bottle Type:	BG-1L	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab	4
	W-PSNP-TQ						

Benchmark EnviroAnalytical, Inc

1711 12th Street East

Palmetto, FL 34221

941-723-9986

941-723-6061 Fax

PO# ~~B578C6~~ B77B80

Client Information: **FDEP**

Address: 13051 N. Telecom Parkway

Tampa FL 33604

Phone # 815-470-5772

Report to: Judy.ashton@dep.state.fl.us, DEP-Overflomicro@dep.state

Invoice to: FDEP Micro Overflow

Project Name: RQ-2020-06-15-13

Laboratory Submission #

Sample Name	Sample Type ¹ / Sample Matrix ²	Collection		Container			Preservative ⁴	Parameters for Analysis	Laboratory Sample #
		Date	Time	Qty	Capacity	Type ³			
G3SW0059	SW	7/6/20	0955		120mL	P	Plain (on Ice)	Enter0	
G3SW0060	SW	7/6/20	1010		120mL	P	Plain (on Ice)	Enter0	
	SW				120mL	P	Plain (on Ice)		
	SW				120mL	P	Plain (on Ice)		
	SW				120mL	P	Plain (on Ice)		
	SW				120mL	P	Plain (on Ice)		
	SW				120mL	P	Plain (on Ice)		

1 "Sample Type" is used to indicate whether the sample was a grab (G) or whether it was a composite (C).
2 "Sample Matrix" is used to indicate whether the sample is being discharged to drinking water (DW), groundwater (GW), surface water (SW), fresh surface water (FSW), saline surface water (SSW), soil, sediment (SDMNT), or sludge (SLDG).
3 "Container Type" is used to indicate whether the container is plastic (P) or glass (G).
4 Sample must be refrigerated or stored in wet ice after collection. The temperature during storage should be less than or equal to 6°C (42.8°F).
Under "Preservative," list any preservatives that were added to the sample container.

Instructions:

- Each bottle has a label identifying sample ID, premeasured preservative contained in the bottle, sample type, client ID, and parameters for analysis.
- The following information should be added to each bottle label after collection with permanent black ink: date and time of collection, sampler's name or initials, and any field number or ID.
- All bottles not containing preservative may be rinsed with appropriate sample prior to collection.
- The client is responsible for documentation of the sampling event. Please note special sampling events on the sample custody form.

Laboratory Sample Acceptability:

Temperature:

1	Collected / Relinquished By: <i>S. Meyer / S. Meyer</i>	Date <i>7/6/20</i>	Time <i>1059</i>	Received By: <i>Dropped off @ table due to Covid.</i>	Date	Time
2	Relinquished By:	Date	Time	Received By:	Date	Time

Date of Request: 26-MAR-2020
 Created By: PASWATER_B On: 26-MAR-2020
 Modified By: JASROTIA_P On: 01-JUN-2020
 Customer: SW-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southwest District
 Event Description: Run 7 Whitaker Creek

Send Coolers To:

Phone: 813-632-7600
 FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Paswater
 Cooler Ship EMail: benjamin.paswater@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 01-JUN-2020
 Biology Request Reviewed By: JASROTIA_P On: 01-JUN-2020
 Sampling Kit Required: YES Ship on: 05-JUN-2020
 Sampling Kit Shipped: YES On: 03-JUN-2020
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 15-JUN-2020
 Logged In By: REYNOLDS_T On: 07-JUL-2020

Send Final Report To:

FL Dept. of Environmental Protection
 13051 N. Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Ben Pawater
 Report Notification EMail:
 benjamin.paswater@dep.state.fl.us;judy.ashton@dep.state.fl.us;
 sarah.meyer@dep.state.fl.us

Comments: Run 7 Whitaker Creek

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SW-AEL-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert/QT by AEL in Tampa
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ CICOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO ₃
W-ICP	Template: S-METALS	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Iron		
Manganese		
Zinc		

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Aluminum
Antimony
Arsenic
Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.