

Login Checklist

RQ- 2020-07-27-16

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 9/ 22 /20 @ 9:55

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.1 7.9				7 10		✓ ✓ ✓			1278 4014 7537 1278 4014 7613

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# 8437
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No _____ Init: KKI

Chlorine detected? (One container checked per Field ID)

Yes _____ No ☒ Init: KK

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No _____ NA _____ Init: KK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ☒ Init: KK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: KK

Date: 9/ 22 /20

Event contains NCRs (Y/N)? Y

Event ID: North Boat + Deploy
SE-DIST-2020-09-22-01 (SMP)

Date Received: 22-SEP-2020 09:55

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Infrared Thermometer ID:	Temp Gun #5 EXP:11/05/2020
pH Test Strips 0 – 6	5/15/21 LOT#213316BV
pH Paper 0 – 3	
pH Paper 0 – 13	231019 EXP:11/01/2022
Chlorine Test Strips	8261 EXP:07/2021

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection
Central Laboratory Submittal Form

North Boat + Deploy


last revised Jan 25, 2018

Customer: SE-DIST

Requester: Jordan SkaggsField Report Prepared By: Jordan Skaggs

Project ID: SMP

Collected By: Jordan Skaggs, Drew LiddickSampling Agency: 21FLWPR

Location: South Prong Sebastian @ Park Dock		☐ Comp ☒ Grab		Collection (comp begin or grab) Date <u>09/21/20</u> Time <u>14:00</u>		☒ Eastern ☐ Central		Composite end Date _____ Time _____		Bottle Group(s) (See pg 2)	
WIN ID/Field ID:  G5SE0079		Matrix (type, e.g., Salt, Fresh, etc) <u>SALT</u>		Diss. Oxygen <u>6.27</u>		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L) _____		A	
Latitude ☐ dd ☐ dms Longitude ☐ dd ☐ dms		Temp (C) <u>28.6</u>		pH <u>7.71</u>		Sample Depth <u>0.3</u>		☐ ft ☒ m Sp. Conductance (umho/cm) <u>23188</u>			
Location: Sebastian @ Dale Wimbrow		☐ Comp ☒ Grab		Collection (comp begin or grab) Date <u>09/21/20</u> Time <u>14:40</u>		☒ Eastern ☐ Central		Composite end Date _____ Time _____		Bottle Group(s)	
WIN ID/Field ID:  G5SE0073		Matrix (type, e.g., Salt, Fresh, etc) <u>SALT</u>		Diss. Oxygen <u>4.76</u>		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L) _____		B	
Latitude ☐ dd ☐ dms Longitude ☐ dd ☐ dms		Temp (C) <u>28.6</u>		pH <u>7.39</u>		Sample Depth <u>0.3</u>		☐ ft ☒ m Sp. Conductance (umho/cm) <u>4192</u>			
Field ID		☐ Comp ☐ Grab		Collection (comp begin or grab) Date _____ Time _____		☐ Eastern ☐ Central		Composite end Date _____ Time _____		Bottle Group(s)	
WIN/STORET #		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
Latitude ☐ dd ☐ dms Longitude ☐ dd ☐ dms		Temp (C)		pH		Sample Depth		☐ ft ☐ m Sp. Conductance (umho/cm)			
Field ID		☐ Comp ☐ Grab		Collection (comp begin or grab) Date _____ Time _____		☐ Eastern ☐ Central		Composite end Date _____ Time _____		Bottle Group(s)	
WIN/STORET #		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
Latitude ☐ dd ☐ dms Longitude ☐ dd ☐ dms		Temp (C)		pH		Sample Depth		☐ ft ☐ m Sp. Conductance (umho/cm)			

Relinquished By: <u>JS (DEP)</u>	Date/Time: <u>09/21/20</u>	Shipping Method: <u>Fedex</u>	Number of Coolers Shipped: <u>2</u>	Received By: <u>KK</u>	Date/Time: <u>9.22.20/0955</u>
----------------------------------	----------------------------	-------------------------------	-------------------------------------	------------------------	--------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WO-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	ENT-24-QT						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	CH2ClCOOH Pre-Preserved	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-CARB-AA						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>4</u>
	W-CT-CI-R W-PCL-SQ-R						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-E8321-DI W-E8321-MS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	HNO3	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-ICP W-ICPMS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-PO4-F						
Group: A	Bottle Type:	BG-1L	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>4</u>
	W-PSNP-TQ						
Group: B	Bottle Type:	P-250ML-WO-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	

Group: B	Bottle Type: P-250ML-WO-THI	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
ENT-24-QT					
Group: C	Bottle Type: P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	0
ALKALINITY					
TURBIDITY					
W-BR-IC					
W-F					
W-TSS					
Group: C	Bottle Type: BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	0
CHLSUITE-W					
Group: C	Bottle Type: P-250ML-WO-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	0
ENT-24-QT					
Group: C	Bottle Type: P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	0
W-NH3					
W-NO2NO3					
W-S-A-TP					
W-TKN					
W-TOC					
Group: C	Bottle Type: P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	0
W-PO4-F					

Date of Request: 02-JUL-2020
 Created By: SKAGGS_J On: 02-JUL-2020
 Modified By: WATTS_J On: 29-JUL-2020
 Customer: SE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southeast District
 Event Description: North Boat + Deploy

Send Coolers To:

Phone: (772) 448-5884
 FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Jordan Skaggs
 Cooler Ship EMail: jordan.skaggs@FloridaDEP.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 29-JUL-2020
 Biology Request Reviewed By: JASROTIA_P On: 29-JUL-2020
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped: YES On: 20-JUL-2020
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 05-AUG-2020
 Logged In By: SHAIK_A On: 05-AUG-2020

Send Final Report To:

FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Drew Liddick
 Report Notification EMail:
 jordan.skaggs@FloridaDEP.gov;drew.liddick@floridadep.gov

Comments: Sampler Comments:

Bottle Group A:
3129B1-G573

Bottle Group B:
3129B1-G574
3135A-G582

Bottle Group C: 3135A-G581

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCL-SQ-R	Template:	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template: S-METALS	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Iron		
Manganese		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 2 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 2	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.