

# Chemical Analysis Report

**NE-DIST-2021-01-15-01**

Florida Department of Environmental Protection  
Central Laboratory  
2600 Blair Stone Road  
Tallahassee, FL 32399-2400  
DOH Accreditation E31780

Event Description: **Nassau North West 2021**

Request ID: **RQ-2021-01-11-28**

Customer: **NE-DIST**

Project ID: **SMP**

Send Reports to:  
FL Dept. of Environmental Protection  
8800 Baymeadows Way West  
Suite 100  
Jacksonville, FL 32256  
Attn: Jeremy Parrish

For additional information please contact  
Colin Wright, Ph.D.  
Liang-Tsair Lin, Ph.D.  
Kerry Tate, Ph.D.  
Dr. rer. nat. Bettina Steinbock  
Thekkekalathil Chandrasekhar, Ph.D, QA Officer  
Phone (850) 245-8085

Certified by: Thekkekalathil Chandrasekhar, Chemist Administrator

Date Certified: 08-FEB-2021 09:21



**NON-CONFORMANCE REPORT INCLUDED**

## Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Metals, Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to  $1.3 \times 10^3$  or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (\*\*) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited by the Florida Department of Health Environmental Laboratory Certification Program or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: Unnamed Branch @ Cr125

Collection Date/Time: 01/14/2021 15:00

Field ID: 19010123

Matrix: W-SURF-FRH

| Sample ID | Ref. Method        | Component | Result | Code | Units | Batch ID | QC Codes |
|-----------|--------------------|-----------|--------|------|-------|----------|----------|
| 2219773   | EPA 200.7 Rev. 4.4 | Barium    | 19.4   |      | ug/L  | P392543  |          |
|           |                    | Calcium   | 5.32   |      | mg/L  | P392543  |          |
|           |                    | Iron      | 620    |      | ug/L  | P392543  |          |
|           |                    | Magnesium | 2.28   |      | mg/L  | P392543  |          |
|           |                    | Manganese | 10.6   |      | ug/L  | P392543  |          |
|           |                    | Potassium | 1.3    |      | mg/L  | P392543  |          |
|           |                    | Sodium    | 6.4    |      | mg/L  | P392543  |          |
|           | EPA 200.8 Rev. 5.4 | Zinc      | 5.7    | I    | ug/L  | P392543  |          |
|           |                    | Aluminum  | 184    |      | ug/L  | P392543  |          |
|           |                    | Antimony  | 0.050  | U    | ug/L  | P392543  |          |
|           |                    | Arsenic   | 0.35   |      | ug/L  | P392543  |          |
|           |                    | Beryllium | 0.015  | I    | ug/L  | P392543  |          |
|           |                    | Boron**   | 14.7   |      | ug/L  | P392543  |          |
|           |                    | Cadmium   | 0.020  | U    | ug/L  | P392543  |          |
|           |                    | Chromium  | 0.49   | I    | ug/L  | P392543  |          |
|           |                    | Copper    | 0.40   | U    | ug/L  | P392543  |          |
|           |                    | Lead      | 0.23   | I    | ug/L  | P392543  |          |
|           |                    | Nickel    | 0.50   | U    | ug/L  | P392543  |          |
|           |                    | Selenium  | 0.20   | U    | ug/L  | P392543  |          |
|           |                    | Silver    | 0.010  | U    | ug/L  | P392543  |          |
|           |                    | Thallium  | 0.10   | U    | ug/L  | P392543  |          |
|           | SM 2340B           | Hardness  | 22.7   |      | mg/L  | P392543  |          |

Sample Location: Calkins At Turner Cemetary Rd

Collection Date/Time: 01/14/2021 14:35

Field ID: 19010076

Matrix: W-SURF-FRH

| Sample ID | Ref. Method | Component          | Result  | Code | Units | Batch ID | QC Codes |
|-----------|-------------|--------------------|---------|------|-------|----------|----------|
| 2219771   | EPA 8321B   | 2,4-D              | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Acesulfame K**     | 0.10    | U    | ug/L  | P392508  | MS       |
|           |             | AMPA**             | 0.10    | U    | ug/L  | P392508  |          |
|           |             | Sucralose**        | 0.38    |      | ug/L  | P392508  |          |
|           |             | Acetaminophen**    | 0.0080  | U    | ug/L  | P392593  |          |
|           |             | Acetamiprid**      | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Endothall**        | 0.25    | U    | ug/L  | P392508  |          |
|           |             | Glufosinate**      | 0.10    | U    | ug/L  | P392508  |          |
|           |             | Glyphosate**       | 0.10    | U    | ug/L  | P392508  |          |
|           |             | Afidopyropen**     | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Bentazon           | 8.0E-04 | U    | ug/L  | P392593  |          |
|           |             | Benzovindiflupyr** | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Carbamazepine**    | 8.0E-04 | U    | ug/L  | P392593  |          |
|           |             | Clothianidin**     | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Dinotefuran**      | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Diuron             | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Fenuron            | 0.016   | U    | ug/L  | P392593  |          |
|           |             | Fluridone**        | 8.0E-04 | U    | ug/L  | P392593  |          |
|           |             | Imazapyr**         | 0.22    |      | ug/L  | P392593  |          |
|           |             | Hydrocodone**      | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Ibuprofen**        | 0.020   | U    | ug/L  | P392593  |          |
|           |             | Imidacloprid       | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Linuron            | 0.0040  | U    | ug/L  | P392593  |          |
|           |             | Mandestrobin**     | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | MCPP               | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Naproxen**         | 0.0080  | U    | ug/L  | P392593  |          |
|           |             | Primidone**        | 0.0040  | U    | ug/L  | P392593  |          |
|           |             | Pyraclostrobin**   | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Thiamethoxam**     | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Tolfenpyrad**      | 0.0020  | U    | ug/L  | P392593  |          |
|           |             | Triclopyr**        | 0.0040  | U    | ug/L  | P392593  |          |

Sample Location: Calkins Cr @ Cr 127

Collection Date/Time: 01/14/2021 14:10

Field ID: 19010105

Matrix: W-SURF-FRH

| Sample ID | Ref. Method                  | Component          | Result  | Code | Units      | Batch ID | QC Codes |
|-----------|------------------------------|--------------------|---------|------|------------|----------|----------|
| 2219752   | EPA 180.1 Rev. 2.0           | Turbidity          | 3.6     | A    | NTU        | P392476  |          |
|           | EPA 300.0 Rev. 2.1           | Chloride           | 12      |      | mg Cl/L    | P392734  |          |
|           |                              | Sulfate            | 0.20    | U    | mg SO4/L   | P392736  |          |
|           | SM 2120 B-2011               | Color (true)       | 250     |      | PCU        | P392457  |          |
|           | SM 2320 B-2011               | Total Alkalinity   | 0.65    | U    | mg CaCO3/L | P392588  |          |
|           | SM 2540 C-2011               | TDS                | 104     |      | mg/L       | P392811  |          |
|           | SM 2540 D-2011               | TSS                | 2       | I    | mg/L       | P392970  |          |
| 2219753   | SM 4500 F-C-2011             | Fluoride           | 0.035   | U    | mg F/L     | P392590  |          |
|           | EPA 350.1 Rev. 2.0           | Ammonia-N          | 0.009   |      | mg N/L     | P393205  |          |
|           | EPA 351.2 Rev. 2.0           | Kjeldahl Nitrogen  | 0.89    |      | mg N/L     | P393092  |          |
|           | EPA 353.2 Rev. 2.0           | NO2NO3-N           | 0.004   | U    | mg N/L     | P392741  |          |
|           | EPA 365.1 Rev. 2.0           | Total-P            | 0.011   |      | mg P/L     | P392719  |          |
| 2219754   | SM 5310 B-2011               | Organic Carbon     | 35      |      | mg C/L     | P392754  |          |
|           | EPA 365.1 Rev. 2.0 dissolved | O-Phosphate-P      | 0.004   | I    | mg P/L     | P392482  |          |
| 2219769   | EPA 8321B                    | 2,4-D              | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Acesulfame K**     | 0.10    | U    | ug/L       | P392508  | MS       |
|           |                              | AMPA**             | 0.10    | U    | ug/L       | P392508  |          |
|           |                              | Sucralose**        | 0.21    |      | ug/L       | P392508  |          |
|           |                              | Acetaminophen**    | 0.0080  | U    | ug/L       | P392593  |          |
|           |                              | Acetamiprid**      | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Endothall**        | 0.25    | U    | ug/L       | P392508  |          |
|           |                              | Glufosinate**      | 0.10    | U    | ug/L       | P392508  |          |
|           |                              | Glyphosate**       | 0.10    | U    | ug/L       | P392508  |          |
|           |                              | Afidopyropen**     | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Bentazon           | 8.0E-04 | U    | ug/L       | P392593  |          |
|           |                              | Benzovindiflupyr** | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Carbamazepine**    | 8.0E-04 | U    | ug/L       | P392593  |          |
|           |                              | Clothianidin**     | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Dinotefuran**      | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Diuron             | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Fenuron            | 0.016   | U    | ug/L       | P392593  |          |
|           |                              | Fluridone**        | 8.0E-04 | U    | ug/L       | P392593  |          |
|           |                              | Imazapyr**         | 0.25    |      | ug/L       | P392593  |          |
|           |                              | Hydrocodone**      | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Ibuprofen**        | 0.020   | U    | ug/L       | P392593  |          |
|           |                              | Imidacloprid       | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Linuron            | 0.0040  | U    | ug/L       | P392593  |          |
|           |                              | Mandestrobin**     | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | MCP                | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Naproxen**         | 0.0080  | U    | ug/L       | P392593  |          |
|           |                              | Primidone**        | 0.0040  | U    | ug/L       | P392593  |          |
|           |                              | Pyraclostrobin**   | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Thiamethoxam**     | 0.0020  | U    | ug/L       | P392593  |          |

Field ID: 19010105

Matrix: W-SURF-FRH

| Sample ID | Ref. Method | Component     | Result | Code | Units | Batch ID | QC Codes |
|-----------|-------------|---------------|--------|------|-------|----------|----------|
| 2219769   | EPA 8321B   | Tolfenpyrad** | 0.0020 | U    | ug/L  | P392593  |          |
|           |             | Triclopyr**   | 0.0040 | U    | ug/L  | P392593  |          |

Ref. Method and Comment:

SM 2540 D-2011: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

EPA 351.2 Rev. 2.0: Batch matrix spike recoveries are unavailable because of high analyte concentration in the QC sample.

Sample Location: Daughtery Br @ Crews Rd

Collection Date/Time: 01/14/2021 13:25

Field ID: 19010136

Matrix: W-SURF-FRH

| Sample ID | Ref. Method                  | Component          | Result  | Code | Units      | Batch ID | QC Codes |
|-----------|------------------------------|--------------------|---------|------|------------|----------|----------|
| 2219758   | EPA 180.1 Rev. 2.0           | Turbidity          | 2.9     |      | NTU        | P392476  |          |
|           | EPA 300.0 Rev. 2.1           | Chloride           | 13      |      | mg Cl/L    | P392734  |          |
|           |                              | Sulfate            | 0.86    |      | mg SO4/L   | P392736  |          |
|           | SM 2120 B-2011               | Color (true)       | 160     |      | PCU        | P392457  |          |
|           | SM 2320 B-2011               | Total Alkalinity   | 9.0     |      | mg CaCO3/L | P392588  |          |
|           | SM 2540 C-2011               | TDS                | 88      |      | mg/L       | P392811  |          |
|           | SM 2540 D-2011               | TSS                | 2       | U    | mg/L       | P392970  |          |
| 2219759   | SM 4500 F-C-2011             | Fluoride           | 0.056   | I    | mg F/L     | P392590  |          |
|           | EPA 350.1 Rev. 2.0           | Ammonia-N          | 0.018   |      | mg N/L     | P393205  |          |
|           | EPA 351.2 Rev. 2.0           | Kjeldahl Nitrogen  | 0.63    |      | mg N/L     | P393023  |          |
|           | EPA 353.2 Rev. 2.0           | NO2NO3-N           | 2.0     |      | mg N/L     | P392741  |          |
|           | EPA 365.1 Rev. 2.0           | Total-P            | 0.026   |      | mg P/L     | P392721  |          |
| 2219760   | SM 5310 B-2011               | Organic Carbon     | 16      |      | mg C/L     | P392754  |          |
|           | EPA 365.1 Rev. 2.0 dissolved | O-Phosphate-P      | 0.018   |      | mg P/L     | P392482  |          |
| 2219770   | EPA 8321B                    | 2,4-D              | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Acesulfame K**     | 0.10    | U    | ug/L       | P392508  | MS       |
|           |                              | AMPA**             | 0.10    | U    | ug/L       | P392508  |          |
|           |                              | Sucralose**        | 0.61    |      | ug/L       | P392508  |          |
|           |                              | Acetaminophen**    | 0.0080  | U    | ug/L       | P392593  |          |
|           |                              | Acetamiprid**      | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Endothall**        | 0.25    | U    | ug/L       | P392508  |          |
|           |                              | Glufosinate**      | 0.10    | U    | ug/L       | P392508  |          |
|           |                              | Glyphosate**       | 0.10    | U    | ug/L       | P392508  |          |
|           |                              | Afidopyropen**     | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Bentazon           | 8.0E-04 | U    | ug/L       | P392593  |          |
|           |                              | Benzovindiflupyr** | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Carbamazepine**    | 8.0E-04 | U    | ug/L       | P392593  |          |
|           |                              | Clothianidin**     | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Dinotefuran**      | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Diuron             | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Fenuron            | 0.016   | U    | ug/L       | P392593  |          |
|           |                              | Fluridone**        | 8.0E-04 | U    | ug/L       | P392593  |          |
|           |                              | Imazapyr**         | 0.34    |      | ug/L       | P392593  |          |
|           |                              | Hydrocodone**      | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Ibuprofen**        | 0.020   | U    | ug/L       | P392593  |          |
|           |                              | Imidacloprid       | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Linuron            | 0.0040  | U    | ug/L       | P392593  |          |
|           |                              | Mandestrobin**     | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | MCP                | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Naproxen**         | 0.0080  | U    | ug/L       | P392593  |          |
|           |                              | Primidone**        | 0.0040  | U    | ug/L       | P392593  |          |
|           |                              | Pyraclostrobin**   | 0.0020  | U    | ug/L       | P392593  |          |
|           |                              | Thiamethoxam**     | 0.0020  | U    | ug/L       | P392593  |          |

Field ID: 19010136

Matrix: W-SURF-FRH

| Sample ID | Ref. Method        | Component     | Result | Code | Units | Batch ID | QC Codes |
|-----------|--------------------|---------------|--------|------|-------|----------|----------|
| 2219770   | EPA 8321B          | Tolfenpyrad** | 0.0020 | U    | ug/L  | P392593  |          |
|           |                    | Triclopyr**   | 0.0040 | U    | ug/L  | P392593  |          |
| 2219772   | EPA 200.7 Rev. 4.4 | Barium        | 46.9   |      | ug/L  | P392543  |          |
|           |                    | Calcium       | 6.14   |      | mg/L  | P392543  |          |
|           |                    | Iron          | 620    |      | ug/L  | P392543  |          |
|           |                    | Magnesium     | 3.26   |      | mg/L  | P392543  |          |
|           |                    | Manganese     | 19.3   |      | ug/L  | P392543  |          |
|           |                    | Potassium     | 0.61   | I    | mg/L  | P392543  |          |
|           |                    | Sodium        | 7.7    |      | mg/L  | P392543  |          |
|           |                    | Zinc          | 8.2    | I    | ug/L  | P392543  |          |
|           | EPA 200.8 Rev. 5.4 | Aluminum      | 325    |      | ug/L  | P392543  |          |
|           |                    | Antimony      | 0.050  | U    | ug/L  | P392543  |          |
|           |                    | Arsenic       | 0.30   |      | ug/L  | P392543  |          |
|           |                    | Beryllium     | 0.082  |      | ug/L  | P392543  |          |
|           |                    | Boron**       | 14.2   |      | ug/L  | P392543  |          |
|           |                    | Cadmium       | 0.020  | U    | ug/L  | P392543  |          |
|           |                    | Chromium      | 0.69   | I    | ug/L  | P392543  |          |
|           |                    | Copper        | 0.40   | U    | ug/L  | P392543  |          |
|           |                    | Lead          | 0.36   | I    | ug/L  | P392543  |          |
|           |                    | Nickel        | 0.88   | I    | ug/L  | P392543  |          |
|           |                    | Selenium      | 0.20   | U    | ug/L  | P392543  |          |
|           |                    | Silver        | 0.010  | U    | ug/L  | P392543  |          |
|           |                    | Thallium      | 0.10   | U    | ug/L  | P392543  |          |
|           | SM 2340B           | Hardness      | 28.7   |      | mg/L  | P392543  |          |

Ref. Method and Comment:

SM 2540 D-2011: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

EPA 351.2 Rev. 2.0: Batch matrix spike recoveries and relative percent difference are unavailable because of analytical difficulties.

**Sample Location: Moccasin Creek @ Moccasin Creek Cir. E.**

**Collection Date/Time: 01/14/2021 12:30**

**Field ID: 19010121**

**Matrix: W-SURF-FRH**

| Sample ID | Ref. Method                  | Component         | Result | Code | Units      | Batch ID | QC Codes |
|-----------|------------------------------|-------------------|--------|------|------------|----------|----------|
| 2219755   | EPA 180.1 Rev. 2.0           | Turbidity         | 1.1    |      | NTU        | P392476  |          |
|           | EPA 300.0 Rev. 2.1           | Chloride          | 7.1    |      | mg Cl/L    | P392734  |          |
|           |                              | Sulfate           | 0.20   | U    | mg SO4/L   | P392736  |          |
|           | SM 2120 B-2011               | Color (true)      | 380    |      | PCU        | P392457  |          |
|           | SM 2320 B-2011               | Total Alkalinity  | 0.65   | U    | mg CaCO3/L | P392588  |          |
|           | SM 2540 C-2011               | TDS               | 92     |      | mg/L       | P392811  |          |
|           | SM 2540 D-2011               | TSS               | 2      | I    | mg/L       | P392970  |          |
|           | SM 4500 F-C-2011             | Fluoride          | 0.035  | U    | mg F/L     | P392590  |          |
|           | EPA 350.1 Rev. 2.0           | Ammonia-N         | 0.008  |      | mg N/L     | P393205  |          |
|           | EPA 351.2 Rev. 2.0           | Kjeldahl Nitrogen | 0.86   |      | mg N/L     | P393180  |          |
| 2219756   | EPA 353.2 Rev. 2.0           | NO2NO3-N          | 0.004  | U    | mg N/L     | P392741  |          |
|           | EPA 365.1 Rev. 2.0           | Total-P           | 0.007  |      | mg P/L     | P392721  |          |
|           | SM 5310 B-2011               | Organic Carbon    | 46     |      | mg C/L     | P392754  |          |
|           | EPA 365.1 Rev. 2.0           | O-Phosphate-P     | 0.004  | U    | mg P/L     | P392482  |          |
| 2219757   | EPA 365.1 Rev. 2.0 dissolved |                   |        |      |            |          |          |

Ref. Method and Comment:

SM 2540 D-2011: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

---

## Non-Conformance Report

**NCR ID: 8611**

| <u>Event(s)</u>       | <u>Job(s)</u>     | <u>Sample(s)</u> | <u>Test(s)</u> |
|-----------------------|-------------------|------------------|----------------|
| NE-DIST-2021-01-15-01 | TLH-2021-01-15-68 | 2219755          |                |
| NE-DIST-2021-01-15-01 | TLH-2021-01-15-68 | 2219758          |                |

**NCR Type: CUSTODY**

**NCR Category: General**

Observation: Control sensor malfunctioned in Refrigerator #4; temperature fell below normal operating range. Samples discovered frozen solid on 1/25/2021 @ 11:30.

Resolution: Refrigerator control sensor replaced.  
Chemistry supervisor was notified  
Data will be qualified as appropriate.

Authorized by/Date: Joshua Ayres 1/29/2021

---

The Non-Conformance Report details exceptions or problems encountered with the events/jobs/samples/test.  
Please address questions to:

|           |                |                |
|-----------|----------------|----------------|
| Chemistry | Colin Wright   | (850) 245-8085 |
| Biology   | Cheryl Swanson | (850) 245-8177 |

## Quality Assurance Report Method Blank Results

Reference Method: EPA 180.1 Rev. 2.0  
Batch ID: P392476

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| Turbidity | 0.10   | U    | NTU   |

Reference Method: EPA 200.7 Rev. 4.4  
Batch ID: P392543

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| Barium    | 1.0    | U    | ug/L  |
| Calcium   | 0.075  | U    | mg/L  |
| Iron      | 30     | U    | ug/L  |
| Magnesium | 0.040  | U    | mg/L  |
| Manganese | 1.0    | U    | ug/L  |
| Potassium | 0.30   | U    | mg/L  |
| Sodium    | 0.50   | U    | mg/L  |
| Zinc      | 5.0    | U    | ug/L  |

Reference Method: EPA 200.8 Rev. 5.4  
Batch ID: P392543

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| Aluminum  | 5.0    | U    | ug/L  |
| Antimony  | 0.050  | U    | ug/L  |
| Arsenic   | 0.050  | U    | ug/L  |
| Beryllium | 0.010  | U    | ug/L  |
| Boron     | 2.0    | U    | ug/L  |
| Cadmium   | 0.020  | U    | ug/L  |
| Chromium  | 0.40   | U    | ug/L  |
| Copper    | 0.40   | U    | ug/L  |
| Lead      | 0.20   | U    | ug/L  |
| Nickel    | 0.50   | U    | ug/L  |
| Selenium  | 0.20   | U    | ug/L  |
| Silver    | 0.010  | U    | ug/L  |
| Thallium  | 0.10   | U    | ug/L  |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P392734

| Component | Result | Code | Units   |
|-----------|--------|------|---------|
| Chloride  | 0.20   | U    | mg Cl/L |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P392736

| Component | Result | Code | Units    |
|-----------|--------|------|----------|
| Sulfate   | 0.20   | U    | mg SO4/L |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P393205

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Ammonia-N | 0.002  | U    | mg N/L |

## Quality Assurance Report

### Method Blank Results

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P393023

| Component         | Result | Code | Units  |
|-------------------|--------|------|--------|
| Kjeldahl Nitrogen | 0.080  | U    | mg N/L |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P393092

| Component         | Result | Code | Units  |
|-------------------|--------|------|--------|
| Kjeldahl Nitrogen | 0.080  | U    | mg N/L |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P393180

| Component         | Result | Code | Units  |
|-------------------|--------|------|--------|
| Kjeldahl Nitrogen | 0.080  | U    | mg N/L |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P392741

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| NO2NO3-N  | 0.004  | U    | mg N/L |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P392719

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Total-P   | 0.002  | U    | mg P/L |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P392721

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Total-P   | 0.002  | U    | mg P/L |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
Batch ID: P392482

| Component     | Result | Code | Units  |
|---------------|--------|------|--------|
| O-Phosphate-P | 0.004  | U    | mg P/L |

Reference Method: EPA 8321B  
Batch ID: P392508

| Component    | Result | Code | Units |
|--------------|--------|------|-------|
| Acesulfame K | 0.10   | U    | ug/L  |
| AMPA         | 0.10   | U    | ug/L  |
| Endothall    | 0.25   | U    | ug/L  |
| Glufosinate  | 0.10   | U    | ug/L  |
| Glyphosate   | 0.10   | U    | ug/L  |
| Sucralose    | 0.010  | U    | ug/L  |

## Quality Assurance Report Method Blank Results

Reference Method: EPA 8321B

Batch ID: P392593

| Component        | Result  | Code | Units |
|------------------|---------|------|-------|
| 2,4-D            | 0.0020  | U    | ug/L  |
| Acetaminophen    | 0.0080  | U    | ug/L  |
| Acetamiprid      | 0.0020  | U    | ug/L  |
| Afidopyropen     | 0.0020  | U    | ug/L  |
| Bentazon         | 8.0E-04 | U    | ug/L  |
| Benzovindiflupyr | 0.0020  | U    | ug/L  |
| Carbamazepine    | 8.0E-04 | U    | ug/L  |
| Clothianidin     | 0.0020  | U    | ug/L  |
| Dinotefuran      | 0.0020  | U    | ug/L  |
| Diuron           | 0.0020  | U    | ug/L  |
| Fenuron          | 0.016   | U    | ug/L  |
| Fluridone        | 8.0E-04 | U    | ug/L  |
| Hydrocodone      | 0.0020  | U    | ug/L  |
| Ibuprofen        | 0.020   | U    | ug/L  |
| Imazapyr         | 0.0040  | U    | ug/L  |
| Imidacloprid     | 0.0020  | U    | ug/L  |
| Linuron          | 0.0040  | U    | ug/L  |
| Mandestrobin     | 0.0020  | U    | ug/L  |
| MCPP             | 0.0020  | U    | ug/L  |
| Naproxen         | 0.0080  | U    | ug/L  |
| Primidone        | 0.0040  | U    | ug/L  |
| Pyraclostrobin   | 0.0020  | U    | ug/L  |
| Thiamethoxam     | 0.0020  | U    | ug/L  |
| Tolfenpyrad      | 0.0020  | U    | ug/L  |
| Triclopyr        | 0.0040  | U    | ug/L  |

Reference Method: SM 2120 B-2011

Batch ID: P392457

| Component    | Result | Code | Units |
|--------------|--------|------|-------|
| Color (true) | 2.5    | U    | PCU   |

Reference Method: SM 2320 B-2011

Batch ID: P392588

| Component        | Result | Code | Units      |
|------------------|--------|------|------------|
| Total Alkalinity | 0.65   | U    | mg CaCO3/L |

Reference Method: SM 2540 C-2011

Batch ID: P392811

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| TDS       | 15     | U    | mg/L  |

Reference Method: SM 2540 D-2011

Batch ID: P392970

| Component | Result | Code | Units |
|-----------|--------|------|-------|
| TSS       | 2      | U    | mg/L  |

## Quality Assurance Report

### Method Blank Results

Reference Method: SM 4500 F-C-2011  
Batch ID: P392590

| Component | Result | Code | Units  |
|-----------|--------|------|--------|
| Fluoride  | 0.035  | U    | mg F/L |

Reference Method: SM 5310 B-2011  
Batch ID: P392754

| Component      | Result | Code | Units  |
|----------------|--------|------|--------|
| Organic Carbon | 0.50   | U    | mg C/L |

## Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 200.7 Rev. 4.4  
Batch ID: P392543

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Barium    | 98.1    |         | P         | 85 - 115       |
| Calcium   | 104     |         | P         | 85 - 115       |
| Iron      | 104     |         | P         | 85 - 115       |
| Magnesium | 105     |         | P         | 85 - 115       |
| Manganese | 99.1    |         | P         | 85 - 115       |
| Potassium | 101     |         | P         | 85 - 115       |
| Sodium    | 103     |         | P         | 85 - 115       |
| Zinc      | 99.7    |         | P         | 85 - 115       |

Reference Method: EPA 200.8 Rev. 5.4  
Batch ID: P392543

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Aluminum  | 94.5    |         | P         | 85 - 115       |
| Antimony  | 98.7    |         | P         | 85 - 115       |
| Arsenic   | 95.2    |         | P         | 85 - 115       |
| Beryllium | 88.3    |         | P         | 85 - 115       |
| Boron     | 99.9    |         | P         | 85 - 115       |
| Cadmium   | 95.3    |         | P         | 85 - 115       |
| Chromium  | 101     |         | P         | 85 - 115       |
| Copper    | 92.5    |         | P         | 85 - 115       |
| Lead      | 97.5    |         | P         | 85 - 115       |
| Nickel    | 93.8    |         | P         | 85 - 115       |
| Selenium  | 94.8    |         | P         | 85 - 115       |
| Silver    | 102     |         | P         | 85 - 115       |
| Thallium  | 95.2    |         | P         | 85 - 115       |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P392734

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Chloride  | 100     |         | P         | 90 - 110       |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P392736

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Sulfate   | 102     |         | P         | 90 - 110       |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P393205

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Ammonia-N | 98.3    |         | P         | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P393023

| Component         | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-------------------|---------|---------|-----------|----------------|
| Kjeldahl Nitrogen | 109     |         | P         | 90 - 110       |

## Quality Assurance Report

### Laboratory Control Sample Accuracy

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P393092

| Component         | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-------------------|---------|---------|-----------|----------------|
| Kjeldahl Nitrogen | 97.8    |         | P         | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P393180

| Component         | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-------------------|---------|---------|-----------|----------------|
| Kjeldahl Nitrogen | 106     |         | P         | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P392741

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| NO2NO3-N  | 102     |         | P         | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P392719

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Total-P   | 104     |         | P         | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P392721

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Total-P   | 106     |         | P         | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
Batch ID: P392482

| Component     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------|---------|-----------|----------------|
| O-Phosphate-P | 103     |         | P         | 90 - 110       |

Reference Method: EPA 8321B  
Batch ID: P392508

| Component    | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|--------------|---------|---------|-----------|----------------|
| Acesulfame K | 77.5    |         | P         | 40 - 150       |
| AMPA         | 107     |         | P         | 40 - 150       |
| Endothall    | 97.1    |         | P         | 40 - 150       |
| Glufosinate  | 94.6    |         | P         | 40 - 150       |
| Glyphosate   | 102     |         | P         | 40 - 140       |
| Sucralose    | 95.3    |         | P         | 40 - 150       |

Reference Method: EPA 8321B  
Batch ID: P392593

| Component     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------|---------|-----------|----------------|
| 2,4-D         | 134     |         | P         | 30 - 160       |
| Acetaminophen | 65.9    |         | P         | 30 - 160       |
| Acetamiprid   | 101     |         | P         | 30 - 160       |
| Afidopyropen  | 80.1    |         | P         | 30 - 160       |
| Bentazon      | 88.3    |         | P         | 30 - 160       |

## Quality Assurance Report

### Laboratory Control Sample Accuracy

Reference Method: EPA 8321B

Batch ID: P392593

| Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|------------------|---------|---------|-----------|----------------|
| Benzovindiflupyr | 83.4    |         | P         | 30 - 160       |
| Carbamazepine    | 76.8    |         | P         | 30 - 160       |
| Clothianidin     | 102     |         | P         | 30 - 160       |
| Dinotefuran      | 95.1    |         | P         | 30 - 160       |
| Diuron           | 61.7    |         | P         | 30 - 160       |
| Fenuron          | 105     |         | P         | 30 - 160       |
| Fluridone        | 60.8    |         | P         | 30 - 160       |
| Hydrocodone      | 102     |         | P         | 30 - 160       |
| Ibuprofen        | 84.8    |         | P         | 30 - 160       |
| Imazapyr         | 105     |         | P         | 30 - 160       |
| Imidacloprid     | 100     |         | P         | 30 - 160       |
| Linuron          | 73.9    |         | P         | 30 - 160       |
| Mandestrobin     | 91.5    |         | P         | 30 - 160       |
| MCPP             | 112     |         | P         | 30 - 160       |
| Naproxen         | 61.5    |         | P         | 30 - 160       |
| Primidone        | 101     |         | P         | 30 - 160       |
| Pyraclostrobin   | 75.0    |         | P         | 30 - 160       |
| Thiamethoxam     | 92.1    |         | P         | 30 - 160       |
| Tolfenpyrad      | 52.7    |         | P         | 30 - 160       |
| Triclopyr        | 112     |         | P         | 30 - 160       |

Reference Method: SM 2120 B-2011

Batch ID: P392457

| Component    | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|--------------|---------|---------|-----------|----------------|
| Color (true) | 100     |         | P         | 85 - 115       |

Reference Method: SM 2320 B-2011

Batch ID: P392588

| Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|------------------|---------|---------|-----------|----------------|
| Total Alkalinity | 95.6    |         | P         | 93 - 104       |

Reference Method: SM 4500 F-C-2011

Batch ID: P392590

| Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|-----------|---------|---------|-----------|----------------|
| Fluoride  | 97.5    |         | P         | 90 - 106       |

Reference Method: SM 5310 B-2011

Batch ID: P392754

| Component      | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|----------------|---------|---------|-----------|----------------|
| Organic Carbon | 98.8    |         | P         | 85 - 115       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 200.7 Rev. 4.4

Batch ID: P392543

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2219536       | Barium    | 101     |         | P         | 80 - 120       |
| 2219536       | Calcium   | 106     |         | P         | 80 - 120       |
| 2219536       | Iron      | 105     |         | P         | 80 - 120       |
| 2219536       | Magnesium | 106     |         | P         | 80 - 120       |
| 2219536       | Manganese | 101     |         | P         | 80 - 120       |
| 2219536       | Potassium | 99.7    |         | P         | 80 - 120       |
| 2219536       | Sodium    | 103     |         | P         | 80 - 120       |
| 2219536       | Zinc      | 103     |         | P         | 80 - 120       |
| 2219539       | Barium    | 101     | 98.7    | P/P       | 80 - 120       |
| 2219539       | Calcium   | 103     |         | P         | 80 - 120       |
| 2219539       | Iron      | 107     | 106     | P/P       | 80 - 120       |
| 2219539       | Magnesium | 110     | 108     | P/P       | 80 - 120       |
| 2219539       | Manganese | 102     | 99.6    | P/P       | 80 - 120       |
| 2219539       | Potassium | 101     | 98.3    | P/P       | 80 - 120       |
| 2219539       | Sodium    | 101     |         | P         | 80 - 120       |
| 2219539       | Zinc      | 109     | 106     | P/P       | 80 - 120       |

Reference Method: EPA 200.8 Rev. 5.4

Batch ID: P392543

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2219536       | Aluminum  | 93.4    |         | P         | 80 - 120       |
| 2219536       | Antimony  | 98.5    |         | P         | 80 - 120       |
| 2219536       | Arsenic   | 93.0    |         | P         | 80 - 120       |
| 2219536       | Beryllium | 86.4    |         | P         | 80 - 120       |
| 2219536       | Boron     | 97.7    |         | P         | 80 - 120       |
| 2219536       | Cadmium   | 93.6    |         | P         | 80 - 120       |
| 2219536       | Chromium  | 101     |         | P         | 80 - 120       |
| 2219536       | Copper    | 92.0    |         | P         | 80 - 120       |
| 2219536       | Lead      | 98.8    |         | P         | 80 - 120       |
| 2219536       | Nickel    | 93.3    |         | P         | 80 - 120       |
| 2219536       | Selenium  | 91.1    |         | P         | 80 - 120       |
| 2219536       | Silver    | 102     |         | P         | 80 - 120       |
| 2219536       | Thallium  | 96.5    |         | P         | 80 - 120       |
| 2219539       | Aluminum  | 93.3    | 94.8    | P/P       | 80 - 120       |
| 2219539       | Antimony  | 98.7    | 98.4    | P/P       | 80 - 120       |
| 2219539       | Arsenic   | 93.1    | 93.3    | P/P       | 80 - 120       |
| 2219539       | Beryllium | 89.8    | 87.9    | P/P       | 80 - 120       |
| 2219539       | Boron     | 98.5    | 99.2    | P/P       | 80 - 120       |
| 2219539       | Cadmium   | 91.0    | 91.5    | P/P       | 80 - 120       |
| 2219539       | Chromium  | 99.0    | 99.7    | P/P       | 80 - 120       |
| 2219539       | Copper    | 93.0    | 92.5    | P/P       | 80 - 120       |
| 2219539       | Lead      | 99.0    | 97.9    | P/P       | 80 - 120       |
| 2219539       | Nickel    | 93.5    | 93.0    | P/P       | 80 - 120       |
| 2219539       | Selenium  | 91.3    | 90.4    | P/P       | 80 - 120       |
| 2219539       | Silver    | 103     | 102     | P/P       | 80 - 120       |
| 2219539       | Thallium  | 96.7    | 96.8    | P/P       | 80 - 120       |

Reference Method: EPA 300.0 Rev. 2.1

Batch ID: P392734

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
|---------------|-----------|---------|---------|-----------|----------------|

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P392734

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2219600       | Chloride  | 99.0    |         | P         | 90 - 110       |
| 2219939       | Chloride  | 99.5    |         | P         | 90 - 110       |

Reference Method: EPA 300.0 Rev. 2.1  
Batch ID: P392736

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2219600       | Sulfate   | 103     |         | P         | 90 - 110       |
| 2219939       | Sulfate   | 99.4    |         | P         | 90 - 110       |

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P393205

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2219920       | Ammonia-N | 99.2    | 101     | P/P       | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P393180

| Spiked Sample | Component         | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-------------------|---------|---------|-----------|----------------|
| 2220706       | Kjeldahl Nitrogen | 105     | 103     | P/P       | 90 - 110       |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P392741

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2219601       | NO2NO3-N  | 98.4    | 99.4    | P/P       | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P392719

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2219723       | Total-P   | 106     | 105     | P/P       | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P392721

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2219943       | Total-P   | 104     | 105     | P/P       | 90 - 110       |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
Batch ID: P392482

| Spiked Sample | Component     | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|---------------|---------|---------|-----------|----------------|
| 2219683       | O-Phosphate-P | 93.7    | 96.0    | P/P       | 90 - 110       |

Reference Method: EPA 8321B  
Batch ID: P392508

| Spiked Sample | Component    | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|--------------|---------|---------|-----------|----------------|
| 2219257       | Acesulfame K | 30.0    | 39.7    | F/F       | 40 - 150       |
| 2219257       | AMPA         | 73.8    | 98.7    | P/P       | 40 - 150       |

## Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8321B  
Batch ID: P392508

| Spiked Sample | Component   | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-------------|---------|---------|-----------|----------------|
| 2219257       | Endothall   | 68.1    | 87.7    | P/P       | 40 - 150       |
| 2219257       | Glufosinate | 60.7    | 82.1    | P/P       | 40 - 150       |
| 2219257       | Glyphosate  | 64.4    | 81.9    | P/P       | 40 - 140       |
| 2219257       | Sucralose   | 71.8    | 80.1    | P/P       | 40 - 150       |

Reference Method: EPA 8321B  
Batch ID: P392593

| Spiked Sample | Component        | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|------------------|---------|---------|-----------|----------------|
| 2219578       | 2,4-D            | 131     | 129     | P/P       | 30 - 160       |
| 2219578       | Acetaminophen    | 86.3    | 90.5    | P/P       | 30 - 160       |
| 2219578       | Acetamiprid      | 114     | 107     | P/P       | 30 - 160       |
| 2219578       | Afidopyropen     | 86.2    | 92.5    | P/P       | 30 - 160       |
| 2219578       | Bentazon         | 86.9    | 83.5    | P/P       | 30 - 160       |
| 2219578       | Benzovindiflupyr | 85.7    | 84.3    | P/P       | 30 - 160       |
| 2219578       | Carbamazepine    | 82.1    | 82.4    | P/P       | 30 - 160       |
| 2219578       | Clothianidin     | 99.1    | 93.0    | P/P       | 30 - 160       |
| 2219578       | Dinotefuran      | 109     | 95.7    | P/P       | 30 - 160       |
| 2219578       | Diuron           | 59.9    | 64.7    | P/P       | 30 - 160       |
| 2219578       | Fenuron          | 86.0    | 95.1    | P/P       | 30 - 160       |
| 2219578       | Fluridone        | 83.9    | 71.5    | P/P       | 30 - 160       |
| 2219578       | Hydrocodone      | 106     | 106     | P/P       | 30 - 160       |
| 2219578       | Ibuprofen        | 86.7    | 98.7    | P/P       | 30 - 160       |
| 2219578       | Imazapyr         | 132     | 111     | P/P       | 30 - 160       |
| 2219578       | Imidacloprid     | 130     | 121     | P/P       | 30 - 160       |
| 2219578       | Linuron          | 70.4    | 65.5    | P/P       | 30 - 160       |
| 2219578       | Mandestrobin     | 89.6    | 90.6    | P/P       | 30 - 160       |
| 2219578       | MCPP             | 119     | 109     | P/P       | 30 - 160       |
| 2219578       | Naproxen         | 76.5    | 79.8    | P/P       | 30 - 160       |
| 2219578       | Primidone        | 91.1    | 82.1    | P/P       | 30 - 160       |
| 2219578       | Pyraclostrobin   | 75.0    | 69.6    | P/P       | 30 - 160       |
| 2219578       | Thiamethoxam     | 105     | 98.3    | P/P       | 30 - 160       |
| 2219578       | Tolfenpyrad      | 58.5    | 52.1    | P/P       | 30 - 160       |
| 2219578       | Triclopyr        | 114     | 120     | P/P       | 30 - 160       |

Reference Method: SM 4500 F-C-2011  
Batch ID: P392590

| Spiked Sample | Component | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|-----------|---------|---------|-----------|----------------|
| 2219336       | Fluoride  | 97.9    | 97.9    | P/P       | 94 - 107       |

Reference Method: SM 5310 B-2011  
Batch ID: P392754

| Spiked Sample | Component      | % Rec.1 | % Rec.2 | Pass/Fail | Control Limits |
|---------------|----------------|---------|---------|-----------|----------------|
| 2219759       | Organic Carbon | 102     | 104     | P/P       | 85 - 115       |

## Quality Assurance Report Precision

Reference Method: EPA 180.1 Rev. 2.0

Batch ID: P392476

Replicated

| Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|-----------|-----------|-------------------|-----------|----------------|
| 2219752    | Turbidity | 0.832     | Sample            | P         | 0 - 20         |

Reference Method: EPA 200.7 Rev. 4.4

Batch ID: P392543

Replicated

| Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|-----------|-----------|-------------------|-----------|----------------|
| 2219539    | Barium    | 2.38      | Spike             | P         | 0 - 20         |
| 2219539    | Calcium   | 1.24      | Spike             | P         | 0 - 20         |
| 2219539    | Iron      | 0.302     | Spike             | P         | 0 - 20         |
| 2219539    | Magnesium | 1.11      | Spike             | P         | 0 - 20         |
| 2219539    | Manganese | 2.28      | Spike             | P         | 0 - 20         |
| 2219539    | Potassium | 2.70      | Spike             | P         | 0 - 20         |
| 2219539    | Sodium    | 2.92      | Spike             | P         | 0 - 20         |
| 2219539    | Zinc      | 1.97      | Spike             | P         | 0 - 20         |

Reference Method: EPA 200.8 Rev. 5.4

Batch ID: P392543

Replicated

| Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|-----------|-----------|-------------------|-----------|----------------|
| 2219539    | Aluminum  | 1.50      | Spike             | P         | 0 - 20         |
| 2219539    | Antimony  | 0.356     | Spike             | P         | 0 - 20         |
| 2219539    | Arsenic   | 0.174     | Spike             | P         | 0 - 20         |
| 2219539    | Beryllium | 2.07      | Spike             | P         | 0 - 20         |
| 2219539    | Boron     | 0.655     | Spike             | P         | 0 - 20         |
| 2219539    | Cadmium   | 0.550     | Spike             | P         | 0 - 20         |
| 2219539    | Chromium  | 0.790     | Spike             | P         | 0 - 20         |
| 2219539    | Copper    | 0.574     | Spike             | P         | 0 - 20         |
| 2219539    | Lead      | 1.09      | Spike             | P         | 0 - 20         |
| 2219539    | Nickel    | 0.461     | Spike             | P         | 0 - 20         |
| 2219539    | Selenium  | 0.926     | Spike             | P         | 0 - 20         |
| 2219539    | Silver    | 1.26      | Spike             | P         | 0 - 20         |
| 2219539    | Thallium  | 0.0904    | Spike             | P         | 0 - 20         |

Reference Method: EPA 300.0 Rev. 2.1

Batch ID: P392734

Replicated

| Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|-----------|-----------|-------------------|-----------|----------------|
| 2219600    | Chloride  | 0.782     | Sample            | P         | 0 - 20         |

Reference Method: EPA 300.0 Rev. 2.1

Batch ID: P392736

Replicated

| Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|------------|-----------|-----------|-------------------|-----------|----------------|
| 2219600    | Sulfate   | 1.13      | Sample            | P         | 0 - 20         |

## Quality Assurance Report Precision

Reference Method: EPA 350.1 Rev. 2.0  
Batch ID: P393205

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2219920                  | Ammonia-N | 1.72      | Spike             | P         | 0 - 20         |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P393092

| Replicated<br>Lab Sample | Component         | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-------------------|-----------|-------------------|-----------|----------------|
| 2220014                  | Kjeldahl Nitrogen | 0.479     | Spike             | P         | 0 - 20         |

Reference Method: EPA 351.2 Rev. 2.0  
Batch ID: P393180

| Replicated<br>Lab Sample | Component         | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-------------------|-----------|-------------------|-----------|----------------|
| 2220706                  | Kjeldahl Nitrogen | 0.736     | Spike             | P         | 0 - 20         |

Reference Method: EPA 353.2 Rev. 2.0  
Batch ID: P392741

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2219601                  | NO2NO3-N  | 0.803     | Spike             | P         | 0 - 20         |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P392719

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2219723                  | Total-P   | 1.39      | Spike             | P         | 0 - 20         |

Reference Method: EPA 365.1 Rev. 2.0  
Batch ID: P392721

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2219943                  | Total-P   | 1.12      | Spike             | P         | 0 - 20         |

Reference Method: EPA 365.1 Rev. 2.0 dissolved  
Batch ID: P392482

| Replicated<br>Lab Sample | Component     | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|---------------|-----------|-------------------|-----------|----------------|
| 2219683                  | O-Phosphate-P | 2.12      | Spike             | P         | 0 - 20         |

Reference Method: EPA 8321B  
Batch ID: P392508

| Replicated<br>Lab Sample | Component    | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|--------------|-----------|-------------------|-----------|----------------|
| 2219257                  | Acesulfame K | 27.8      | Spike             | P         | 0 - 30         |
| 2219257                  | AMPA         | 28.9      | Spike             | P         | 0 - 30         |

## Quality Assurance Report Precision

Reference Method: EPA 8321B  
Batch ID: P392508

| Replicated<br>Lab Sample | Component   | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-------------|-----------|-------------------|-----------|----------------|
| 2219257                  | Endothall   | 25.2      | Spike             | P         | 0 - 30         |
| 2219257                  | Glufosinate | 29.9      | Spike             | P         | 0 - 30         |
| 2219257                  | Glyphosate  | 24.0      | Spike             | P         | 0 - 30         |
| 2219257                  | Sucralose   | 2.47      | Spike             | P         | 0 - 30         |

Reference Method: EPA 8321B  
Batch ID: P392593

| Replicated<br>Lab Sample | Component        | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|------------------|-----------|-------------------|-----------|----------------|
| 2219578                  | 2,4-D            | 1.65      | Spike             | P         | 0 - 30         |
| 2219578                  | Acetaminophen    | 4.72      | Spike             | P         | 0 - 30         |
| 2219578                  | Acetamiprid      | 6.22      | Spike             | P         | 0 - 30         |
| 2219578                  | Afidopyropen     | 7.06      | Spike             | P         | 0 - 30         |
| 2219578                  | Bentazon         | 3.28      | Spike             | P         | 0 - 30         |
| 2219578                  | Benzovindiflupyr | 1.66      | Spike             | P         | 0 - 30         |
| 2219578                  | Carbamazepine    | 0.306     | Spike             | P         | 0 - 30         |
| 2219578                  | Clothianidin     | 6.28      | Spike             | P         | 0 - 30         |
| 2219578                  | Dinotefuran      | 12.6      | Spike             | P         | 0 - 30         |
| 2219578                  | Diuron           | 7.67      | Spike             | P         | 0 - 30         |
| 2219578                  | Fenuron          | 10.0      | Spike             | P         | 0 - 30         |
| 2219578                  | Fluridone        | 16.0      | Spike             | P         | 0 - 30         |
| 2219578                  | Hydrocodone      | 0.251     | Spike             | P         | 0 - 30         |
| 2219578                  | Ibuprofen        | 12.9      | Spike             | P         | 0 - 30         |
| 2219578                  | Imazapyr         | 16.2      | Spike             | P         | 0 - 30         |
| 2219578                  | Imidacloprid     | 6.96      | Spike             | P         | 0 - 30         |
| 2219578                  | Linuron          | 7.19      | Spike             | P         | 0 - 30         |
| 2219578                  | Mandestrobin     | 1.08      | Spike             | P         | 0 - 30         |
| 2219578                  | MCP              | 8.66      | Spike             | P         | 0 - 30         |
| 2219578                  | Naproxen         | 4.21      | Spike             | P         | 0 - 30         |
| 2219578                  | Primidone        | 10.4      | Spike             | P         | 0 - 30         |
| 2219578                  | Pyraclostrobin   | 7.47      | Spike             | P         | 0 - 30         |
| 2219578                  | Thiamethoxam     | 6.18      | Spike             | P         | 0 - 30         |
| 2219578                  | Tolfenpyrad      | 11.5      | Spike             | P         | 0 - 30         |
| 2219578                  | Triclopyr        | 5.41      | Spike             | P         | 0 - 30         |

Reference Method: SM 2120 B-2011  
Batch ID: P392457

| Replicated<br>Lab Sample | Component    | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|--------------|-----------|-------------------|-----------|----------------|
| 2219600                  | Color (true) | 0.326     | Sample            | P         | 0 - 20         |

Reference Method: SM 2320 B-2011  
Batch ID: P392588

| Replicated<br>Lab Sample | Component        | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|------------------|-----------|-------------------|-----------|----------------|
| 2219336                  | Total Alkalinity | 0.582     | Sample            | P         | 0 - 8.1        |

## Quality Assurance Report Precision

Reference Method: SM 2540 C-2011  
Batch ID: P392811

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2219600                  | TDS       | 3.66      | Sample            | P         | 0 - 10         |

Reference Method: SM 4500 F-C-2011  
Batch ID: P392590

| Replicated<br>Lab Sample | Component | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|-----------|-----------|-------------------|-----------|----------------|
| 2219336                  | Fluoride  | 0.0       | Spike             | P         | 0 - 2.8        |

Reference Method: SM 5310 B-2011  
Batch ID: P392754

| Replicated<br>Lab Sample | Component      | % RSD/RPD | Sample/Spike/LCS* | Pass/Fail | Control Limits |
|--------------------------|----------------|-----------|-------------------|-----------|----------------|
| 2219759                  | Organic Carbon | 1.08      | Spike             | P         | 0 - 20         |

\* Sample, spike and/or laboratory control sample precision (LCS) is reported.

## Quality Assurance Report Surrogates

Lab Sample ID: 2219769

Field Sample ID: 19010105

| Reference Method | Surrogate          | % Rec. | Pass/Fail | Control Limits |
|------------------|--------------------|--------|-----------|----------------|
| EPA 8321B        | 2,4-D-d3           | 65.5   | P         | 30 - 160       |
| EPA 8321B        | Acetaminophen-d4   | 57.7   | P         | 30 - 160       |
| EPA 8321B        | Carbamazepine-d10  | 42.2   | P         | 30 - 160       |
| EPA 8321B        | Diuron-d6          | 31.9   | P         | 30 - 160       |
| EPA 8321B        | Endothall-d6       | 93.7   | P         | 40 - 160       |
| EPA 8321B        | Endothall-d6       | 93.7   | P         | 40 - 160       |
| EPA 8321B        | Glyphosate 13C 15N | 45.4   | P         | 40 - 160       |
| EPA 8321B        | Glyphosate 13C 15N | 45.4   | P         | 40 - 160       |
| EPA 8321B        | Ibuprofen-d3       | 83.5   | P         | 30 - 160       |
| EPA 8321B        | Primidone-d5       | 38.3   | P         | 30 - 160       |
| EPA 8321B        | Sucralose-d6       | 83.9   | P         | 30 - 160       |
| EPA 8321B        | Sucralose-d6       | 83.9   | P         | 30 - 160       |

Lab Sample ID: 2219770

Field Sample ID: 19010136

| Reference Method | Surrogate          | % Rec. | Pass/Fail | Control Limits |
|------------------|--------------------|--------|-----------|----------------|
| EPA 8321B        | 2,4-D-d3           | 89.6   | P         | 30 - 160       |
| EPA 8321B        | Acetaminophen-d4   | 91.1   | P         | 30 - 160       |
| EPA 8321B        | Carbamazepine-d10  | 55.7   | P         | 30 - 160       |
| EPA 8321B        | Diuron-d6          | 44.4   | P         | 30 - 160       |
| EPA 8321B        | Endothall-d6       | 96.1   | P         | 40 - 160       |
| EPA 8321B        | Endothall-d6       | 96.1   | P         | 40 - 160       |
| EPA 8321B        | Glyphosate 13C 15N | 59.7   | P         | 40 - 160       |
| EPA 8321B        | Glyphosate 13C 15N | 59.7   | P         | 40 - 160       |
| EPA 8321B        | Ibuprofen-d3       | 89.0   | P         | 30 - 160       |
| EPA 8321B        | Primidone-d5       | 62.7   | P         | 30 - 160       |
| EPA 8321B        | Sucralose-d6       | 109    | P         | 30 - 160       |
| EPA 8321B        | Sucralose-d6       | 109    | P         | 30 - 160       |

Lab Sample ID: 2219771

Field Sample ID: 19010076

| Reference Method | Surrogate          | % Rec. | Pass/Fail | Control Limits |
|------------------|--------------------|--------|-----------|----------------|
| EPA 8321B        | 2,4-D-d3           | 73.4   | P         | 30 - 160       |
| EPA 8321B        | Acetaminophen-d4   | 64.4   | P         | 30 - 160       |
| EPA 8321B        | Carbamazepine-d10  | 46.4   | P         | 30 - 160       |
| EPA 8321B        | Diuron-d6          | 39.2   | P         | 30 - 160       |
| EPA 8321B        | Endothall-d6       | 95.5   | P         | 40 - 160       |
| EPA 8321B        | Endothall-d6       | 95.5   | P         | 40 - 160       |
| EPA 8321B        | Glyphosate 13C 15N | 60.8   | P         | 40 - 160       |
| EPA 8321B        | Glyphosate 13C 15N | 60.8   | P         | 40 - 160       |
| EPA 8321B        | Ibuprofen-d3       | 84.1   | P         | 30 - 160       |
| EPA 8321B        | Primidone-d5       | 47.7   | P         | 30 - 160       |
| EPA 8321B        | Sucralose-d6       | 98.4   | P         | 30 - 160       |
| EPA 8321B        | Sucralose-d6       | 98.4   | P         | 30 - 160       |

## Quality Assurance Report Calibration Verification

Reference Method: SM 2120 B-2011

Run ID: A103088

Included Lab Sample IDs: 2219752, 2219755, 2219758

| Component    | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------|---------|---------|------------|----------------|
| Color (true) | 97.1    | 103     | P/P        | 90 - 115       |
| Color (true) | 99.7    | 97.1    | P/P        | 90 - 115       |

Reference Method: EPA 180.1 Rev. 2.0

Run ID: A103090

Included Lab Sample IDs: 2219752, 2219755, 2219758

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Turbidity | 102     | 102     | P/P        | 95 - 105       |

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Run ID: A103092

Included Lab Sample IDs: 2219754, 2219757, 2219760

| Component     | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|---------------|---------|---------|------------|----------------|
| O-Phosphate-P | 99.2    | 97.1    | P/P        | 90 - 110       |

Reference Method: SM 2320 B-2011

Run ID: A103130

Included Lab Sample IDs: 2219752, 2219755, 2219758

| Component        | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|------------------|---------|---------|------------|----------------|
| Total Alkalinity | 96.2    | 93.2    | P/P        | 90 - 110       |

Reference Method: SM 4500 F-C-2011

Run ID: A103130

Included Lab Sample IDs: 2219752, 2219755, 2219758

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Fluoride  | 98.1    | 102     | P/P        | 90 - 110       |

Reference Method: EPA 200.7 Rev. 4.4

Run ID: A103146

Included Lab Sample IDs: 2219772, 2219773

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Barium    | 97.8    | 98.5    | P/P        | 90 - 110       |
| Calcium   | 101     | 99.7    | P/P        | 90 - 110       |
| Iron      | 102     | 98.8    | P/P        | 90 - 110       |
| Magnesium | 102     | 99.6    | P/P        | 90 - 110       |
| Manganese | 101     | 101     | P/P        | 90 - 110       |
| Potassium | 98.7    | 96.3    | P/P        | 90 - 110       |
| Sodium    | 101     | 100     | P/P        | 90 - 110       |
| Zinc      | 105     | 107     | P/P        | 90 - 110       |

Reference Method: EPA 300.0 Rev. 2.1

Run ID: A103154

Included Lab Sample IDs: 2219752, 2219755, 2219758

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Chloride  | 100     | 99.6    | P/P        | 90 - 110       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 300.0 Rev. 2.1

Run ID: A103154

Included Lab Sample IDs: 2219752, 2219755, 2219758

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Sulfate   | 101     | 99.9    | P/P        | 90 - 110       |

Reference Method: EPA 8321B

Run ID: A103179

Included Lab Sample IDs: 2219769, 2219770, 2219771

| Component    | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|--------------|---------|---------|------------|----------------|
| Acesulfame K | 63.0    | 62.6    | P/P        | 60 - 160       |
| AMPA         | 95.2    | 97.7    | P/P        | 60 - 160       |
| Endothall    | 97.6    | 96.9    | P/P        | 60 - 160       |
| Glufosinate  | 86.2    | 98.6    | P/P        | 60 - 160       |
| Glyphosate   | 99.3    | 76.5    | P/P        | 60 - 160       |

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A103180

Included Lab Sample IDs: 2219753, 2219756, 2219759

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| NO2NO3-N  | 100     | 100     | P/P        | 90 - 110       |
| NO2NO3-N  | 100     | 100     | P/P        | 90 - 110       |

Reference Method: SM 5310 B-2011

Run ID: A103188

Included Lab Sample IDs: 2219753, 2219756, 2219759

| Component      | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|----------------|---------|---------|------------|----------------|
| Organic Carbon | 103     | 102     | P/P        | 90 - 110       |
| Organic Carbon | 99.5    | 103     | P/P        | 90 - 110       |

Reference Method: EPA 8321B

Run ID: A103189

Included Lab Sample IDs: 2219769, 2219770, 2219771

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Sucralose | 93.0    | 98.2    | P/P        | 60 - 160       |

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A103218

Included Lab Sample IDs: 2219753, 2219756, 2219759

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Total-P   | 94.0    | 97.5    | P/P        | 90 - 110       |
| Total-P   | 96.2    | 94.0    | P/P        | 90 - 110       |

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A103222

Included Lab Sample IDs: 2219772, 2219773

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Aluminum  | 97.2    | 97.0    | P/P        | 90 - 110       |
| Antimony  | 98.5    | 97.7    | P/P        | 90 - 110       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A103222

Included Lab Sample IDs: 2219772, 2219773

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Arsenic   | 96.3    | 94.4    | P/P        | 90 - 110       |
| Beryllium | 92.0    | 90.4    | P/P        | 90 - 110       |
| Boron     | 106     | 108     | P/P        | 90 - 110       |
| Chromium  | 102     | 102     | P/P        | 90 - 110       |
| Copper    | 95.0    | 93.9    | P/P        | 90 - 110       |
| Lead      | 98.8    | 98.2    | P/P        | 90 - 110       |
| Nickel    | 94.7    | 94.2    | P/P        | 90 - 110       |
| Selenium  | 95.8    | 95.3    | P/P        | 90 - 110       |
| Silver    | 104     | 104     | P/P        | 90 - 110       |
| Thallium  | 101     | 99.9    | P/P        | 90 - 110       |

Reference Method: EPA 8321B

Run ID: A103235

Included Lab Sample IDs: 2219769, 2219770, 2219771

| Component        | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|------------------|---------|---------|------------|----------------|
| 2,4-D            | 112     | 117     | P/P        | 50 - 150       |
| Acetaminophen    | 111     | 112     | P/P        | 60 - 160       |
| Acetamiprid      | 117     | 114     | P/P        | 50 - 150       |
| Afidopyropen     | 118     | 112     | P/P        | 50 - 150       |
| Bentazon         | 142     | 143     | P/P        | 50 - 160       |
| Benzovindiflupyr | 113     | 116     | P/P        | 50 - 160       |
| Carbamazepine    | 105     | 115     | P/P        | 60 - 150       |
| Clothianidin     | 113     | 99.8    | P/P        | 60 - 150       |
| Dinotefuran      | 121     | 110     | P/P        | 50 - 150       |
| Diuron           | 120     | 130     | P/P        | 60 - 160       |
| Fenuron          | 119     | 113     | P/P        | 60 - 150       |
| Fluridone        | 131     | 125     | P/P        | 60 - 160       |
| Hydrocodone      | 124     | 111     | P/P        | 60 - 150       |
| Ibuprofen        | 100     | 105     | P/P        | 50 - 160       |
| Imazapyr         | 99.1    | 110     | P/P        | 50 - 160       |
| Imidacloprid     | 103     | 99.7    | P/P        | 60 - 150       |
| Linuron          | 113     | 115     | P/P        | 60 - 150       |
| Mandestrobin     | 115     | 120     | P/P        | 50 - 150       |
| MCPP             | 123     | 112     | P/P        | 50 - 150       |
| Naproxen         | 125     | 152     | P/P        | 50 - 160       |
| Primidone        | 88.5    | 96.9    | P/P        | 60 - 150       |
| Pyraclostrobin   | 103     | 113     | P/P        | 60 - 150       |
| Thiamethoxam     | 123     | 110     | P/P        | 50 - 150       |
| Tolfenpyrad      | 119     | 122     | P/P        | 60 - 150       |
| Triclopyr        | 119     | 104     | P/P        | 50 - 150       |

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A103250

Included Lab Sample IDs: 2219772, 2219773

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Cadmium   | 93.1    | 93.9    | P/P        | 90 - 110       |
| Cadmium   | 95.2    | 93.1    | P/P        | 90 - 110       |

## Quality Assurance Report Calibration Verification

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A103294

Included Lab Sample IDs: 2219759

| Component         | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-------------------|---------|---------|------------|----------------|
| Kjeldahl Nitrogen | 99.6    | 100     | P/P        | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A103322

Included Lab Sample IDs: 2219753

| Component         | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-------------------|---------|---------|------------|----------------|
| Kjeldahl Nitrogen | 99.2    | 96.2    | P/P        | 90 - 110       |

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A103348

Included Lab Sample IDs: 2219753, 2219756, 2219759

| Component | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-----------|---------|---------|------------|----------------|
| Ammonia-N | 101     | 93.0    | P/P        | 90 - 110       |

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A103356

Included Lab Sample IDs: 2219756

| Component         | % Rec.1 | % Rec.2 | Pass/Fail* | Control Limits |
|-------------------|---------|---------|------------|----------------|
| Kjeldahl Nitrogen | 97.7    | 99.8    | P/P        | 90 - 110       |

\* Pass/Fail determinations are made for each bracketing calibration verification check.

Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.

Where they are different, both control limits are provided.

## Quality Assurance Report Summary

| Ref. Method                  | Analyte           | LCS % Recovery | MS % Recovery |      |      | LCS | Precision<br>SMP | MS     |
|------------------------------|-------------------|----------------|---------------|------|------|-----|------------------|--------|
| EPA 180.1 Rev. 2.0           | Turbidity         |                |               |      |      |     | 0.832            |        |
| EPA 200.7 Rev. 4.4           | Barium            | 98.1           | 101           | 101  | 98.7 |     |                  | 2.38   |
|                              | Calcium           | 104            | 106           | 103  |      |     |                  | 1.24   |
|                              | Iron              | 104            | 105           | 107  | 106  |     |                  | 0.302  |
|                              | Magnesium         | 105            | 106           | 110  | 108  |     |                  | 1.11   |
|                              | Manganese         | 99.1           | 101           | 102  | 99.6 |     |                  | 2.28   |
|                              | Potassium         | 101            | 99.7          | 101  | 98.3 |     |                  | 2.70   |
|                              | Sodium            | 103            | 103           | 101  |      |     |                  | 2.92   |
|                              | Zinc              | 99.7           | 103           | 109  | 106  |     |                  | 1.97   |
| EPA 200.8 Rev. 5.4           | Aluminum          | 94.5           | 93.3          | 94.8 | 93.4 |     |                  | 1.50   |
|                              | Antimony          | 98.7           | 98.7          | 98.4 | 98.5 |     |                  | 0.356  |
|                              | Arsenic           | 95.2           | 93.1          | 93.3 | 93.0 |     |                  | 0.174  |
|                              | Beryllium         | 88.3           | 89.8          | 87.9 | 86.4 |     |                  | 2.07   |
|                              | Boron             | 99.9           | 98.5          | 99.2 | 97.7 |     |                  | 0.655  |
|                              | Cadmium           | 95.3           | 91.0          | 91.5 | 93.6 |     |                  | 0.550  |
|                              | Chromium          | 101            | 99.0          | 99.7 | 101  |     |                  | 0.790  |
|                              | Copper            | 92.5           | 93.0          | 92.5 | 92.0 |     |                  | 0.574  |
|                              | Lead              | 97.5           | 99.0          | 97.9 | 98.8 |     |                  | 1.09   |
|                              | Nickel            | 93.8           | 93.5          | 93.0 | 93.3 |     |                  | 0.461  |
|                              | Selenium          | 94.8           | 91.3          | 90.4 | 91.1 |     |                  | 0.926  |
|                              | Silver            | 102            | 103           | 102  | 102  |     |                  | 1.26   |
|                              | Thallium          | 95.2           | 96.7          | 96.8 | 96.5 |     |                  | 0.0904 |
| EPA 300.0 Rev. 2.1           | Chloride          | 100            | 99.0          | 99.5 |      |     | 0.782            |        |
|                              | Sulfate           | 102            | 103           | 99.4 |      |     | 1.13             |        |
| EPA 350.1 Rev. 2.0           | Ammonia-N         | 98.3           | 99.2          | 101  |      |     |                  | 1.72   |
| EPA 351.2 Rev. 2.0           | Kjeldahl Nitrogen | 109            |               |      |      |     |                  |        |
|                              | Kjeldahl Nitrogen | 97.8           |               |      |      |     |                  | 0.479  |
|                              | Kjeldahl Nitrogen | 106            | 105           | 103  |      |     |                  | 0.736  |
| EPA 353.2 Rev. 2.0           | NO2NO3-N          | 102            | 98.4          | 99.4 |      |     |                  | 0.803  |
| EPA 365.1 Rev. 2.0           | Total-P           | 104            | 106           | 105  |      |     |                  | 1.39   |
|                              | Total-P           | 106            | 104           | 105  |      |     |                  | 1.12   |
| EPA 365.1 Rev. 2.0 dissolved | O-Phosphate-P     | 103            | 93.7          | 96.0 |      |     |                  | 2.12   |
| EPA 8321B                    | 2,4-D             | 134            | 131           | 129  |      |     |                  | 1.65   |
|                              | Acesulfame K      | 77.5           | 30.0          | 39.7 |      |     |                  | 27.8   |
|                              | Acetaminophen     | 65.9           | 86.3          | 90.5 |      |     |                  | 4.72   |
|                              | Acetamiprid       | 101            | 114           | 107  |      |     |                  | 6.22   |
|                              | Afidopyropen      | 80.1           | 86.2          | 92.5 |      |     |                  | 7.06   |
|                              | AMPA              | 107            | 73.8          | 98.7 |      |     |                  | 28.9   |
|                              | Bentazon          | 88.3           | 86.9          | 83.5 |      |     |                  | 3.28   |
|                              | Benzovindiflupyr  | 83.4           | 85.7          | 84.3 |      |     |                  | 1.66   |
|                              | Carbamazepine     | 76.8           | 82.1          | 82.4 |      |     |                  | 0.306  |
|                              | Clothianidin      | 102            | 99.1          | 93.0 |      |     |                  | 6.28   |
|                              | Dinotefuran       | 95.1           | 109           | 95.7 |      |     |                  | 12.6   |
|                              | Diuron            | 61.7           | 59.9          | 64.7 |      |     |                  | 7.67   |
|                              | Endothall         | 97.1           | 68.1          | 87.7 |      |     |                  | 25.2   |
|                              | Fenuron           | 105            | 86.0          | 95.1 |      |     |                  | 10.0   |
|                              | Fluridone         | 60.8           | 83.9          | 71.5 |      |     |                  | 16.0   |
|                              | Glufosinate       | 94.6           | 60.7          | 82.1 |      |     |                  | 29.9   |
|                              | Glyphosate        | 102            | 64.4          | 81.9 |      |     |                  | 24.0   |
|                              | Hydrocodone       | 102            | 106           | 106  |      |     |                  | 0.251  |
|                              | Ibuprofen         | 84.8           | 86.7          | 98.7 |      |     |                  | 12.9   |
|                              | Imazapyr          | 105            | 132           | 111  |      |     |                  | 16.2   |
|                              | Imidacloprid      | 100            | 130           | 121  |      |     |                  | 6.96   |
|                              | Linuron           | 73.9           | 70.4          | 65.5 |      |     |                  | 7.19   |

## Quality Assurance Report Summary

| Ref. Method      | Analyte          | LCS % Recovery | MS % Recovery |      | Precision<br>LCS | SMP   | MS   |
|------------------|------------------|----------------|---------------|------|------------------|-------|------|
|                  |                  |                |               |      |                  |       |      |
| EPA 8321B        | Mandestrobin     | 91.5           | 89.6          | 90.6 |                  |       | 1.08 |
|                  | MCCP             | 112            | 119           | 109  |                  |       | 8.66 |
|                  | Naproxen         | 61.5           | 76.5          | 79.8 |                  |       | 4.21 |
|                  | Primidone        | 101            | 91.1          | 82.1 |                  |       | 10.4 |
|                  | Pyraclostrobin   | 75.0           | 75.0          | 69.6 |                  |       | 7.47 |
|                  | Sucralose        | 95.3           | 71.8          | 80.1 |                  |       | 2.47 |
|                  | Thiamethoxam     | 92.1           | 105           | 98.3 |                  |       | 6.18 |
|                  | Tolfenpyrad      | 52.7           | 58.5          | 52.1 |                  |       | 11.5 |
|                  | Triclopyr        | 112            | 114           | 120  |                  |       | 5.41 |
| SM 2120 B-2011   | Color (true)     | 100            |               |      |                  | 0.326 |      |
| SM 2320 B-2011   | Total Alkalinity | 95.6           |               |      |                  | 0.582 |      |
| SM 2540 C-2011   | TDS              |                |               |      |                  | 3.66  |      |
| SM 4500 F-C-2011 | Fluoride         | 97.5           | 97.9          | 97.9 |                  |       | 0.0  |
| SM 5310 B-2011   | Organic Carbon   | 98.8           | 102           | 104  |                  |       | 1.08 |

## Reference Method Descriptions

| Method                       | Description                                                                                                               | Associated Samples        |
|------------------------------|---------------------------------------------------------------------------------------------------------------------------|---------------------------|
| EPA 180.1 Rev. 2.0           | Turbidity in aqueous matrices                                                                                             | 2219752, 2219755, 2219758 |
| EPA 200.7 Rev. 4.4           | Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects | 2219772, 2219773          |
| EPA 200.8 Rev. 5.4           | Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects                    | 2219772, 2219773          |
| EPA 300.0 Rev. 2.1           | Chloride in aqueous matrices                                                                                              | 2219752, 2219755, 2219758 |
| EPA 300.0 Rev. 2.1           | Sulfate in aqueous matrices                                                                                               | 2219752, 2219755, 2219758 |
| EPA 350.1 Rev. 2.0           | Ammonia in aqueous matrices as mg N/L                                                                                     | 2219753, 2219756, 2219759 |
| EPA 351.2 Rev. 2.0           | Total Kjeldahl Nitrogen in aqueous matrices                                                                               | 2219753, 2219756, 2219759 |
| EPA 353.2 Rev. 2.0           | Nitrite/Nitrate in aqueous matrices as mg N/L                                                                             | 2219753, 2219756, 2219759 |
| EPA 365.1 Rev. 2.0           | Total Phosphorus in aqueous matrices as mg P/L                                                                            | 2219753, 2219756, 2219759 |
| EPA 365.1 Rev. 2.0 dissolved | Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L                                                       | 2219754, 2219757, 2219760 |
| EPA 8321B                    | Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS                                               | 2219769, 2219770, 2219771 |
| EPA 8321B                    | Water soluble organic compounds by HPLC/MS/MS                                                                             | 2219769, 2219770, 2219771 |
| SM 2120 B-2011               | True Color measured at 450 nm (not valid for NPDES monitoring)                                                            | 2219752, 2219755, 2219758 |
| SM 2320 B-2011               | Alkalinity in aqueous matrices as mg CaCO <sub>3</sub> /L                                                                 | 2219752, 2219755, 2219758 |
| SM 2340B                     | Hardness by calculation, in aqueous matrices, reported as mg/L CaCO <sub>3</sub>                                          | 2219772, 2219773          |
| SM 2540 C-2011               | Total Dissolved Solids in aqueous matrices                                                                                | 2219752, 2219755, 2219758 |
| SM 2540 D-2011               | Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample                                            | 2219752, 2219755, 2219758 |
| SM 4500 F-C-2011             | Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)                                       | 2219752, 2219755, 2219758 |
| SM 5310 B-2011               | Nonpurgeable Organic Carbon in aqueous matrices                                                                           | 2219753, 2219756, 2219759 |

## Preparation and Analysis Log

| Ref. Method                  | Received Date | Prep Date/Time   | Prepared By      | Analysis Date/Time | Analyzed By          | Associated Samples        |
|------------------------------|---------------|------------------|------------------|--------------------|----------------------|---------------------------|
| EPA 180.1 Rev. 2.0           | 01/15/2021    |                  |                  | 01/15/2021 14:50   | Yen Ta               | 2219752, 2219755, 2219758 |
| EPA 200.7 Rev. 4.4           | 01/15/2021    | 01/19/2021 15:45 | Elliott D. Healy | 01/20/2021 15:26   | Betina Topolski      | 2219772                   |
|                              | 01/15/2021    | 01/19/2021 15:45 | Elliott D. Healy | 01/20/2021 15:34   | Betina Topolski      | 2219773                   |
| EPA 200.8 Rev. 5.4           | 01/15/2021    | 01/19/2021 15:45 | Elliott D. Healy | 01/25/2021 21:50   | Alexander Thompson   | 2219772                   |
|                              | 01/15/2021    | 01/19/2021 15:45 | Elliott D. Healy | 01/25/2021 21:57   | Alexander Thompson   | 2219773                   |
|                              | 01/15/2021    | 01/19/2021 15:45 | Elliott D. Healy | 01/26/2021 16:07   | Alexander Thompson   | 2219772                   |
|                              | 01/15/2021    | 01/19/2021 15:45 | Elliott D. Healy | 01/26/2021 16:35   | Alexander Thompson   | 2219773                   |
| EPA 300.0 Rev. 2.1           | 01/15/2021    |                  |                  | 01/21/2021 17:18   | Lipi Saha            | 2219752                   |
|                              | 01/15/2021    |                  |                  | 01/21/2021 17:30   | Lipi Saha            | 2219755                   |
|                              | 01/15/2021    |                  |                  | 01/21/2021 17:42   | Lipi Saha            | 2219758                   |
| EPA 350.1 Rev. 2.0           | 01/15/2021    |                  |                  | 02/01/2021 18:43   | Ping Hua             | 2219753                   |
|                              | 01/15/2021    |                  |                  | 02/01/2021 18:45   | Ping Hua             | 2219756                   |
|                              | 01/15/2021    |                  |                  | 02/01/2021 18:46   | Ping Hua             | 2219759                   |
| EPA 351.2 Rev. 2.0           | 01/15/2021    | 01/27/2021 13:15 | Yen Ta           | 01/28/2021 15:59   | Julia Storbeck       | 2219759                   |
|                              | 01/15/2021    | 01/28/2021 17:00 | Yen Ta           | 01/29/2021 14:53   | Julia Storbeck       | 2219753                   |
|                              | 01/15/2021    | 02/01/2021 09:53 | Yen Ta           | 02/01/2021 20:37   | Julia Storbeck       | 2219756                   |
| EPA 353.2 Rev. 2.0           | 01/15/2021    |                  |                  | 01/22/2021 10:05   | Beverly Y. Sanders   | 2219753                   |
|                              | 01/15/2021    |                  |                  | 01/22/2021 10:06   | Beverly Y. Sanders   | 2219756                   |
|                              | 01/15/2021    |                  |                  | 01/22/2021 11:03   | Beverly Y. Sanders   | 2219759                   |
| EPA 365.1 Rev. 2.0           | 01/15/2021    | 01/21/2021 17:45 | Madeline Gruver  | 01/25/2021 15:09   | Shengyu Wang         | 2219753                   |
|                              | 01/15/2021    | 01/21/2021 17:45 | Madeline Gruver  | 01/25/2021 15:28   | Shengyu Wang         | 2219756                   |
|                              | 01/15/2021    | 01/21/2021 17:45 | Madeline Gruver  | 01/25/2021 15:29   | Shengyu Wang         | 2219759                   |
| EPA 365.1 Rev. 2.0 dissolved | 01/15/2021    |                  |                  | 01/15/2021 16:44   | Ping Hua             | 2219754                   |
|                              | 01/15/2021    |                  |                  | 01/15/2021 16:45   | Ping Hua             | 2219757                   |
|                              | 01/15/2021    |                  |                  | 01/15/2021 16:46   | Ping Hua             | 2219760                   |
| EPA 8321B                    | 01/15/2021    | 01/19/2021 12:15 | Rebecca Ware     | 01/19/2021 19:27   | Rebecca Ware         | 2219769                   |
|                              | 01/15/2021    | 01/19/2021 12:15 | Rebecca Ware     | 01/19/2021 19:41   | Rebecca Ware         | 2219770                   |
|                              | 01/15/2021    | 01/19/2021 12:15 | Rebecca Ware     | 01/19/2021 19:55   | Rebecca Ware         | 2219771                   |
|                              | 01/15/2021    | 01/19/2021 12:15 | Rebecca Ware     | 01/21/2021 11:32   | Rebecca Ware         | 2219769                   |
|                              | 01/15/2021    | 01/19/2021 12:15 | Rebecca Ware     | 01/21/2021 11:44   | Rebecca Ware         | 2219770                   |
|                              | 01/15/2021    | 01/19/2021 12:15 | Rebecca Ware     | 01/21/2021 11:56   | Rebecca Ware         | 2219771                   |
|                              | 01/15/2021    | 01/21/2021 08:30 | Hoor Shaik       | 01/23/2021 02:29   | Juyoung Kim          | 2219769                   |
|                              | 01/15/2021    | 01/21/2021 08:30 | Hoor Shaik       | 01/23/2021 03:04   | Juyoung Kim          | 2219770                   |
|                              | 01/15/2021    | 01/21/2021 08:30 | Hoor Shaik       | 01/23/2021 03:38   | Juyoung Kim          | 2219771                   |
| SM 2120 B-2011               | 01/15/2021    |                  |                  | 01/15/2021 15:44   | Benjamin T. Nordmann | 2219752                   |
|                              | 01/15/2021    |                  |                  | 01/15/2021 15:45   | Benjamin T. Nordmann | 2219755                   |
|                              | 01/15/2021    |                  |                  | 01/15/2021 15:46   | Benjamin T. Nordmann | 2219758                   |
| SM 2320 B-2011               | 01/15/2021    |                  |                  | 01/19/2021 21:49   | Dale L. Simmons      | 2219752                   |
|                              | 01/15/2021    |                  |                  | 01/19/2021 21:55   | Dale L. Simmons      | 2219755                   |
|                              | 01/15/2021    |                  |                  | 01/19/2021 22:08   | Dale L. Simmons      | 2219758                   |

## Preparation and Analysis Log

| Ref. Method      | Received Date | Prep Date/Time | Prepared By | Analysis Date/Time | Analyzed By     | Associated Samples        |
|------------------|---------------|----------------|-------------|--------------------|-----------------|---------------------------|
| SM 2340B         | 01/15/2021    |                |             | 01/20/2021 15:26   | Betina Topolski | 2219772                   |
|                  | 01/15/2021    |                |             | 01/20/2021 15:34   | Betina Topolski | 2219773                   |
| SM 2540 C-2011   | 01/15/2021    |                |             | 01/19/2021 14:52   | Yijie Li        | 2219752, 2219755, 2219758 |
| SM 2540 D-2011   | 01/15/2021    |                |             | 01/19/2021 14:52   | Yijie Li        | 2219752, 2219755, 2219758 |
| SM 4500 F-C-2011 | 01/15/2021    |                |             | 01/19/2021 21:49   | Dale L. Simmons | 2219752                   |
|                  | 01/15/2021    |                |             | 01/19/2021 21:55   | Dale L. Simmons | 2219755                   |
|                  | 01/15/2021    |                |             | 01/19/2021 22:08   | Dale L. Simmons | 2219758                   |
| SM 5310 B-2011   | 01/15/2021    |                |             | 01/21/2021 18:57   | Touraj Touran   | 2219759                   |
|                  | 01/15/2021    |                |             | 01/21/2021 21:03   | Touraj Touran   | 2219753                   |
|                  | 01/15/2021    |                |             | 01/21/2021 21:15   | Touraj Touran   | 2219756                   |