

RQ-2021-02-08-16

Login Checklist

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | GreyhoundDate/Time of Receipt: 02/23/2021 @ 10:15

*Cooler Temperature	Samples Frozen? YES	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
		HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
0.7°C				9		X			9293 8010 4420

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: Tyler

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init: Tyler

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: Tyler**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☐ NA ☒ Init: Tyler

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: TylerDate: 02/23/2021Event contains NCRs (Y/N)? NoneEvent ID: Adelaide/Lotus/Asher/Florida

CEN-DIST-2021-02-23-01 (SMP)

Date Received: 23-FEB-2021 10:15

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	#4 Temp Gun EXP:10/28/2021
pH Test Strips 0 – 6	N/A
pH Paper 0 – 3	N/A
pH Paper 0 – 13	231019 EXP:11/01/2022
Chlorine Test Strips	8261 EXP:07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____


FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 2/22/2021 **Collected By:** Natalie Ayala, Victoria Schwartz
Customer: CEN-DIST **Sampling Agency:** FDEP
RQ: RQ-2021-02-08-16 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Lake Adelaide @ Center	 G2CE0151
Lake Florida @ Center of Lake	 G2CE0150

RELINQUISHED BY(SIGNATURE): Victoria Schwartz DATE/TIME: 02/22/21 16:00

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: Tyler Reynolds Rec'd/Inspected Date: 02/23/2021



RQ-2021-02-08-16

Customer: WQAP

Project ID: SMP

Collected By: Natalie Ayala, Victoria Schwartz

Field Report Prepared By: Natalie Ayala

Sampling Agency: FDEP

Place Label Here

WIN ID/Field ID:



G2CE0150

Location: Lake Florida @ Center of Lake

Comments:

Matrix: Fresh

(Check one)

☒ GRAB☐ COMPOSITE

Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
2/22/2021	1217 EST	8.31	91.6	20.1	7.6	0.3	0.8 ☐ VOB (S)	3.7	153.1	0.07
	1219	7.9	86.4	19.6	7.42	2.0	Central Lab please use top row for login purposes		153.2	0.07
	1221 EST	0.4	4.7	17.6	6.68	3.2			163.6	0.08

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # SA0293040 Exp: 10/19/21	☒ Ice ☒ H2SO4*	☒ <2	1	B
Metals (P-500ML)	☐ W-ICPMS ☐ W-ICP ☐ W-HARD Lot # Exp:	☐ Ice ☐ HNO3* ☐ <2			
Filtered Nutrients (P125ML)	☒ W-PO4-F ☒ Field Filtered 0.45 µm Filter Filter Lot # 17135566 Syringe Lot # 0079900	☒ Ice		1	B
Chlorophyll (BP-1L)	☒ CHLSUITE-W	☒ Ice		1	B
Physical/Aggregate (Fresh) (P-1L)	☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W-TDS	☒ Ice		1	B
Physical/Aggregate (Marine) (P-1L)	☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	☐ Ice			
Macroinvertebrates (PJ-2L)	☐ MI-FW-QLDC	☐ Formalin			
Periphyton (PT-50ML)	☐ ALGAE-ID	☐ Ice			
Microbiology (Contract Lab Bottle)	☐ E Coli ☐ F Coli ☐ Enterococci ☐ Contract Lab	☐ Ice			
Molecular (QPCR-P-500ML)	☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD	☐ Ice			
Tracers (BG-500ML)	☐ W-E8321-DI ☐ W-E8321-MS	☐ Ice			
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI W-E8321-MS W-PSNP-TQ W-CT-CL-R W-PCL-SQ-R W-CARB-AA (5 ml of MCAA** Buffer Solution) W-DIELDRIN	☐ Ice			
Phytoplankton/Periphyton	DTM-QL-C PEN-QL-C x DTY-QN-C PKD-QN-C DTM-QN-C PRN-QN-C x PKD-QN-BV	☒ Ice		1	B

Name:
Natalie Ayala
Victoria Schwartz

Signature:

Victoria Schwartz

Date:

02/22/21

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution



RQ-2021-02-08-16

Customer: WQAP

Project ID: SMP

Collected By: Victoria Schwartz, Natalie Ayala

Field Report Prepared By: Victoria Schwartz

Sampling Agency: FDEP

Place Label Here

WIN ID/Field ID:



G2CE0151

Location: Lake Adelaide @ Center

Comments:

Matrix: Fresh

(Check one)

☒ GRAB☐ COMPOSITE

Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT _h)
2/22/2021	1122 EST	7.88	86.9	20	7.06	0.3	0.9 ☐ VOB (S)	3.3	176.7	0.08
	1125	7.62	83.6	19.7	7	2.0	Central Lab please use top row for login purposes		176.3	0.08
	1127 EST	6.89	74.9	19.4	6.89	2.8			175.9	0.08

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # SA0293040 Exp: 10/19/21	☒ Ice ☒ H2SO4*	☒ <2	1	A
Metals (P-500ML)	☐ W-ICPMS ☐ W-ICP ☐ W-HARD Lot # Exp:	☐ Ice ☐ HNO3* ☐ <2			
Filtered Nutrients (P125ML)	☒ W-P04-F ☒ Field Filtered 0.45 µm Filter Filter Lot # 17135566 Syringe Lot # 0079900	☒ Ice		1	A
Chlorophyll (BP-1L)	☒ CHLSUITE-W	☒ Ice		1	A
Physical/Aggregate (Fresh) (P-1L)	☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-S04-IC / W-TDS	☒ Ice		1	A
Physical/Aggregate (Marine) (P-1L)	☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	☐ Ice			
Macroinvertebrates (PJ-2L)	☐ MI-FW-QLDC	☐ Formalin			
Periphyton (PT-50ML)	☐ ALGAE-ID	☐ Ice			
Microbiology (Contract Lab Bottle)	☐ E Coli ☐ F Coli ☐ Enterococci ☐ Contract Lab	☐ Ice			
Molecular (QPCR-P-500ML)	☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD	☐ Ice			
Tracers (BG-500ML)	☐ W-E8321-DI ☐ W-E8321-MS	☐ Ice			
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI W-E8321-MS W-PSNP-TQ W-CT-CL-R W-PCL-SQ-R W-CARB-AA (5 ml of MCAA** Buffer Solution) W-DIELDIN	☐ Ice			
Phytoplankton/Periphyton	DTM-QL-C PEN-QL-C DTY-QN-C PKD-QN-C DTM-QN-C PRN-QN-C PKD-QN-BV	☐ Ice			

Name:
Victoria Schwartz
Natalie Ayala

Signature:

Victoria Schwartz

Date:

02/22/21

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution

Printed: 2/23/2021 10:45:37 AM

Page 1 of 2

Date of Request: 10-JAN-2021
 Created By: BOMAN_L On: 10-JAN-2021
 Modified By: JASROTIA_P On: 19-JAN-2021
 Customer: CEN-DIST
 Project: SMP
 Division:
 District: Central District
 Event Description: Adelaide/Lotus/Asher/Florida

Send Coolers To:

Phone: 407-897-4178
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Natalie Ayala
 Cooler Ship EMail: natalie.ayala@dep.state.fl.us

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: JASROTIA_P On: 19-JAN-2021
 Biology Request Reviewed By: JASROTIA_P On: 19-JAN-2021
 Sampling Kit Required: YES Ship on: 29-JAN-2021
 Sampling Kit Shipped: YES On: 25-JAN-2021
 Sampling Kit Packed By: KLUG_K
 Preservatives Needed: NO
 Date to Receive Samples: 08-FEB-2021
 Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Kalina Warren
 Report Notification EMail: natalie.ayala@dep.state.fl.us

Comments: Receiving, log algae samples in under separate Event, Priority 12

Bottle Group A: Adelaide/Lotus/Asher
 Bottle Group B: Florida

Bottle Group A (Water) With 3 Samples:

Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 3	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 3	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices	
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)	
Color (true)			
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices	
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices	
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	
Bottle Type: BP-1L		Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry	
Bottle Type: BP-1L		Number of Bottles: 1	Preserved With: Lugols
DTY-QN-C	Template: DEFAULT	(SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.	
PKD-QN-BV	Template: DEFAULT	(SOP-AB05) No. of wet taxa of quantitative phytoplankton sample w/speciation and cell counts.	
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L	
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L	
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L	
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices	
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices	
Bottle Type: P-125ML		Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.