

Login Checklist

RQ- **2021 - 03 - 01 - 12**

Login Station ID: **# 3**

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: **02-26-2021 / 15:40**

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
3.6c				4		x			9293 8010 2336

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included? Yes **x** No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes _____ No **x**

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA **x** Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken? Yes _____ No _____ Containers intact? Yes **x** No _____

Caps on tight? Yes **x** No _____

Sufficient Sample Volume: Yes **x** No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes _____ No **x** Init: **ABS/**

Chlorine detected? (One container checked per Field ID) Yes _____ No _____ Init: **ABS/**

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

Acid Preserved Samples: pH< 2.0? Yes **x No _____ NA _____ Init: **ABS/**

W-1-4-DIOX (Green dot on container) preserved to pH<4.0? Yes _____ No _____ NA **x Init: **ABS/**

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: **ABS/** Date: **02-26-2021** Event contains NCRs (Y/N)? **N**

EventID: **Coon Lake / Lake Center**
-CEN-DIST-2021-02-26-03 (SMP)

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IRTG # 3 EXP:10/28/2021
pH Test Strips 0 – 6	213316 BV EXP:05/15/21
pH Paper 0 – 3	N/A
pH Paper 0 – 13	231019 EXP:11/01/2021
Chlorine Test Strips	0261 2023 / 05

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: ABS

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 2/25/2021 Collected By: Terry Riordan, Victoria Schwartz
Customer: CEN-DIST Sampling Agency: FDEP
RQ: RQ-2021-03-01-12 Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Coon Lake @ Center	 G4CE0162

RELINQUISHED BY(SIGNATURE):

Victoria Schwartz

DATE/TIME: 2/25/21 16:00

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

[Signature]

Rec'd/Inspected Date:

2-26-21

3 PO4s SD 2/26/21 3:59 pm
1 Turb Y.T. 2/26/21 4:00 pm



RQ-2021-03-01-12

Customer: WQAP

Project ID: SMP

Collected By: Terry Riordan, Victoria Schwartz

Field Report Prepared By: Terry Riordan

Sampling Agency: FDEP

Place Label Here						Comments:				
WIN ID/Field ID:  G4CE0162										
Location: Coon Lake @ Center										
Matrix: Fresh						(Check one) ☒ GRAB ☐ COMPOSITE				
Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
2/25/2021	1225 EST	7.73	89.2	22.4	5.69	0.3	0.3 ☐ VOB (S)	3.5	126.3	0.06
	1227	7.38	83.1	21	5.68	2.0	Central Lab please use top row for login purposes		127.6	0.06
	1229 EST	6.73	73.6	19.6	5.64	3			126.6	0.06
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				☒ Ice ☒ H2SO4*		☒ <2	1	A
		Lot # SA0293040		Exp:		10/19/21				
Metals (P-500ML)		☐ W-ICPMS ☐ W-ICP ☐ W-HARD				☐ Ice ☐ HNO3*		☐ <2		
		Lot #		Exp:						
Filtered Nutrients (P125ML)		☒ W-PO4-F ☒ Field Filtered 0.45 µm Filter				☒ Ice			1	A
		Filter Lot # 17135566								
		Syringe Lot # 0079900								
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	A
Physical/Aggregate (Fresh) (P-1L)		☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-S04-IC / W-TDS				☒ Ice			1	A
Physical/Aggregate (Marine) (P-1L)		☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				☐ Ice				
MacroInvertebrates (PJ-2L)		☐ MI-FW-QLDC				☐ Formalin				
Periphyton (PT-50ML)		☐ ALGAE-ID				☐ Ice				
Microbiology (Contract Lab Bottle)		☐ E Coli ☐ F Coli ☐ Enterococci ☐ Contract Lab				☐ Ice				
Molecular (QPCR-P-500ML)		☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD ☐				☐ Ice				
Tracers (BG-500ML)		☐ W-E8321-DI ☐ W-E8321-MS				☐ Ice				
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI W-E8321-MS W-PSNP-TQ W-CT-CL-R W-PCL-SQ-R W-CARB-AA (5 ml of MCAA** Buffer Solution) W-DIELDRIN				☐ Ice				
Phytoplankton/Periphyton		DTM-QL-C PEN-QL-C DTY-QN-C PKD-QN-C DTM-QN-C PRN-QN-C				☐ Ice				
Name: Terry Riordan Victoria Schwartz						Signature: <i>Victoria Schwartz</i>			Date: 2/25/21	

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution

Date of Request: 02-FEB-2021
 Created By: BOMAN_L On: 02-FEB-2021
 Modified By: JASROTIA_P On: 08-FEB-2021
 Customer: CEN-DIST
 Project: SMP
 Division:
 District: Central District
 Event Description: Coon Lake / Lake Center

Send Coolers To:

Phone: 407-897-4178
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Natalie Ayala
 Cooler Ship EMail: natalie.ayala@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 08-FEB-2021
 Biology Request Reviewed By: JASROTIA_P On: 08-FEB-2021
 Sampling Kit Required: YES Ship on: 19-FEB-2021
 Sampling Kit Shipped: YES On: 12-FEB-2021
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 01-MAR-2021
 Logged In By: SHAIK_A On: 26-FEB-2021

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Kalina Warren
 Report Notification EMail: natalie.ayala@dep.state.fl.us

Comments:**Bottle Group A (Water) With 1 Samples:**

Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011)	Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0)	Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011)	True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)			
W-F	Template: DEFAULT	(SM 4500 F-C-2011)	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011)	Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011)	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L		Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.))	Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0)	Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011)	Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML		Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

