

Chemical Analysis Report

CEN-DIST-2021-06-16-03

Florida Department of Environmental Protection
Central Laboratory
2600 Blair Stone Road
Tallahassee, FL 32399-2400
DOH Accreditation E31780


Event Description: **Lake Condel**
Request ID: **RQ-2021-03-29-36**
Customer: **CEN-DIST**
Project ID: **SMP**

Send Reports to:
FL Dept. of Environmental Protection
FL Dept. of Environmental Protection
3319 Maguire Blvd., Suite 232
Orlando, FL 32803-3767
Attn: Kalina Warren

For additional information please contact
Colin Wright, Ph.D.
Liang-Tsair Lin, Ph.D.
Kerry Tate, Ph.D.
Dr. rer. nat. Bettina Steinbock
Thekkekalathil Chandrasekhar, Ph.D, QA Officer
Phone (850) 245-8085

Certified by: Dr. rer. nat. Bettina Steinbock, Environmental Administrator

Date Certified: 29-JUN-2021 13:19



Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical group are included in this report: Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to 1.3×10^3 or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (**) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited by the Florida Department of Health Environmental Laboratory Certification Program or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: Lake Condel @ Center

Collection Date/Time: 06/15/2021 10:45

Field ID: G4CE0177

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2255171	EPA 8321B	2,4-D	0.034		ug/L	P399742	
		Acesulfame K	0.10	U	ug/L	P399865	
		AMPA	0.65		ug/L	P399865	
		2,4,5-T	0.0040	U	ug/L	P399742	MS
		Acetaminophen	0.0080	U	ug/L	P399742	
		Acetamiprid	0.0020	U	ug/L	P399742	
		Endothall	0.25	U	ug/L	P399865	
		Glufosinate	0.10	U	ug/L	P399865	
		Glyphosate	1.4		ug/L	P399865	
		Afidopyropen	0.0020	U	ug/L	P399742	
		Bentazon	0.0029	I	ug/L	P399742	
		Sucralose	1.7		ug/L	P399865	
		Benzovindiflupyr	0.0020	U	ug/L	P399742	
		Carbamazepine	0.0024	I	ug/L	P399742	
		Clothianidin	0.013		ug/L	P399742	
		Dinotefuran	0.0020	U	ug/L	P399742	
		Diuron	0.0028	I	ug/L	P399742	
		Fenuron	0.13		ug/L	P399742	
		Fluridone	0.016		ug/L	P399742	
		Imazapyr	0.13		ug/L	P399742	
		Hydrocodone	0.0020	U	ug/L	P399742	
		Ibuprofen	0.020	U	ug/L	P399742	
		Imidacloprid	0.011		ug/L	P399742	MS
		Linuron	0.0040	U	ug/L	P399742	
		Mandestrobin	0.0020	U	ug/L	P399742	
		MCPP	0.033		ug/L	P399742	MS
		Naproxen	0.0080	U	ug/L	P399742	
		Primidone	0.0040	U	ug/L	P399742	
		Pyraclostrobin	0.0020	U	ug/L	P399742	
		Thiamethoxam	0.0020	I	ug/L	P399742	
		Tolfenpyrad	0.0020	U	ug/L	P399742	
		Triclopyr	0.0040	U	ug/L	P399742	MS

Ref. Method and Comment:

EPA 8321B: MS accuracy for some analytes could not be assessed due to high concentration of parameter in the spiked sample.

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8321B

Batch ID: P399742

Component	Result	Code	Units
2,4-D	0.0020	U	ug/L
2,4,5-T	0.0040	U	ug/L
Acetaminophen	0.0080	U	ug/L
Acetamiprid	0.0020	U	ug/L
Afidopyropen	0.0020	U	ug/L
Bentazon	8.0E-04	U	ug/L
Benzovindiflupyr	0.0020	U	ug/L
Carbamazepine	8.0E-04	U	ug/L
Clothianidin	0.0020	U	ug/L
Dinotefuran	0.0020	U	ug/L
Diuron	0.0020	U	ug/L
Fenuron	0.016	U	ug/L
Fluridone	8.0E-04	U	ug/L
Hydrocodone	0.0020	U	ug/L
Ibuprofen	0.020	U	ug/L
Imazapyr	0.0040	U	ug/L
Imidacloprid	0.0020	U	ug/L
Linuron	0.0040	U	ug/L
Mandestrobin	0.0020	U	ug/L
MCPP	0.0020	U	ug/L
Naproxen	0.0080	U	ug/L
Primidone	0.0040	U	ug/L
Pyraclostrobin	0.0020	U	ug/L
Thiamethoxam	0.0020	U	ug/L
Tolfenpyrad	0.0020	U	ug/L
Triclopyr	0.0040	U	ug/L

Reference Method: EPA 8321B

Batch ID: P399865

Component	Result	Code	Units
Acesulfame K	0.10	U	ug/L
AMPA	0.10	U	ug/L
Endothall	0.25	U	ug/L
Glufosinate	0.10	U	ug/L
Glyphosate	0.10	U	ug/L
Sucralose	0.010	U	ug/L

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: EPA 8321B

Batch ID: P399742

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2,4-D	106		P	30 - 160
2,4,5-T	99.3		P	30 - 160
Acetaminophen	60.6		P	30 - 150
Acetamiprid	78.4		P	30 - 160
Afidopyropen	73.3		P	30 - 160
Bentazon	39.2		P	30 - 150
Benzovindiflupyr	78.0		P	30 - 160
Carbamazepine	76.5		P	30 - 160
Clothianidin	77.5		P	30 - 160
Dinotefuran	68.1		P	30 - 160
Diuron	66.8		P	30 - 160
Fenuron	85.5		P	30 - 160
Fluridone	83.2		P	30 - 160
Hydrocodone	81.6		P	30 - 160
Ibuprofen	65.1		P	30 - 160
Imazapyr	91.7		P	30 - 160
Imidacloprid	72.3		P	30 - 160
Linuron	59.6		P	30 - 160
Mandestrobin	88.0		P	30 - 160
MCPP	147		P	30 - 160
Naproxen	81.4		P	30 - 160
Primidone	86.5		P	30 - 160
Pyraclostrobin	62.0		P	30 - 160
Thiamethoxam	52.4		P	30 - 160
Tolfenpyrad	47.0		P	30 - 160
Triclopyr	112		P	30 - 160

Reference Method: EPA 8321B

Batch ID: P399865

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Acesulfame K	80.5		P	40 - 150
AMPA	99.4		P	40 - 150
Endothall	71.4		P	40 - 150
Glufosinate	101		P	40 - 150
Glyphosate	103		P	40 - 150
Sucralose	102		P	40 - 150

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8321B

Batch ID: P399742

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2254386	2,4-D	127	139	P/P	30 - 160
2254386	2,4,5-T	150	161	P/F	30 - 160
2254386	Acetaminophen	48.3	51.9	P/P	30 - 150
2254386	Acetamiprid	90.4	85.9	P/P	30 - 160
2254386	Afidopyropen	81.3	86.6	P/P	30 - 160
2254386	Benzovindiflupyr	73.8	78.6	P/P	30 - 160
2254386	Carbamazepine	77.5	70.6	P/P	30 - 160
2254386	Clothianidin	109	101	P/P	30 - 160
2254386	Dinotefuran	97.4	98.4	P/P	30 - 160
2254386	Diuron	69.0	64.6	P/P	30 - 160
2254386	Fenuron	79.8	81.6	P/P	30 - 160
2254386	Fluridone	86.1	82.8	P/P	30 - 160
2254386	Hydrocodone	83.6	87.4	P/P	30 - 160
2254386	Ibuprofen	65.0	85.4	P/P	30 - 160
2254386	Imidacloprid	157	162	P/F	30 - 160
2254386	Linuron	74.5	80.2	P/P	30 - 160
2254386	Mandestrobin	92.8	97.3	P/P	30 - 160
2254386	MCPP	199	213	F/F	30 - 160
2254386	Naproxen	94.0	101	P/P	30 - 160
2254386	Primidone	104	85.9	P/P	30 - 160
2254386	Pyraclostrobin	74.7	65.6	P/P	30 - 160
2254386	Thiamethoxam	119	116	P/P	30 - 160
2254386	Tolfenpyrad	48.4	64.3	P/P	30 - 160
2254386	Triclopyr	155	161	P/F	30 - 160

Reference Method: EPA 8321B

Batch ID: P399865

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2255020	Acesulfame K	84.0	86.4	P/P	40 - 150
2255020	AMPA	95.1	97.3	P/P	40 - 150
2255020	Endothall	70.2	82.7	P/P	40 - 150
2255020	Glufosinate	103	105	P/P	40 - 150
2255020	Glyphosate	106	111	P/P	40 - 150
2255020	Sucralose	99.7	103	P/P	40 - 150

Quality Assurance Report

Precision

Reference Method: EPA 8321B

Batch ID: P399742

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2254386	2,4-D	8.10	Spike	P	0 - 30
2254386	2,4,5-T	7.63	Spike	P	0 - 30
2254386	Acetaminophen	5.02	Spike	P	0 - 30
2254386	Acetamiprid	5.13	Spike	P	0 - 30
2254386	Afidopyropen	6.35	Spike	P	0 - 30
2254386	Bentazon	11.4	Spike	P	0 - 30
2254386	Benzovindiflupyr	6.22	Spike	P	0 - 30
2254386	Carbamazepine	4.66	Spike	P	0 - 30
2254386	Clothianidin	7.29	Spike	P	0 - 30
2254386	Dinotefuran	1.06	Spike	P	0 - 30
2254386	Diuron	6.65	Spike	P	0 - 30
2254386	Fenuron	2.17	Spike	P	0 - 30
2254386	Fluridone	2.03	Spike	P	0 - 30
2254386	Hydrocodone	4.45	Spike	P	0 - 30
2254386	Ibuprofen	27.1	Spike	P	0 - 30
2254386	Imazapyr	2.51	Spike	P	0 - 30
2254386	Imidacloprid	3.25	Spike	P	0 - 30
2254386	Linuron	7.30	Spike	P	0 - 30
2254386	Mandestrobin	4.70	Spike	P	0 - 30
2254386	MCPP	6.70	Spike	P	0 - 30
2254386	Naproxen	7.41	Spike	P	0 - 30
2254386	Primidone	11.6	Spike	P	0 - 30
2254386	Pyraclostrobin	13.0	Spike	P	0 - 30
2254386	Thiamethoxam	3.17	Spike	P	0 - 30
2254386	Tolfenpyrad	28.3	Spike	P	0 - 30
2254386	Triclopyr	3.84	Spike	P	0 - 30

Reference Method: EPA 8321B

Batch ID: P399865

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2255020	Acesulfame K	2.82	Spike	P	0 - 30
2255020	AMPA	2.28	Spike	P	0 - 30
2255020	Endothall	16.3	Spike	P	0 - 30
2255020	Glufosinate	1.33	Spike	P	0 - 30
2255020	Glyphosate	4.62	Spike	P	0 - 30
2255020	Sucralose	2.76	Spike	P	0 - 30

* Sample, spike and/or laboratory control sample precision (LCS) is reported.

Quality Assurance Report Surrogates

Lab Sample ID: 2255171

Field Sample ID: G4CE0177

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	139	P	30 - 160
EPA 8321B	Acetaminophen-d4	46.1	P	30 - 160
EPA 8321B	Carbamazepine-d10	59.2	P	30 - 160
EPA 8321B	Diuron-d6	50.1	P	30 - 160
EPA 8321B	Endothall-d6	79.5	P	30 - 160
EPA 8321B	Glyphosate 13C 15N	85.8	P	30 - 160
EPA 8321B	Ibuprofen-d3	63.4	P	30 - 160
EPA 8321B	Primidone-d5	69.3	P	30 - 160
EPA 8321B	Sucralose-d6	105	P	30 - 160

Quality Assurance Report Calibration Verification

Reference Method: EPA 8321B
Run ID: A106190
Included Lab Sample IDs: 2255171

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
AMPA	97.2	82.6	P/P	60 - 160
Glufosinate	95.5	89.7	P/P	60 - 160
Glyphosate	99.1	93.6	P/P	60 - 160

Reference Method: EPA 8321B
Run ID: A106192
Included Lab Sample IDs: 2255171

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Acesulfame K	77.2	76.7	P/P	60 - 160
Endothall	75.7	82.8	P/P	60 - 160
Sucralose	110	107	P/P	60 - 160

Reference Method: EPA 8321B
Run ID: A106199
Included Lab Sample IDs: 2255171

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
2,4-D	87.7	84.5	P/P	50 - 150
2,4,5-T	102	93.6	P/P	50 - 150
Acetaminophen	79.2	77.0	P/P	60 - 160
Acetamiprid	101	95.6	P/P	50 - 150
Afidopyropen	127	120	P/P	50 - 150
Bentazon	102	101	P/P	50 - 160
Benzovindiflupyr	106	87.7	P/P	50 - 160
Carbamazepine	115	106	P/P	60 - 150
Clothianidin	104	91.5	P/P	60 - 150
Dinotefuran	87.7	88.4	P/P	50 - 150
Diuron	104	101	P/P	60 - 160
Fenuron	99.6	102	P/P	60 - 150
Fluridone	126	125	P/P	60 - 160
Hydrocodone	104	103	P/P	60 - 150
Ibuprofen	71.3	83.9	P/P	50 - 160
Imazapyr	106	86.3	P/P	50 - 150
Imidacloprid	87.7	92.3	P/P	60 - 150
Linuron	124	109	P/P	60 - 150
Mandestrobin	113	110	P/P	50 - 150
MCPP	116	115	P/P	50 - 150
Naproxen	119	93.2	P/P	50 - 160
Primidone	112	100	P/P	60 - 150
Pyraclostrobin	90.6	96.3	P/P	60 - 150
Thiamethoxam	93.9	94.5	P/P	50 - 150
Tolfenpyrad	115	109	P/P	60 - 150
Triclopyr	105	110	P/P	50 - 150

* Pass/Fail determinations are made for each bracketing calibration verification check.
Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.
Where they are different, both control limits are provided.

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		Precision SMP	MS
			LCS			
EPA 8321B	2,4-D	106	127	139		8.10
	2,4,5-T	99.3	150	161		7.63
	Acesulfame K	80.5	84.0	86.4		2.82
	Acetaminophen	60.6	48.3	51.9		5.02
	Acetamiprid	78.4	90.4	85.9		5.13
	Afidopyropen	73.3	81.3	86.6		6.35
	AMPA	99.4	95.1	97.3		2.28
	Bentazon	39.2				11.4
	Benzovindiflupyr	78.0	73.8	78.6		6.22
	Carbamazepine	76.5	77.5	70.6		4.66
	Clothianidin	77.5	109	101		7.29
	Dinotefuran	68.1	97.4	98.4		1.06
	Diuron	66.8	69.0	64.6		6.65
	Endothall	71.4	70.2	82.7		16.3
	Fenuron	85.5	79.8	81.6		2.17
	Fluridone	83.2	86.1	82.8		2.03
	Glufosinate	101	103	105		1.33
	Glyphosate	103	106	111		4.62
	Hydrocodone	81.6	83.6	87.4		4.45
	Ibuprofen	65.1	65.0	85.4		27.1
	Imazapyr	91.7				2.51
	Imidacloprid	72.3	157	162		3.25
	Linuron	59.6	74.5	80.2		7.30
	Mandestrobin	88.0	92.8	97.3		4.70
	MCPP	147	199	213		6.70
	Naproxen	81.4	94.0	101		7.41
	Primidone	86.5	104	85.9		11.6
	Pyraclostrobin	62.0	74.7	65.6		13.0
	Sucralose	102	99.7	103		2.76
	Thiamethoxam	52.4	119	116		3.17
	Tolfenpyrad	47.0	48.4	64.3		28.3
	Triclopyr	112	155	161		3.84

Reference Method Descriptions

Method	Description	Associated Samples
EPA 8321B	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	2255171

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
EPA 8321B	06/16/2021	06/16/2021 14:00	Hoor Shaik	06/21/2021 09:45	Juyoung Kim	2255171
	06/16/2021	06/18/2021 11:00	Juyoung Kim	06/18/2021 15:20	Juyoung Kim	2255171
	06/16/2021	06/18/2021 11:00	Juyoung Kim	06/18/2021 22:51	Juyoung Kim	2255171