

RQ-2021-04-12-75

Login Checklist

Login Station ID: #2

Shipping Method: ☒ FedEx | ☐ UPS | ☐ HD | ☐ Greyhound

Date/Time of Receipt: 4/15/2021 9:20

*Cooler Temperature	Samples Frozen? YES	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
		HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
2.1				9			☒		9293 804 2039

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☒Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☐ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☐ NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IM

Date: 4/15/2021

Event contains NCRs (Y/N)? ☒

Event ID:

Faulk/Fox

CEN-DIST-2021-04-15-03 (SMP)

Date Received: 15-APR-2021 09:20

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:10/28/21
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	231019 exp: 11/1/22
Chlorine Test Strips	0129 exp: 03/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 4/14/2021
Customer: CEN-DIST
RQ: RQ-2021-04-12-75

Collected By: Elizabeth Bates, Terry Riordan
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Faulk Canal @ 50m upstream of Fiske Blvd	 G3CE0016
Fox Lake near Center	 G3CE0041

RELINQUISHED BY(SIGNATURE):



DATE/TIME:

4/14/2021 1600

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:



Rec'd/Inspected

Date:

4/15/21



RQ-2021-04-12-75	Collected By: Elizabeth Bates, Terry Riordan
Customer: FDEP	Field Report Prepared by: Elizabeth Bates, Terry Riordan
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID: 
WIN ID/Field ID: G3CE0016

Comments:

Location: Faulk Canal @ 50m upstream of Fiske Blvd

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
4/14/2021 1108	1.72	20.3	23.6	6.65	0.2	0.4	0.4	603	0.29

Central Lab please use top row for login purposes

Central Lab Protocol and Reporting for Right Purpose																
Parameter Suite		Parameter Methods					Preservation			pH Check		# Bottles sent to Lab	Bottle Group			
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP					X	Ice	X	H2SO4*	X	<2	1	A		
		Lot #		SA0353110		Exp:	01/11/22									
Metals (P-500ML)		W-ICPMS		W-ICP		W-HARD			Ice		HNO3*		<2			
		Lot #				Exp:										
Filtered Nutrients (P125ML)	X	W-PO4-F		X	Field Filtered 0.45 um Filter			X	Ice							
		Filter Lot #		17135566												
		Syringe Lot #		79900												
Chlorophyll (BP-1L)	X	CHLSUITE-W					X	Ice								
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS					X	Ice								
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY						Ice								
Macroinvertebrates (PJ-2L)		MI-FW-QLDC						Ice								
Periphyton (PT-50ML)		ALGAE-ID						Ice								
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli		Enterococci		X	Ice							
		Contract Lab														
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3			Ice							
		PCR-GULL2		PCR-GFD												
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS				Ice								
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-MS		W-PSNP-TQ			Ice							
						W-DIELDRIN										
		W-PCL-SQ-R		W-CARB-AA (5 ml of MCAA** Buffer Solution)		W-CT-CL-R										
Phytoplankton		DTY-QN-C		PKD-QN-BV					Ice							



RQ-2021-04-12-75					Collected By: Elizabeth Bates, Terry Riordan					
Customer: FDEP					Field Report Prepared by: Elizabeth Bates, Terry Riordan					
Project ID: SMP					Sampling Agency: FDEP					
WIN ID/Field ID:  WIN ID/Field ID: G3CE0041 Location: Fox Lake near Center					Comments:					
Matrix: Fresh					(Check One) ☒ Grab ☐ Composite					
Date and Time	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)	
4/14/2021 1336	6.87	84.9	26	7.01	0.31	0.4	1.5	895	0.44	
Central Lab please use top row for login purposes										
Parameter Suite	Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group	
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	H2SO4*	<2	1	B
		Lot #	Sa353110		Exp:	1/11/22				
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice	HNO3*	<2		
		Lot #			Exp:					
Filtered Nutrients (P125ML)	X	W-PO4-F	X	Field Filtered 0.45 µm Filter		X	Ice		1	B
		Filter Lot #	17135566							
		Syringe Lot #	79900							
Chlorophyll (BP-1L)	X	CHLSUITE-W			X	Ice			1	B
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-C-IC / W-COLOR / W-SO4-IC / W-TDS			X	Ice			1	B
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				Ice				
Macroinvertebrates (PJ-2L)		MI-FW-QLDC				Ice				
Periphyton (PT-50ML)		ALGAE-ID				Ice				
Microbiology (Contract Lab Bottle)		E Coli		F Coli		Enterococci				
		Contract Lab								
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3				
		PCR-GULL2		PCR-GFD						
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS						
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-MS		W-PSNP-TQ				
		W-PCL-SQ-R		W-CARB-AA (5 ml of MCAA** Buffer Solution)		W-DIELDIN				
				W-CT-CL-R						
Phytoplankton		DTY-QN-C		PKD-QN-BV						

Date of Request: 13-APR-2021
 Created By: BOMAN_L On: 13-APR-2021
 Modified By: WATTS_J On: 15-APR-2021
 Customer: CEN-DIST
 Project: SMP
 Division:
 District: Central District
 Event Description: Faulk/Fox

Send Coolers To:

Phone: 407-897-4181
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Leif Boman
 Cooler Ship EMail: Leif.Boman@FloridaDEP.gov

Priority: 3
 Event Status: P
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 15-APR-2021
 Biology Request Reviewed By:
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 13-APR-2021
 Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Kalina Warren
 Report Notification EMail: Leif.Boman@FloridaDEP.gov

Comments: Bottle Group A: Faulk
 Bottle Group B: Fox

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices	
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices	
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)	
Color (true)			
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices	
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices	
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	
Bottle Type: BP-1L		Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry	
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L	
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L	
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L	
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices	
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices	
Bottle Type: P-125ML		Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	