

RQ-2021-04-19-23

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 5/19/2021 10:35

*Cooler Temperature	Samples Frozen?	* All Samples In Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
3.9				11		✓			92938016641

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒

Evidence Tape intact?

Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐

Containers intact?

Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No ☐ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☒ Init: IM

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☐ No ☐ NA ☒ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☐ NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/checked by: IM

Date: 5/19/2021

Event contains NCRs (Y/N)? ☒

Salt Creek SMP
Event ID: CEN-DIST-2021-05-19-01 (SMP)
Date Received: 19-MAY-2021 10:35

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:10/28/21
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	219019 exp: 7/1/22
Chlorine Test Strips	0129 exp: 03/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 5/18/2021
Customer: CEN-DIST
RQ: RQ-2021-04-19-23

Collected By: Victoria Schwartz, Leif Boman
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Salt Creek @ Packard Ave	 G2CE0088

RELINQUISHED BY(SIGNATURE):

Victoria Schwartz

DATE/TIME: 5/18/2021
1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

IM

Rec'd/Inspected

Date:

5/19/21



RQ-2021-04-19-23	Collected By: Victoria Schwartz, Leif Boman
Customer: FDEP	Field Report Prepared by: Victoria Schwartz, Leif Boman
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID: 
 WIN ID/Field ID: G2CE0088

Comments:

Location: Salt Creek @ Packard Ave

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
5/18/2021 1325	6.34	73.9	22.3	7.47	0.1	0.2	0.2	4435	2.37

Central Lab please use top row for login purposes

Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group			
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice		H2SO4*	<2						
	Lot #		Exp:											
Metals (P-500ML)	W-ICPMS		W-ICP		W-HARD		Ice		HNO3*	<2				
	Lot #		Exp:											
Filtered Nutrients (P125ML)	W-PO4-F		Field Filtered 0.45 um Filter			Ice								
	Filter Lot #													
	Syringe Lot #													
Chlorophyll (BP-1L)	CHLSUITE-W				Ice									
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W- TDS				Ice									
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				Ice									
Macroinvertebrates (PJ-2L)	MI-FW-QLDC				Ice									
Periphyton (PT-50ML)	ALGAE-ID				Ice									
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli		Enterococci					x	Ice	1	A
	Contract Lab													
Molecular (QPCR-P-500ML)	PCR-HF183		PCR-BacR		PCR-DG3		Ice							
	PCR-GULL2		PCR-GFD											
Tracers (BG-500ML)	W-E8321-DI		W-E8321-MS			Ice								
Pesticides (BG-500ML) (BG-1L)	X	W-E8321-DI	X	W-E8321-MS		X	W-PSNP-TQ	x	Ice	10	A			
					X	W-DIELDRIN								
	X	W-PCL-SQ-R	X	W-CARB-AA (5 ml of MCAA** Buffer Solution)		X	W-CT-CL-R							
Phytoplankton	DTY-QN-C		PKD-QN-BV		Ice									

Date of Request: 12-MAR-2021
 Created By: BOMAN_L On: 12-MAR-2021
 Modified By: JASROTIA_P On: 23-MAR-2021
 Customer: CEN-DIST
 Project: SMP
 Division:
 District: Central District
 Event Description: Salt Creek SMP

Send Coolers To:

Phone: 407-897-4178
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Natalie Ayala
 Cooler Ship EMail: natalie.ayala@dep.state.fl.us

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 23-MAR-2021
 Biology Request Reviewed By: JASROTIA_P On: 23-MAR-2021
 Sampling Kit Required: YES Ship on: 09-APR-2021
 Sampling Kit Shipped: YES On: 02-APR-2021
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 19-APR-2021
 Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Kalina Warren
 Report Notification EMail: natalie.ayala@dep.state.fl.us

Comments: Bottle Group A: Pesticides
 Bottle Group B: Single E. coli

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2CICOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-DIELDRLIN	Template: DEFAULT	(EPA 8270E) Dieldrin (ultra low level) in water matrices by GC/MS/MS
W-PCL-SQ-R	Template: DFLT-MINUS	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.