

RQ-2021-05-10-07

Login Checklist

Login Station ID: #4

Shipping Method: FedEx UPS | HD | GreyhoundDate/Time of Receipt: 05/11/2021 @ 10:15

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.9°C				5		X			9293 8011 6420

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA ☒ Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken? Yes _____ No _____ Containers intact? Yes ☒ No _____

Caps on tight? Yes ☒ No _____

Sufficient Sample Volume: Yes ☒ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ☒ Init: Tulum

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

Acid Preserved Samples: pH < 2.0? Yes ☒ No _____ NA _____ Init: TulumW-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes _____ No _____ NA ☒ Init: Tulum

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: TulumDate: 05/10/2021Event contains NCRs (Y/N)? NoEvent ID: Lake Baldwin Outfall
CEN-DIST-2021-05-11-04 (SMP)

Date Received: 11-MAY-2021 10:15

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	#4 Temp Gun EXP:10/28/2021
pH Test Strips 0 – 6	N/A
pH Paper 0 – 3	N/A
pH Paper 0 – 13	210620 EXP:04/15/2023
Chlorine Test Strips	0261 EXP:05/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 5/10/2021
Customer: CEN-DIST
RQ: RQ-2021-05-10-07
Collected By: Elizabeth Bates, Leif Boman
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1
Delivery Method: FedEx
FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Lake Baldwin outfall 145m W of Goldenrod	 G2CE0243

RELINQUISHED BY(SIGNATURE):

Elizabeth Bates

DATE/TIME: 5/10/2021
1600EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *Tyler Reynolds*

Rec'd/Inspected

Date: *05/11/2021 @ 10:15*



RQ-2021-05-10-07

Customer: FDEP

Project ID: SMP

Collected By: Elizabeth Bates, Leif Boman

Field Report Prepared by: Elizabeth Bates, Leif Boman

Sampling Agency: FDEP

 WIN ID/Field ID: 
 WIN ID/Field ID: G2CE0243

Location: Lake Baldwin outfall 145m W of Goldenrod

Matrix: Fresh

Comments:

(Check One) ☒ Grab ☐ Composite

Date and Time	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
5/10/2021 1303	7.92	101	27.9	6.79	0.3	0.5	0.5	249.4	0.12

Central Lab please use top row for login purposes

Parameter Suite		Parameter Methods					Preservation			pH Check		# Bottles sent to Lab	Bottle Group	
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP					X	Ice	X	H2SO4*	X	<2	1	A
		Lot #		SA0353110		Exp:	1/11/22							
Metals (P-500ML)		W-ICPMS		W-ICP		W-HARD			Ice		HNO3*	<2		
		Lot #				Exp:								
Filtered Nutrients (P125ML)	X	W-PO4-F		X	Field Filtered 0.45 um Filter			X	Ice				1	A
		Filter Lot #		17135566										
		Syringe Lot #		79900										
Chlorophyll (BP-1L)	X	CHLSUITE-W					X	Ice		1			A	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS					X	Ice		1			A	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY						Ice						
Macroinvertebrates (PJ-2L)		MI-FW-QLDC						Ice						
Periphyton (PT-50ML)		ALGAE-ID						Ice						
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli		Enterococci		X	Ice				1	A
		Contract Lab												
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3			Ice					
		PCR-GULL2		PCR-GFD										
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS				Ice						
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-MS		W-PSNP-TQ			Ice					
						W-DIELDRIN								
		W-PCL-SQ-R		W-CARB-AA (5 ml of MCAA** Buffer Solution)		W-CT-CL-R								
Phytoplankton		DTY-QN-C		PKD-QN-BV					Ice					

Date of Request: 04-MAR-2021
 Created By: BOMAN_L On: 04-MAR-2021
 Modified By: JASROTIA_P On: 16-APR-2021
 Customer: CEN-DIST
 Project: SMP
 Division:
 District: Central District
 Event Description: Lake Baldwin Outfall

Send Coolers To:

Phone: 407-897-4178
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Natalie Ayala
 Cooler Ship Email: natalie.ayala@dep.state.fl.us

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 16-APR-2021
 Biology Request Reviewed By: JASROTIA_P On: 16-APR-2021
 Sampling Kit Required: YES Ship on: 30-APR-2021
 Sampling Kit Shipped: YES On: 27-APR-2021
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 10-MAY-2021
 Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Kalina Warren
 Report Notification Email: natalie.ayala@dep.state.fl.us

Comments:**Bottle Group A (Water) With 1 Samples:**

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

