

Login Checklist

RQ-2021-06-07-71

Login Station ID: #4

Shipping Method: FedEx UPS | HD | Greyhound

Date/Time of Receipt: 06/17/2021 9:20

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.9°C				4		X			9293 8014 3027

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles? Yes ☐ No ☐ NA ☒ Evidence Tape intact? Yes ☐ No ☐
 If Criminal, photographs taken? Yes ☐ No ☐ Containers intact? Yes ☒ No ☐
 Caps on tight? Yes ☒ No ☐
 Sufficient Sample Volume: Yes ☒ No ☐

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: Tulum

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0? Yes ☒ No ☐ NA ☐ Init: Tulum

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☐ NA ☒ Init: Tulum

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: Tulum

Date: 06/17/2021 Event contains NCRs (Y/N)? ☒

Event ID: Luma/Jane
CEN-DIST-2021-06-17-02 (SMP)

Page 1 of 2, 06/15 Date Received: 17-JUN-2021 09:20

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	#4 Temp Gun EXP:10/28/2021
pH Test Strips 0 – 6	N/A
pH Paper 0 – 3	N/A
pH Paper 0 – 13	210620 EXP:04/15/2023
Chlorine Test Strips	0261 EXP:05/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 6/16/2021
Customer: CEN-DIST
RQ: RQ-2021-06-07-71


Collected By: Victoria Schwartz, Katie March
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Lake Lurna W	 G4CE0203

RELINQUISHED BY(SIGNATURE):

V. A. March

DATE/TIME: 6/16/2021

1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *Tyler N*

Rec'd/Inspected

Date: *06/17/2021 09:20*



RQ-2021-06-07-71	Collected By: Victoria Schwartz, Katie March
Customer: FDEP	Field Report Prepared by: Victoria Schwartz, Katie March
Project ID: SMP	Sampling Agency: FDEP
WIN ID/Field ID:  WIN ID/Field ID: G4CE0203	Comments:

Location: Lake Lurna W

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPTH)			
6/16/2021 1255	6.1	81	30.3	7.36	0.3	1.5	2.7	193.2	0.09			
Central Lab please use top row for login purposes												
Parameter Suite	Parameter Methods					Preservation	pH Check	# Bottles sent to Lab	Bottle Group			
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	B
		Lot #		SA1105060	Exp:	4/30/22						
Metals (P-500ML)		W-ICPMS		W-ICP		Ice		HNO3*		<2		
		Lot #			Exp:							
Filtered Nutrients (P125ML)	X	W-PO4-F		X	Field Filtered 0.45 um Filter		X	Ice			1	B
		Filter Lot #		17135566								
		Syringe Lot #		1091364								
Chlorophyll (BP-1L)	X	CHLSUITE-W			X	Ice					1	B
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS			X	Ice					1	B
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				Ice						
Macroinvertebrates (PJ-2L)		MI-FW-QLDC				Ice						
Periphyton (PT-50ML)		ALGAE-ID				Ice						
Microbiology (Contract Lab Bottle)		E Coli			F Coli		Enterococci		Ice			
		Contract Lab										
Molecular (QPCR-P-500ML)		PCR-HF183			PCR-BacR		PCR-DG3		Ice			
		PCR-GULL2			PCR-GFD							
Tracers (BG-500ML)		W-E8321-DI			W-E8321-MS				Ice			
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS			W-PSNP-TQ			Ice			
		W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA** Buffer Solution)			W-DIELDRIN						
						W-CT-CL-R						
Phytoplankton		DTY-QN-C			PKD-QN-BV				Ice			

Date of Request: 09-JUN-2021
 Created By: BOMAN_L On: 09-JUN-2021
 Modified By: JASROTIA_P On: 09-JUN-2021
 Customer: CEN-DIST
 Project: SMP
 Division:
 District: Central District
 Event Description: Luma/Jane

Send Coolers To:

Phone: 407-897-4181
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Leif Boman
 Cooler Ship EMail: Leif.Boman@FloridaDEP.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 09-JUN-2021
 Biology Request Reviewed By: JASROTIA_P On: 09-JUN-2021
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 09-JUN-2021
 Logged In By: SHAIK_A On: 10-JUN-2021

Send Final Report To:

3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Matt Bearden
 Report Notification EMail: Matthew.Bearden@FloridaDEP.gov

Comments: Bottle Group A: Lake Jane
 Bottle Group B: Lake Luma

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices	
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices	
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)	
Color (true)			
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices	
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices	
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	
Bottle Type: BP-1L		Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry	
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L	
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L	
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L	
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices	
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices	
Bottle Type: P-125ML		Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	