

Login Checklist

RQ- 2021-07-12-53

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 7/ 14 /21 @ 9:20

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.6				12		✓			9293 8013 0440

COOLER CHECK

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ✓

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ✓

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ✓ No _____

Caps on tight?

Yes ✓ No _____

Sufficient Sample Volume:

Yes ✓ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ✓ Init: KK

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes ✓ No _____ NA _____ Init: KK

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA ✓ Init: KK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: KK

Date: 7/ 14 /21

Event contains NCRs (Y/N)? N

EventID: Unnamed Branch (x2)
CEN-DIST-2021-07-14-04 (SMP)

— Date Received: 14-JUL-2021 09:20 —

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #5 EXP:10-28-21
pH Test Strips 0 – 6	Lot#210620 EXP:4-15-23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#210620 EXP:4-15-23
Chlorine Test Strips	Lot#0261 EXP:5-23

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM


Date: 7/13/2021
Customer: CEN-DIST
RQ: RQ-2021-07-12-53
Collected By: Leif Boman,
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Unnamed Branch @ SR50	 G2CE0253
Unnamed Branch @ Bridgeway Rd	 G2CE0245

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 7/13/2021
1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *KVL*

Rec'd/Inspected

Date: *7.14.21/0920*



RQ-2021-07-12-53

Collected By: Leif Boman,

Customer: FDEP

Field Report Prepared by: Leif Boman,

Project ID: SMP

Sampling Agency: FDEP

Comments:

WIN ID/Field ID:



WIN ID/Field ID: G2CE0253

Location:

Location: Unnamed Branch @ SR50

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPTH)
7/13/2021 1342	5.4	67.4	26.7	6.62	0.3	1	1	162.9	0.08

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # _____ Exp: _____	Ice H2SO4*	<2		
Metals (P-500ML)	W-ICPMS W-ICP W-HARD Lot # _____ Exp: _____	Ice HNO3*	<2		
Filtered Nutrients (P125ML)	W-PO4-F Field Filtered 0.45 µm Filter Filter Lot # _____ Syringe Lot # _____	Ice			
Chlorophyll (BP-1L)	CHLSUITE-W	Ice			
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-CHC / W-COLOR / W-SO4-IC / W-TDS	Ice			
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	Ice			
Macroinvertebrates (PJ-2L)	MI-FW-QLDC Formalin Lot # _____	Formalin			
Periphyton (PT-50ML)	ALGAE-ID	Ice			
Microbiology (Contract Lab Bottle)	X E Coli F Coli Enterococci Contract Lab	x Ice		1	A
Molecular (QPCR-P-500ML)	PCR-HF183 PCR-BacR PCR-DG3 PCR-GULL2 PCR-GFD	Ice			
Tracers (BG-500ML)	W-E8321-DI W-E8321-MS	Ice			
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI W-E8321-MS W-PSNP-TQ W-PCL-TQ-R W-CARB-AA (5 ml of MCAA** Buffer Solution) W-CT-CL-R	Ice			
Phytoplankton	DTY-QN-C PKD-QN-BV	Ice			



RQ-2021-07-12-53

Customer: FDEP

Project ID: SMP

Collected By: Leif Boman,

Field Report Prepared by: Leif Boman,

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G2CE0245

Comments:

Location:

Location: Unnamed Branch @ Bridgeway Rd

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. ©	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
7/13/2021 1403	5.41	68.4	27.3	6.54	0.3	0.9	0.9	162.4	0.08

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP	Ice H2SO4*	<2		
	Lot # Exp:				
Metals (P-500ML)	W-ICPMS W-ICP W-HARD	Ice HNO3*	<2		
	Lot # Exp:				
Filtered Nutrients (P125ML)	W-PO4-F Field Filtered 0.45 um Filter	Ice			
	Filter Lot # Syringe Lot #				
Chlorophyll (BP-1L)	CHLSUITE-W	Ice			
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-C-IC / W-COLOR / W-SO4-IC / W- TDS	Ice			
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	Ice			
Macroinvertebrates (PJ-2L)	MI-FW-QLDC Formalin Lot #	Formalin			
Periphyton (PT-50ML)	ALGAE-ID	Ice			
Microbiology (Contract Lab Bottle)	X E Coli F Coli Enterococci Contract Lab	x Ice		1	A
Molecular (QPCR-P-500ML)	PCR-HF183 PCR-BacR PCR-DG3 PCR-GULL2 PCR-GFD	Ice			
Tracers (BG-500ML)	W-E8321-DI W-E8321-MS	Ice			
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI W-E8321-MS W-PSNP-TQ W-PCL-TQ-R W-CAR8-AA (5 ml of MCAA** Buffer Solution) W-CT-CL-R	Ice			
Phytoplankton	DTY-QN-C PKD-QN-BV	Ice			

Printed: 7/14/2021 11:06:17 AM

Page 1 of 1

Date of Request: 02-JUL-2021
Created By: BOMAN_L On: 02-JUL-2021
Modified By: JASROTIA_P On: 06-JUL-2021
Customer: CEN-DIST
Project: SMP
Division:
District: Central District
Event Description: Unnamed Branch (x2)

Send Coolers To:

Phone: 407-897-4181
FL Dept. of Environmental Protection
3319 Maguire Blvd., Suite 232
Orlando, FL 32803-3767
Attn: Leif Boman
Cooler Ship EMail: Leif.Boman@FloridaDEP.gov

Priority: 3
Event Status: A
Criminal Investigation: NO
Chemistry Request Reviewed By:
Biology Request Reviewed By: JASROTIA_P On: 06-JUL-2021
Sampling Kit Required: NO Ship on:
Sampling Kit Shipped:
Sampling Kit Packed By:
Preservatives Needed: NO
Date to Receive Samples: 12-JUL-2021
Logged In By:

Send Final Report To:

3319 Maguire Blvd., Suite 232

Orlando, FL 32803-3767
Attn: Matt Bearden
Report Notification EMail: Matthew.Bearden@FloridaDEP.gov

Comments:

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-250ML-WO-THI Number of Bottles: 2 Preserved With: ICE
ECOLI-18QT Template: DEFAULT (SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems