

Login Checklist

RQ- **2021 - 11 - 01 - 20**

Login Station ID: **# 3**

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: **12/08/2021 / 09:55**

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.5C				5		X			5225 5540 2344

COOLER CHECK

***All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.**

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. **NCR#** _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. **NCR#** _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. **NCR#** _____
- If coolers or samples are received late; identify the affected samples in an NCR. **NCR#** _____

Chain of Custody/ Field Sheet(s) Included?

Yes **X** No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No **X**

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA **X**

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes **X** No _____

Caps on tight?

Yes **X** No _____

Sufficient Sample Volume:

Yes **X** No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. **NCR#** _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No **X** Init: **ABS/**

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: **ABS/**

If chlorine is detected, generate an NCR listing affected sample IDs . **NCR#** _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

****Acid Preserved Samples:** pH < 2.0?

Yes **X** No _____ NA _____ Init: **ABS/**

****W-1-4-DIOX** (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA **X** Init: **ABS**

If samples were not preserved correctly, generate an NCR listing affected sample IDs . **NCR#** _____

Coolers Unpacked/Checked by: **ABS/**

Date: **12/08/2021**

Event contains NCRs (Y/N)? **N**

Event ID: **Wekiwa River**

- CEN-DIST-2021-12-08-01 (SMP)

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IRTG # 3 EXP:10/19/2022
pH Test Strips 0 – 6	LOT # 223819AV EXP:08/30/2023
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT 207621 EXP:03/15/2024
Chlorine Test Strips	0261 2023/05

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: ABS

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 12/7/2021
Customer: CEN-DIST
RQ: RQ-2021-11-01-20
Collected By: Leif Boman, Victoria Schwartz
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB


Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Wekiva River 2km DS of Blackwater Creek	 G2CE0244

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 12/7/2021
1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: A.SHAIK

Rec'd/Inspected
Date: 12/08/2021



RQ-2021-11-01-20	Collected By: Leif Boman, Victoria Schwartz
Customer: FDEP	Field Report Prepared by: Leif Boman, Victoria Schwartz
Project ID: SMP	Sampling Agency: FDEP
WIN ID/Field ID:  WIN ID/Field ID: G2CE0244	Comments:

Location:

Location: Wekiva River 2km DS of Blackwater Creek

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. ©	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
12/7/2021 1224	6.64	72.8	19.7	7.17	0.3	1.3	1.3	762	0.37

Parameter Suite	Parameter Methods			Preservation		pH Check		# Bottles sent to Lab	Bottle Group				
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A	
		Lot #	SA1105060		Exp:	4/30/22							
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD		Ice		HNO3*		<2		
		Lot #			Exp:								
Filtered Nutrients (P125ML)	X	W-PO4-F		X	Field Filtered 0.45 µm Filter			x	Ice	1	A		
		Filter Lot #	17135566										
		Syringe Lot #	1112035										
Chlorophyll (BP-1L)	X	CHLSUITE-W			X	Ice				1	A		
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CHC / W-COLOR / W-SO4-IC / W-TDS			X	Ice				1	A		
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				Ice							
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin							
Periphyton (PT-50ML)		ALGAE-ID				Ice							
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli		Enterococci	x	Ice	1	A			
		Contract Lab											
Molecular (QPCR-P-500ML)		PCR-HF1B3		PCR-BacR		PCR-DG3		Ice					
		PCR-GULL2		PCR-GFD									
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS		Ice							
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-MS		W-PSNP-TQ		Ice					
		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA** Buffer Solution)		W-CT-CL-R							
Phytoplankton		DTY-QN-C		PKD-QN-BV		Ice							

Date of Request: 27-SEP-2021
 Created By: BEARDEN_M On: 27-SEP-2021
 Modified By: JASROTIA_P On: 14-OCT-2021
 Customer: CEN-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Central District
 Event Description: Wekiva River

Send Coolers To:

Phone: 407-897-4123
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Matthew Bearden
 Cooler Ship EMail: matthew.bearden@floridadep.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 13-OCT-2021
 Biology Request Reviewed By: JASROTIA_P On: 14-OCT-2021
 Sampling Kit Required: YES Ship on: 22-OCT-2021
 Sampling Kit Shipped: YES On: 26-OCT-2021
 Sampling Kit Packed By: ROBERTS_Z
 Preservatives Needed: NO
 Date to Receive Samples: 05-NOV-2021
 Logged In By: SHAIK_A On: 08-DEC-2021

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Matthew Bearden
 Report Notification EMail:
 matthew.bearden@floridadep.gov; victoria.schwartz@floridadep.gov

Comments:**Bottle Group A (Water) With 1 Samples:**

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

