

RQ-2021-03-29-63

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 4/16/2021 9:30

*Cooler Temperature	Samples Frozen? YES	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
		HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
0.7				4		✓			4751 8781 0842

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☒Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No ☐ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☒ Init: IM

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☒ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☐ NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IM

Date: 4/16/2021

Event contains NCRs (Y/N)? ☒Event ID: 2021 SMP : Collier County
SO-DIST-2021-04-16-03 (SMP)

Date Received: 16-APR-2021 09:30

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:10/28/21
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	231019 exp: 11/1/22
Chlorine Test Strips	0129 exp: 03/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

2021 SMP : Collier County

last revised Jan 25, 2018

Customer: SO-DIST

Requester: Chris Hormuth

Field Report Prepared By: Danny B

Project ID: SMP

Collected By: Danny BergerSampling Agency: CCPC

Location <u>WCOCORIV</u>		☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>04-15-2021</u> Time <u>11:11</u>	Eastern Central	Composite end Date _____ Time _____	Bottle Group(s) (See pg 2) <u>A</u>
Field ID <u>AF64475</u>		Matrix (type, e.g., Salt, Fresh, etc) <u>Fresh</u>		Diss. Oxygen <u>27.9%, 2.36mg/L</u>	Total Res. Chlorine (mg/L) _____	
WIN/STORET # _____		Temp (C) <u>23.6</u>	pH <u>7.36</u>	Sample Depth <u>0.2</u>	Sp. Conductance (umho/cm) <u>1050</u>	
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt) <u>0.52</u>	Comments <u>Secchi: 0.4m Total Depth: 0.4m</u>			
Location <u>N Naples</u>		☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>04-15-2021</u> Time <u>10:35</u>	Eastern Central	Composite end Date _____ Time _____	Bottle Group(s) (See pg 2) <u>A</u>
Field ID <u>AF64478</u>		Matrix (type, e.g., Salt, Fresh, etc) <u>Fresh</u>		Diss. Oxygen <u>47.8%, 3.77mg/L</u>	Total Res. Chlorine (mg/L) _____	
WIN/STORET # _____		Temp (C) <u>27.4</u>	pH <u>7.23</u>	Sample Depth <u>0.3</u>	Sp. Conductance (umho/cm) <u>1036</u>	
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt) <u>0.51</u>	Comments <u>Secchi: 1.20m Total Depth: 1.20m</u>			
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____	Eastern Central	Composite end Date _____ Time _____	Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen ☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN/STORET #		Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)	
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)	Comments			
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____	Eastern Central	Composite end Date _____ Time _____	Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen ☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN/STORET #		Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)	
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)	Comments			

Relinquished By: <u>Danny Berger</u>	Date/Time <u>04-15-2021 / 16:00</u>	Shipping Method <u>FedEx</u>	Number of Coolers Shipped: <u>1</u>	Received By: <u>IM</u>	Date/Time <u>4/16/21 9:30</u>
---	--	---------------------------------	--	---------------------------	----------------------------------

Group: A	Bottle Type:	QPCR-P-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	PCR-BACR						
	PCR-DG3						
	PCR-HF183						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	CH2CICOOH Pre-Preserved	Enter Number of Bottles Sent to Lab	
	W-CARB-AA						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab	
	W-CT-CI-R						
	W-DIELDRLIN						
	W-PCL-SQ-R						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	W-E8321-DI						
	W-E8321-MS						
Group: A	Bottle Type:	BG-1L	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab	
	W-PSNP-TQ						
Group: B	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	
	PCR-BACR						
	PCR-DG3						
	PCR-HF183						
Group: B	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	
	W-E8321-DI						
	W-E8321-MS						

Date of Request: 11-MAR-2021
 Created By: HORMUTH_C On: 11-MAR-2021
 Modified By: JASROTIA_P On: 16-MAR-2021
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Event Description: 2021 SMP : Collier County

Send Coolers To:

Phone: 239-252-7806
 Collier County Pollution Control Lab
 3339 Tamiami Trail East, Suite 304
 Naples, FL 34112
 Attn: Geoff Rosenaw
 Cooler Ship Email:
 Chris.Hormuth@FloridaDEP.gov;Geoffrey.Rosenaw@colliercoun
 tyfl.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 16-MAR-2021
 Biology Request Reviewed By: JASROTIA_P On: 16-MAR-2021
 Sampling Kit Required: YES Ship on: 19-MAR-2021
 Sampling Kit Shipped: YES On: 17-MAR-2021
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 29-MAR-2021
 Logged In By:

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Chris Hormuth
 Report Notification Email:
 Nicole.Reistad@FloridaDEP.gov;Kirby.Wolfe@dep.state.fl.us;Ga
 ry.Snorek@dep.state.fl.us;Chris.Hormuth@FloridaDEP.gov;Willia
 m.Mullen@FloridaDEP.gov

Comments: Group A: (COCAT41) Pesticides, Markers
 Group B: Markers, Tracers

Bottle Group A (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2CICOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-DIELDRLIN	Template: DEFAULT	(EPA 8270E) Dieldrin (ultra low level) in water matrices by GC/MS/MS
W-PCL-SQ-R	Template: DFLT-MINUS	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Bottle Group B (Water) With 2 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 2	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE

Bottle Group B (Water) With 2 Samples:

Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.