

RQ- 2021-08-02-16

Login Checklist

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | GreyhoundDate/Time of Receipt: 8/ 10 /21 @ 9:40

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
-0.1				9		✓			9293 8015 8177
-1.1				8		✓			9293 8015 8122

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 °C (above 10.0 °C for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ✓

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ✓ No _____

Caps on tight?

Yes ✓ No _____

Sufficient Sample Volume:

Yes ✓ No _____If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ✓ No ✓ Init: 1/K

Chlorine detected? (One container checked per Field ID)

Yes _____ No ✓ Init: 1/K

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ✓ No _____ NA _____ Init: 1/K

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ✓ Init: 1/K

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: 1/KDate: 8/ 10 /21Event contains NCRs (Y/N)? NEvent ID: 2021 SMP : Myakka
SO-DIST-2021-08-10-02 (SMP)

Date Received: 10-AUG-2021 09:40

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Infrared Thermometer ID:	IR TEMP GUN #5 EXP:10-28-21
pH Test Strips 0 – 6	Lot#210620 EXP:4-15-23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#210620 EXP:4-15-23
Chlorine Test Strips	Lot#0261 EXP:5-23

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 8/9/2021
Customer: SO-DIST
RQ: RQ-2021-08-02-76

Collected By: Thomas Baker, Monica Jaeger
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB


Number of Coolers Shipped: 2

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
BrandyBranch@NWLilyCoRd	 G3SD0201
Osborn Branch	 G3SD0179
BRANDY BRANCH @ SR 70	 G3SD0083
LAKE MYAKKA (LOWER) @ MIDDLE	 G3SD0107

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 8/9/2021 1400
EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *kh*

Rec'd/Inspected

Date: *8.10.21/0940*



RQ-2021-08-02-76	Collected By: Thomas Baker, Monica Jaeger
Customer: FDEP	Field Report Prepared by: Thomas Baker, Monica Jaeger
Project ID: SMP	Sampling Agency: FDEP
WIN ID/Field ID:  WIN ID/Field ID: G3SD0201	Comments: Microbiology sample(s) submitted to contract laboratory

Location:
Location: BrandyBranch@NWLilyCoRd

Matrix: Fresh (Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. ©	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
8/9/2021 940	2	24.3	25.11	5.3	0.3	0.3	0.95	183.5	0.09

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # _____ Exp: _____	Ice H2SO4*	<2		
Metals (P-500ML)	W-ICPMS / W-ICP / W-HARD Lot # _____ Exp: _____	Ice HNO3*	<2		
Filtered Nutrients (P125ML)	W-PO4-F / Field Filtered 0.45 µm Filter Filter Lot # _____ Syringe Lot # _____	Ice			
Chlorophyll (BP-1L)	CHLSUITE-W	Ice			
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS	Ice			
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	Ice			
Macroinvertebrates (PJ-2L)	MI-FW-QLDC / Formalin Lot # _____	Formalin			
Periphyton (PT-50ML)	ALGAE-ID	Ice			
Microbiology (Contract Lab Bottle)	X E Coli / F Coli / Enterococci X Contract Lab	x Ice		1	D
Molecular (QPCR-P-500ML)	PCR-HF183 / PCR-BacR / PCR-DG3 PCR-GULL2 / PCR-GFD	Ice			
Tracers (BG-500ML)	W-E8321-DI / W-E8321-MS	Ice			
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI / W-E8321-MS / W-PSNP-TQ W-PCL-TQ-R / W-CARB-AA (5 ml of MCAA** Buffer Solution) / W-CT-CL-R	Ice			
Phytoplankton	DTY-QN-C / PKD-QN-BV	Ice			



RQ-2021-08-02-76

Customer: FDEP

Project ID: SMP

Collected By: Thomas Baker, Monica Jaeger

Field Report Prepared by: Thomas Baker, Monica Jaeger

Sampling Agency: FDEP

 WIN ID/Field ID: 
 WIN ID/Field ID: G3SD0179

Comments: Microbiology sample(s) submitted to contract laboratory

Location:

Location: Osborn Branch

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
8/9/2021 1005	0.6	7.6	27.03	6.2	0.3	0.5	0.7	190.2	0.09

Parameter Suite	Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	
		Lot #	SA1105060		Exp:	04/30/22		X	<2
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice	HNO3*		<2
		Lot #			Exp:				
Filtered Nutrients (P125ML)	X	W-PO4-F		X	Field Filtered 0.45 µm Filter				
		Filter Lot #	17162587						
		Syringe Lot #	1091364						
Chlorophyll (BP-1L)	X	CHLSUITE-W			X	Ice			
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS			X	Ice			
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				Ice			
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin			
Periphyton (PT-50ML)		ALGAE-ID				Ice			
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli		Enterococci			
	X	Contract Lab			X	Ice			
Molecular (QPCR-P-500ML)	X	PCR-HF183	X	PCR-BacR	X	PCR-DG3			
		PCR-GULL2		PCR-GFD					
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS		Ice			
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-MS		W-PSNP-TQ			
		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA™ Buffer Solution)		W-CT-CL-R			
Phytoplankton		DTY-QN-C		PKD-QN-BV		Ice			



RQ-2021-08-02-76

Collected By: Thomas Baker, Monica Jaeger

Customer: FDEP

Field Report Prepared by: Thomas Baker, Monica Jaeger

Project ID: SMP

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G3SD0083

Comments: Microbiology sample(s) submitted to contract laboratory

Location:

Location: BRANDY BRANCH @ SR 70

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
8/9/2021 1050	6.28	80	27.74	6.89	0.3	0.9	0.9	747	0.36

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	C
		Lot # SA1105060		Exp:	04/30/22							
Metals (P-500ML)		W-ICPMS		W-ICP		W-HARD	Ice	HNO3*		<2		
		Lot #		Exp:								
Filtered Nutrients (P125ML)	X	W-PO4-F	X	Field Filtered 0.45 µm Filter		X	Ice		1	C		
		Filter Lot #		17162587								
		Syringe Lot #		007993								
Chlorophyll (BP-1L)	X	CHLSUITE-W			X	Ice	1		C			
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-C / W-COLOR / W-SO4-IC / W-TDS			X	Ice	1		C			
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				Ice						
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin						
Periphyton (PT-50ML)		ALGAE-ID				Ice						
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli		Enterococci	X		Ice	1	C	
	X	Contract Lab										
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3						
		PCR-GULL2		PCR-GFD								
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS			Ice					
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-MS		W-PSNP-TQ	X	Ice	4	C		
		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA** Buffer Solution)	X	W-CT-CL-R						
Phytoplankton		DTY-QN-C		PKD-QN-BV			Ice					



RQ-2021-08-02-76

Customer: FDEP

Project ID: SMP

Collected By: Thomas Baker, Monica Jaeger

Field Report Prepared by: Thomas Baker, Monica Jaeger

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G3SD0107

Comments:

Location:

Location: LAKE MYAKKA (LOWER) @ MIDDLE

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
8/9/2021 1220	4.12	55.4	31.86	6.82	0.3	0.5	1.5	285	0.13

Parameter Suite	Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	
		Lot #	SA1105060		Exp:	04/30/22		X	<2
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice	HNO3*		<2
		Lot #			Exp:				
Filtered Nutrients (P125ML)	X	W-PO4-F	X	Field Filtered 0.45 µm Filter		X	Ice		
		Filter Lot #	17162587					1	A
		Syringe Lot #	1091364						
Chlorophyll (BP-1L)	X	CHLSUITE-W			X	Ice		1	A
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-C / W-COLOR / W-SO4-IC / W-TDS			X	Ice		1	A
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				Ice			
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin			
Periphyton (PT-50ML)		ALGAE-ID				Ice			
Microbiology (Contract Lab Bottle)		E Coli		F Coli		Enterococci			
		Contract Lab				Ice			
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3			
		PCR-GULL2		PCR-GFD					
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS		Ice			
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-MS		W-PSNP-TQ			
		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA** Buffer Solution)		W-CT-CL-R			
Phytoplankton		DTY-QN-C		PKD-QN-BV		Ice			

Benchmark EnviroAnalytical, Inc.
1001 Corporate Ave. Suite 102
North Port, FL 34289
(941) 625-3137 / (941) 240-3071 fax

BEAS Sample Receipt Temp. 4.4 °C
Checked at Benchmark EA South E85086
With Temperature Gun ID #7

Client Name: FDEP
Address: 2600 Blair Stone Rd.
Tallahassee, FL, 32399
Phone: (850) 245-8085
Email: dep-overflowmicro@dep.state.fl.us

Bill to: Frances Moore
P.O. #: Lab B16970
B95341

Project Name: RQ-2021-08-02-76
~~RQ-2020-~~

Project Run/Location: LOWER MYAKKA

Laboratory Submission #:

521080217

Project Run/Location: LOWER MYAKKA		Station ID	Surface Water Sample Matrix ² (Fresh / Marine) Sample Type	Enterococci E.coli (SM9223B Quantitray)		Laboratory Sample #
			E.Coli = 250 mL ; Entero = 120 mL ; Fecal Coliform = 120 mL			
G3SD0201	☒ M / ☒ Grab	☒ E.coli /	Entero /	F.coli	Date & Time: 8/9/21 940	1
G3SD0179	☒ M / ☒ Grab	☒ E.coli /	Entero /	F.coli	Date & Time: 8/9/21 1005	2
G3SD0083	☒ M / ☒ Grab	☒ E.coli /	Entero /	F.coli	Date & Time: 8/9/21 1050	3
	F / M / Grab	E.coli /	Entero /	F.coli	Date & Time:	
	F / M / Grab	E.coli /	Entero /	F.coli	Date & Time:	
	F / M / Grab	E.coli /	Entero /	F.coli	Date & Time:	
	F / M / Grab	E.coli /	Entero /	F.coli	Date & Time:	
	F / M / Grab	E.coli /	Entero /	F.coli	Date & Time:	
	F / M / Grab	E.coli /	Entero /	F.coli	Date & Time:	
	F / M / Grab	E.coli /	Entero /	F.coli	Date & Time:	
	F / M / Grab	E.coli /	Entero /	F.coli	Date & Time:	

¹ "Sample Type" is used to indicate whether the sample was a grab (G) or whether it was a composite (C).

² "Sample Matrix" is used to indicate whether the sample is being discharged to drinking water (DW), groundwater (GW), surface water (SW), fresh surface water (FSW), saline surface water (SSW), soil, sediment (SDMT), or sludge (SLDG).

³ "Container Type" is used to indicate whether the container is plastic (P) or glass (G).

⁴ Sample must be refrigerated or stored in wet ice after collection. The maximum temperature during storage should be 6°C (42.8°F). Under "Preservative," list any preservatives that were added to the sample container.

Instructions:

- Each bottle has a label identifying sample ID, preservative, container type, client ID, and parameters for analysis.
- The following information should be added to each bottle label after collection with permanent black ink: date and time of collection, sampler's name or initials, and any field number or ID.
- All bottles not containing preservative may be rinsed with appropriate sample prior to collection.
- The client is responsible for documentation of the sampling event. Please note special sampling events on the sample custody form.

Laboratory Sample Acceptability:

pH < 2.0 BEAS Temperature: 4.4°C

1	Collector: <u>Monica Jaeger</u>	Date: <u>8/9/21</u>	Time:	Received By:	Date:	Time:
2	Relinquished by: <u>Monica Jaeger</u>	Date: <u>8/9/21</u>	Time: <u>1409</u>	Received By: <u>Michelle Murchant</u>	Date: <u>8/9/21</u>	Time: <u>1409</u>
3	Relinquished by:	Date:	Time:	Received By:	Date:	Time:
4	Relinquished by:	Date:	Time:	Received By:	Date:	Time:
5	Relinquished by:	Date:	Time:	Received By:	Date:	Time:

Date of Request: 20-JUL-2021
 Created By: BAKER_T On: 20-JUL-2021
 Modified By: WATTS_J On: 26-JUL-2021
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Event Description: 2021 SMP : Myakka

Send Coolers To:

Phone: 239-344-5716
 FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: William Mullen
 Cooler Ship EMail: William.Mullen@FloridaDEP.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 26-JUL-2021
 Biology Request Reviewed By: WATTS_J On: 26-JUL-2021
 Sampling Kit Required: YES Ship on: 26-JUL-2021
 Sampling Kit Shipped: YES On: 26-JUL-2021
 Sampling Kit Packed By: KLUG_K
 Preservatives Needed: NO
 Date to Receive Samples: 02-AUG-2021
 Logged In By:

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: William Mullen
 Report Notification EMail:
 Nicole.Reistad@FloridaDEP.gov; Kirby.Wolfe@dep.state.fl.us; Gary.Snorek@dep.state.fl.us; William.Mullen@FloridaDEP.gov; Monica.Jaeger@FloridaDEP.gov; Thomas.J.Baker@FloridaDEP.gov

Comments: Group A: (Lower Myakka) Freshwater Nutrients
 Group B: (Osborn) Freshwater Nutrients, E. coli, Markers
 Group C: (Brandy@70) Freshwater Nutrients, E. coli, W-CT-CI-R
 Group D: (Brandy@LilyCo) E. coli

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: NO BOTTLE LABEL	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: NO BOTTLE LABEL	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-BES-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) E. coli by Colilert/QT by BEA South in North Port
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: NO BOTTLE LABEL	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
SD-BES-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) E. coli by Colilert/QT by BEA South in North Port
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-Cl-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
-----------------------------	----------------------	---------------------

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-250ML-WI-THI Number of Bottles: 1 Preserved With: ICE
SD-BES-ECQ Template: DEFAULT (SM 9223 Quanti-Tray) E. coli by Colilert/QT by BEA South in North Port

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.