

RQ-2021-05-31-20

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 6/1/2021 14:25

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.9				21					

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No ☐ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☒ Init: IM

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☐ NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IM

Date: 6/1/2021

Event contains NCRs (Y/N)? ☒

Event ID:

Run 12

TLH-ROC-2021-06-01-02 (SMP)

Page 1 of 2, 06/15/2021 Date Received: 01-JUN-2021 14:25

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:10/28/21
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	219019 exp: 7/1/22
Chlorine Test Strips	0129 exp: 03/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 6/1/2021
Customer: TLH-DIST
RQ: RQ-2021-05-31-20

Collected By: Jonathan Woods, Jade Burtchett
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB


Number of Coolers Shipped: 1

Delivery Method: HandDelivered

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Watson Bayou South	 G3TLHR0006
Parker Bayou @ Mouth	 G3TLHR0043
Parker Creek @ Park	 G3TLHR0040

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 6/1/2021 1600
EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

IM

Rec'd/Inspected

Date:

6/1/21



RQ-2021-05-31-20	Collected By: Jonathan Woods, Jade Burtchett
Customer: FDEP	Field Report Prepared by: Jonathan Woods, Jade Burtchett
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID: 
WIN ID/Field ID: G3TLHR0006

Location: Watson Bayou South

Matrix: Marine

Comments:

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
6/1/2021 1100	7.38	108.4	27.3	7.91	0.3	1.4	3.6	44077	28.38

Central Lab please use top row for login purposes

Parameter Suite	Parameter Methods							Preservation			pH Check	# Bottles sent to Lab	Bottle Group				
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP					X	Ice	X	H2SO4*	X	<2	1	C			
		Lot #		1105060		Exp:		4/30/22									
Metals (P-500ML)		W-ICPMS		W-ICP			W-HARD		Ice		HNO3*		<2				
		Lot #				Exp:											
Filtered Nutrients (P125ML)	X	W-PO4-F		X	Field Filtered 0.45 um Filter			X	Ice				1	C			
		Filter Lot #		17162587													
		Syringe Lot #		79900													
Chlorophyll (BP-1L)	X	CHLSUITE-W					X	Ice						1	C		
Physical/Aggregate (Fresh) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W-TDS					Ice										
Physical/Aggregate (Marine) (P-1L)	X	Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY					X	Ice									
Macroinvertebrates (PJ-2L)		MI-FW-QLDC					Ice										
Periphyton (PT-50ML)		ALGAE-ID					Ice										
Microbiology (Contract Lab Bottle)		E Coli			F Coli		X	Enterococci							X	Ice	
		Contract Lab															
Molecular (QPCR-P-500ML)		PCR-HF183			PCR-BacR			PCR-DG3			Ice						
		PCR-GULL2			PCR-GFD												
Tracers (BG-500ML)		W-E8321-DI			W-E8321-MS				Ice								
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI			W-E8321-MS			W-PSNP-TQ		Ice							
								W-DIELDRIN									
		W-PCL-SQ-R			W-CARB-AA (5 ml of MCAA** Buffer Solution)			W-CT-CL-R									
Phytoplankton		DTY-QN-C			PKD-QN-BV			Ice									



RQ-2021-05-31-20	Collected By: Jonathan Woods, Jade Burtchett
Customer: FDEP	Field Report Prepared by: Jonathan Woods, Jade Burtchett
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID:  WIN ID/Field ID: G3TLHR0043 Location: Parker Bayou @ Mouth Matrix: Marine	Comments: (Check One) ☒ Grab ☐ Composite
---	--

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)
6/1/2021 1150	7.44	109.5	28.5	7.8	0.3	1.1	1.6	37785	23.9

Central Lab please use top row for login purposes

Parameter Suite	Parameter Methods						Preservation			pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP					X	Ice	X	H2SO4*	X	<2	1	B	
	Lot #		1105060		Exp:		4/30/22								
Metals (P-500ML)		W-ICPMS		W-ICP		W-HARD			Ice		HNO3*		<2		
	Lot #				Exp:										
Filtered Nutrients (P125ML)	X	W-PO4-F		X	Field Filtered 0.45 um Filter			X	Ice				1	B	
	Filter Lot #		17162587												
	Syringe Lot #		79900												
Chlorophyll (BP-1L)	X	CHLSUITE-W					X	Ice		1			B		
Physical/Aggregate (Fresh) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W- TDS							Ice						
Physical/Aggregate (Marine) (P-1L)	X	Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY						X	Ice				1	B	
Macroinvertebrates (PJ-2L)		MI-FW-QLDC							Ice						
Periphyton (PT-50ML)		ALGAE-ID							Ice						
Microbiology (Contract Lab Bottle)		E Coli		X	F Coli		X	Enterococci		X			Ice	2	B
		Contract Lab													
Molecular (QPCR-P-500ML)		PCR-HF183			PCR-BacR			PCR-DG3					Ice		
		PCR-GULL2			PCR-GFD										
Tracers (BG-500ML)		W-E8321-DI			W-E8321-MS				Ice						
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI			W-E8321-MS			W-PSNP-TQ					Ice		
								W-DIELDRIN							
		W-PCL-SQ-R			W-CARB-AA (5 ml of MCAA** Buffer Solution)			W-CT-CL-R							
Phytoplankton		DTY-QN-C			PKD-QN-BV			Ice							

RQ-2021-05-31-20

Collected By: Jonathan Woods, Jade Burtchett



Customer: FDEP

Field Report Prepared by: Jonathan Woods, Jade Burtchett

Project ID: SMP

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G3TLHR0040

Comments:

Location: Parker Creek @ Park

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)			
6/1/2021 1130	4.03	47.7	23.8	5.83	0.3	1.3	1.3	122.6	0.06			
Central Lab please use top row for login purposes												
Parameter Suite	Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group			
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A
		Lot #	1105060		Exp:	4/30/22						
Metals (P-500ML)		W-ICPMS	W-ICP	W-HARD		Ice		HNO3*		<2		
		Lot #			Exp:							
Filtered Nutrients (P125ML)	X	W-PO4-F	X	Field Filtered 0.45 um Filter	X	Ice					1	A
		Filter Lot #	17162587									
		Syringe Lot #	79900									
Chlorophyll (BP-1L)	X	CHLSUITE-W			X	Ice					1	A
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TDS			X	Ice					1	A
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				Ice						
Macroinvertebrates (PJ-2L)		MI-FW-QLDC				Ice						
Periphyton (PT-50ML)		ALGAE-ID				Ice						
Microbiology (Contract Lab Bottle)	X	E Coli	F Coli	Enterococci	X	Ice					1	A
Molecular (QPCR-P-500ML)	X	PCR-HF183	X	PCR-BacR	X	PCR-DG3	X	Ice			1	A
		PCR-GULL2		PCR-GFD					1	A		
Tracers (BG-500ML)	X	W-E8321-DI	X	W-E8321-MS	X	Ice						
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS	W-PSNP-TQ		Ice						
				W-DIELDRIN								
		W-PCL-SQ-R	W-CARB-AA (5 ml of MCAA** Buffer Solution)	W-CT-CL-R								
Phytoplankton		DTY-QN-C	PKD-QN-BV			Ice						

Date of Request: 29-APR-2021
 Created By: ECKLES_M On: 29-APR-2021
 Modified By: JASROTIA_P On: 03-MAY-2021
 Customer: TLH-ROC
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Not Applicable
 Event Description: Run 12

Send Coolers To:

Phone: 850-245-7586
 2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Michael Eckles
 Cooler Ship Email: Michael.eckles@floridadep.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 30-APR-2021
 Biology Request Reviewed By: JASROTIA_P On: 03-MAY-2021
 Sampling Kit Required: YES Ship on: 27-MAY-2021
 Sampling Kit Shipped: YES On: 26-MAY-2021
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: NO
 Date to Receive Samples: 31-MAY-2021
 Logged In By:

Send Final Report To:

2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Michael Eckles
 Report Notification Email:
 michael.eckles@FloridaDEP.gov; terry.green@floridadep.gov

Comments: Group A: WBID 1141A (0040)
 Group B: WBID 1141B (0043)
 Group C: WBID 1136 (0006)
 Group D: WBID 1142 (0015) & 1162 (0017)
 Group E: Blank
 No FedEx Labels

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction

Bottle Group A (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
FCOLI-MF	Template: DEFAULT	(SM 9222 D) Fecal coliforms by membrane filter method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group D (Water) With 2 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 2	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Bottle Group E (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.