

Klug, Kyle

From: Klug, Kyle
Sent: Friday, January 29, 2021 12:57 PM
To: Musson, Curtis
Cc: Ayres, Joshua
Subject: RQ-2021-01-25-15 & RQ2021-01-18-47 | Late coolers

Good afternoon,

The coolers for these two events arrived late and the expired short holds have been canceled based off of the SMP protocol for late samples.

Thank you,



Kyle Klug
Lab Technician IV
DEP Laboratories
Voice: 850.245.8153
Kyle.Klug@floridadep.gov

Login Checklist

RQ- 2021-01-18-47

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 1/ 29 /21 @ 11:35

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.3				11		✓			1278 4013 4841
-0.6				11		✓			1278 4013 4830
WV 0.4				16		✓			1278 4013 4852

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# 8621

Chain of Custody/ Field Sheet(s) Included? Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes _____ No ✓

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA ✓ Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken? Yes _____ No _____ Containers intact? Yes ✓ No _____

Caps on tight? Yes ✓ No _____

Sufficient Sample Volume: Yes ✓ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes ✓ No _____ Init: HK

Chlorine detected? (One container checked per Field ID) Yes _____ No ✓ Init: HK

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0? Yes ✓ No _____ NA _____ Init: HK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes _____ No _____ NA ✓ Init: HK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: HK Date: 1/ 29 /21 Event contains NCRs (Y/N)? Y

SMP - Bessey Creek Monthly 01/21 (SFS)
Event ID: SE-DIST-2021-01-29-01 (SMP)

Date Received: 29-JAN-2021 11:35

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Infrared Thermometer ID:	Temp Gun #5 EXP:10/28/2021
pH Test Strips 0 – 6	5/15/21 LOT#213316BV
pH Paper 0 – 3	
pH Paper 0 – 13	231019 EXP:11/01/2022
Chlorine Test Strips	8261 EXP:07/2021

Additional Comments:

1 ENT
30HL AS
1/29/21

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 1/27/2021
Customer: WQAP
RQ: RQ-2021-01-18-47

Collected By: Drew Liddick,
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 3

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Roebuck Creek @ Locks	 G2SE0029
DL 01/27/2021 FB Roebuck Creek @ Locks	 FB_012721
South Fork Slr @ Hosford Park	 G2SE0043
Bessey Creek @ Mouth	 G2SE0048

RELINQUISHED BY(SIGNATURE):

Drew Liddick

01/27/2021 1600
DATE/TIME:

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *KL*

Rec'd/Inspected Date: *1-29-21/1135*



RQ-2021-01-18-47

Customer: WQAP

Project ID: SMP

Collected By: Drew Liddick

Field Report Prepared By: Drew Liddick

Sampling Agency: FDEP

Place Label Here						Comments:				
WIN ID/Field ID: 										
G2SE0029										
Location: Roebuck Creek @ Locks										
Matrix: Fresh						(Check one) ☒ GRAB ☐ COMPOSITE				
Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPTH)
1/27/2021	1000 EST	4.39	49.1	20.7	7.34	0.2	0.3 ☒ VOB (S)	0.3	633	0.31
							Central Lab please use top row for login purposes			
	EST									
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				☒ Ice ☒ H2SO4*		☒ <2	1	B
		Lot # SA0293040		Exp:		1019/21				
Metals (P-500ML)		☒ W-ICPMS ☒ W-ICP ☒ W-HARD				☒ Ice ☒ HNO3*		☒ <2	1	B
		Lot # 116856		Exp:		03/31/22				
Filtered Nutrients (P125ML)		☒ W-PO4-F ☒ Field Filtered 0.45 µm Filter				☒ Ice			1	B
		Filter Lot #								
		Syringe Lot # 9303354								
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	B
Physical/Aggregate (Fresh) (P-1L)		☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-SO4-IC / W-TDS				☒ Ice			1	B
Physical/Aggregate (Marine) (P-1L)		☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				☐ Ice				
Macroinvertebrates (PJ-2L)		☐ MI-FW-QLDC				☐ Formalin				
Periphyton (PT-50ML)		☐ ALGAE-ID				☐ Ice				
Microbiology (Contract Lab Bottle)		☐ E Coli ☐ F Coli ☒ Enterococci				☒ Ice			1	B
		☐ Contract Lab								
Molecular (QPCR-P-500ML)		☒ PCR-HF183 ☒ PCR-BacR ☒ PCR-DG3				☒ Ice			1	B
		☐ PCR-GULL2 ☐ PCR-GFD ☐								
Tracers (BG-500ML)		☒ W-E8321-DI ☒ W-E8321-MS				☒ Ice			2	B
Pesticides (BG-500ML) (BG-1L)		☐ W-E8321-DI ☐ W-E8321-MS ☐ W-PSNP-TQ ☐ W-CT-CL-R				☐ Ice				
		☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution) ☐ W-DIELDRIN								
Phytoplankton/Periphyton		☐ DTM-QL-C ☐ PEN-QL-C ☐ DTY-QN-C ☐ PKD-QN-C				☐ Ice				
		☐ DTM-QN-C ☐ PRN-QN-C ☐ PKD-QN-BV								
Name: Drew Liddick						Signature: <i>Drew Liddick</i>			Date: 01/27/2021	

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution



RQ- 2021-01-18-47

Customer: WQAP

Project ID: SMP

Collected By: Drew Liddick,

Field Report Prepared By: Drew Liddick,

Sampling Agency: FDEP

BLANK

Field ID: FB 012721

Comments:

Matrix: FB

(Check one) ☐ COMPOSITE ☒ GRAB

Date

Time

DI Source: UF IFAS

1/27/2021

1015

EST

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # SA0293040 Exp:	☒ Ice ☒ H2SO4	☒ <2	1	D
Metals (P-500ML)	☒ W-ICPMS ☒ W-ICP Lot # 116856 Exp:	☒ Ice ☒ H2SO4	☒ <2	1	D
Filtered Nutrients (P125ML)	☒ W-PO4-F Filter ☒ Field Filtered 0.45 µm Filter Lot # Syringe Lot # 9303354	☒ Ice		1	D
Physical/Aggregate (Fresh) (P-1L)	☒ Alkalinity / W-F / W-TSS / TURBIDITY / W-CHC / W-COLOR / W-SO4-IC / W-IC / TDS	☒ Ice		1	D
Physical/Aggregate (Marine) (P-1L)	☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	☐ Ice			
Tracers (BG-500ML)	☐ W-E8321-DI ☐ W-E8321-MS	☐ Ice			
Pesticides (BG-500ML) (BG-1L)	☐ W-E8321-DI ☐ W-E8321-MS ☐ W-PSNP-TQ ☐ W-CT-CL-R ☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution) ☐ W-DIELDIN	☐ Ice			
Name: Drew Liddick		Signature: <i>Drew Liddick</i>		Date: 01/27/2021	

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution



RQ-2021-01-18-47

Customer: WQAP

Project ID: SMP

Collected By: Drew Liddick

Field Report Prepared By: Drew Liddick

Sampling Agency: FDEP

Place Label Here						Comments:				
WIN ID/Field ID: 										
G2SE0043										
Location: South Fork Slr @ Hosford Park										
Matrix: Marine						(Check one) ☒ GRAB ☐ COMPOSITE				
Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
1/27/2021	1045 EST	7.73	88.1	21.4	7.61	0.3	0.5 ☐ VOB (S)	4	3545	1.87
	1044	7.3	83.4	21.1	7.53	2.0	Central Lab please use top row for login purposes		5337	2.89
	1044 EST	7.35	84.2	21.1	7.5	3.5			5529	3
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				☒ Ice ☒ H2SO4*		☒ <2	1	C
		Lot # SA0293040		Exp: 10/19/21						
Metals (P-500ML)		☒ W-ICPMS ☒ W-ICP ☒ W-HARD				☒ Ice ☒ HNO3*		☒ <2	1	C
		Lot # 116856		Exp: 03/31/22						
Filtered Nutrients (P125ML)		☒ W-PO4-F ☒ Field Filtered 0.45 µm Filter				☒ Ice			1	C
		Filter Lot #								
		Syringe Lot # 9303354								
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	C
Physical/Aggregate (Fresh) (P-1L)		☐ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-C / W-COLOR / W-SO4-IC / W-TDS				☐ Ice				
Physical/Aggregate (Marine) (P-1L)		☒ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				☒ Ice			1	C
Macroinvertebrates (PJ-2L)		☐ MI-FW-QLDC				☐ Formalin				
Periphyton (PT-50ML)		☐ ALGAE-ID				☐ Ice				
Microbiology (Contract Lab Bottle)		☐ E Coli ☐ F Coli ☒ Enterococci				☒ Ice			1	C
Molecular (QPCR-P-500ML)		☒ PCR-HF183 ☒ PCR-BacR ☒ PCR-DG3				☒ Ice			1	C
		☐ PCR-GULL2 ☐ PCR-GFD ☐								
Tracers (BG-500ML)		☒ W-E8321-DI ☒ W-E8321-MS				☒ Ice			1	C
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-MS		W-PSNP-TQ		W-CT-CL-R		☐ Ice
		W-PCL-SQ-R		W-CARB-AA (5 ml of MCAA** Buffer Solution)		W-DIELDRIN				
Phytoplankton/Periphyton		DTM-QL-C		PEN-QL-C		DTY-QN-C		PKD-QN-C		☐ Ice
		DTM-QN-C		PRN-QN-C		PKD-QN-BV				
Name: Drew Liddick						Signature: <i>Drew Liddick</i>			Date: 01/27/2021	

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution



RQ-2021-01-18-47

Customer: WQAP

Project ID: SMP

Collected By: Drew Liddick

Field Report Prepared By: Drew Liddick

Sampling Agency: FDEP

Place Label Here						Comments:				
WIN ID/Field ID: G2SE0048										
Location: Bessey Creek @ Mouth										
Matrix: Marine						(Check one) ☒ GRAB ☐ COMPOSITE				
Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT _h)
1/27/2021	1200 EST	6.28	77.9	22.1	7.47	0.3	0.5 ☐ VOB (S)	2.8	23410	14.02
	1200	5.41	68.1	21.6	7.43	2.0	Central Lab please use top row for login purposes		28927	17.89
	1159 EST	5.47	69.6	21.9	7.36	2.3			28829	17.83
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				☒ Ice ☒ H2SO4*		☒ <2	1	A
		Lot #		Exp:						
Metals (P-500ML)		☒ W-ICPMS ☒ W-ICP ☒ W-HARD				☒ Ice ☒ HNO3*		☒ <2	1	A
		Lot #		Exp:						
Filtered Nutrients (P125ML)		☒ W-PO4-F ☒ Field Filtered 0.45 µm Filter				☒ Ice			1	A
		Filter Lot #								
		Syringe Lot #								
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	A
Physical/Aggregate (Fresh) (P-1L)		☐ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-SO4-IC / W-TDS				☐ Ice				
Physical/Aggregate (Marine) (P-1L)		☒ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				☒ Ice			1	A
Macroinvertebrates (PJ-2L)		☐ MI-FW-QLDC				☐ Formalin				
Periphyton (PT-50ML)		☐ ALGAE-ID				☐ Ice				
Microbiology (Contract Lab Bottle)		☐ E Coli ☐ F Coli ☒ Enterococci ☐ Contract Lab				☒ Ice			1	A
Molecular (QPCR-P-500ML)		☒ PCR-HF183 ☒ PCR-BacR ☒ PCR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD ☐				☒ Ice			1	A
Tracers (BG-500ML)		☒ W-E8321-DI ☒ W-E8321-MS				☒ Ice			1	A
Pesticides (BG-500ML) (BG-1L)		☒ W-E8321-DI ☒ W-E8321-MS ☒ W-PSNP-TQ ☒ W-CT-CL-R ☒ W-PCL-SQ-R ☒ W-CARB-AA (5 ml of MCAA** Buffer Solution) ☒ W-DIELDRIN				☒ Ice			12	A
Phytoplankton/Periphyton		DTM-QL-C PEN-QL-C DTY-QN-C PKD-QN-C DTM-QN-C PRN-QN-C				☐ Ice				
Name: Drew Liddick						Signature: <i>Drew Liddick</i>			Date: 01/27/2021	

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution

Date of Request: 07-JAN-2021
 Created By: SKAGGS_J On: 07-JAN-2021
 Modified By: JASROTIA_P On: 11-JAN-2021
 Customer: SE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southeast District
 Event Description: SMP - Bessey Creek Monthly 01/21 (SFSLR,Roebuck)

Send Coolers To:

Phone: (772) 448-5884
 FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Jordan Skaggs
 Cooler Ship EMail: jordan.skaggs@FloridaDEP.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 11-JAN-2021
 Biology Request Reviewed By: JASROTIA_P On: 11-JAN-2021
 Sampling Kit Required: YES Ship on: 15-JAN-2021
 Sampling Kit Shipped: YES On: 12-JAN-2021
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: YES
 Date to Receive Samples: 26-JAN-2021
 Logged In By:

Send Final Report To:

FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Drew Liddick
 Report Notification EMail:
 drew.liddick@FloridaDEP.gov;jordan.skaggs@floridadep.gov;and
 rew.luering@floridadep.gov

Comments: Lab Comments:
 2 - boxes nitric acid
 2 - boxes sulfuric acid

Sampler Comments:

Group A - 3211 - G2SE0048 (boat/canoe)
 Group B - 3210E - G2SE0029
 Group C - 3210C - G2SE0043
 Group D - Field Blank

4 nutrients, 3 micro,

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template:	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE

Bottle Group A (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-DIELDRIN	Template: DEFAULT	(EPA 8270E) Dieldrin (ultra low level) in water matrices by GC/MS/MS
W-PCL-SQ-R	Template: DFLT-MINUS	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO ₃
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Iron		
Magnesium		
Manganese		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Beryllium		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction

Bottle Group B (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Iron		
Magnesium		
Manganese		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Beryllium		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: HNO3
 W-ICP Template: (EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Calcium
 Iron
 Magnesium
 Manganese
 Zinc

W-ICPMS Template: (EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Aluminum
 Antimony
 Arsenic
 Beryllium
 Cadmium
 Chromium
 Copper
 Lead
 Nickel
 Selenium
 Silver
 Thallium

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
 W-TOC Template: DEFAULT (SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 1 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L Number of Bottles: 1 Preserved With: ICE
 ALKALINITY Template: DEFAULT (SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
 TURBIDITY Template: DEFAULT (EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
 W-BR-IC Template: DEFAULT (EPA 300.0 Rev. 2.1) Bromide in aqueous matrices
 W-F Template: DEFAULT (SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
 W-TSS Template: DEFAULT (SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: HNO3
 W-ICP Template: (EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Calcium
 Iron
 Magnesium
 Manganese
 Zinc

W-ICPMS Template: (EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Aluminum
 Antimony
 Arsenic
 Beryllium
 Cadmium
 Chromium
 Copper
 Lead
 Nickel
 Selenium
 Silver
 Thallium

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.