

Login Checklist

RQ- 2021-10-25-07

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 11/ 2 /21 @ 9:33

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.9				6		✓			5225 5540 2870

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ✓

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ✓

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ✓ No _____

Caps on tight?

Yes ✓ No _____

Sufficient Sample Volume:

Yes ✓ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ✓ No _____ Init: KK

Chlorine detected? (One container checked per Field ID)

Yes _____ No ✓ Init: KK

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ✓ No _____ NA _____ Init: KK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ✓ Init: KK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: KK

Date: 11/ 2 /21

Event contains NCRs (Y/N)? N

Event ID: SMP - 3208C Deploy
SE-DIST-2021-11-02-01 (SMP)

Date Received: 02-NOV-2021 09:33

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #5 EXP:10-19-22
pH Test Strips 0 – 6	Lot#210620 EXP:4-15-23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#210620 EXP:4-15-23
Chlorine Test Strips	Lot#0070 EXP:2-23

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 11/1/2021
Customer: SE-DIST
RQ: RQ-2021-10-25-07

Collected By: Jordan Skaggs, Drew Liddick
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Manatee Pocket North	 G2SE0063

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 11/1/2021
1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *KL*

Rec'd/Inspected

Date: *11-2-21/0933*



RQ-2021-10-25-07

Collected By: Jordan Skaggs, Drew Liddick

Customer: FDEP

Field Report Prepared by: Jordan Skaggs, Drew Liddick

Project ID: SMP

Sampling Agency: FDEP

 WIN ID/Field ID: 
 WIN ID/Field ID: G2SE0063

Comments:

Location:

Location: Manatee Pocket North

Matrix: Marine

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. ©	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
11/1/2021 1430	6.75	96.7	26.5	7.86	0.3	0.7	1.7	42445	27.26

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A
	Lot #		SA0353110		Exp:		01/11/22					
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD		Ice	HNO3*		<2		
	Lot #		Exp:									
Filtered Nutrients (P125ML)	X	W-PO4-F		X	Field Filtered 0.45 µm Filter		X	Ice			1	A
	Filter Lot #											
	Syringe Lot #		1145471									
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice	1			A	
Physical/Aggregate (Fresh) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS					Ice					
Physical/Aggregate (Marine) (P-1L)	X	Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				X	Ice	1			A	
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin					
Periphyton (PT-50ML)		ALGAE-ID					Ice					
Microbiology (Contract Lab Bottle)		E Coli	F Coli	X	Enterococci		X	Ice			1	A
	Contract Lab											
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR	PCR-DG3		Ice					
	PCR-GULL2		PCR-GFD									
Tracers (BG-500ML)	X	W-E8321-DI		X	W-E8321-MS		X	Ice	1	A		
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI	W-E8321-MS		W-PSNP-TQ			Ice				
	W-PCL-TQ-R	W-CAR8-AA (5 ml of MCAA** Buffer Solution)		W-CT-CL-R								
Phytoplankton		DTY-QN-C		PKD-QN-BV			Ice					

Date of Request: 13-SEP-2021
 Created By: SKAGGS_J On: 13-SEP-2021
 Modified By: JASROTIA_P On: 04-OCT-2021
 Customer: SE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Southeast District
 Event Description: SMP - 3208C Deploy

Send Coolers To:

Phone: (772) 448-5884
 FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Jordan Skaggs
 Cooler Ship EMail: jordan.skaggs@FloridaDEP.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 04-OCT-2021
 Biology Request Reviewed By: JASROTIA_P On: 04-OCT-2021
 Sampling Kit Required: YES Ship on: 15-OCT-2021
 Sampling Kit Shipped: YES On: 12-OCT-2021
 Sampling Kit Packed By: KLUG_K
 Preservatives Needed: NO
 Date to Receive Samples: 28-OCT-2021
 Logged In By: MCCOY_I On: 28-OCT-2021

Send Final Report To:

FL Dept. of Environmental Protection
 2199 South Rock Road
 Fort Pierce, FL 34945
 Attn: Drew Liddick
 Report Notification EMail:
 drew.liddick@FloridaDEP.gov;jordan.skaggs@floridadep.gov;and
 rew.luering@floridadep.gov

Comments:

Group A - 3m nut, ent, tracers
 3208C - G2SE0063 (retrieve day)

Group B - ent
 3208C - G2SE0063 (deploy day)

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI Number of Bottles: 1 Preserved With: ICE
ENT-24-QT Template: DEFAULT (Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.