

RQ-20 22-02-21-28

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 3/15/2022 9:50

*Cooler Temperature	Samples Frozen? YES	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
		HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
0.7				4		✓			522555445477

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☐ NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IM

Date: 3/15/2022

Event contains NCRs (Y/N)? ☒

Event ID: Nassau North Boat 2022
 NE-DIST-2022-03-15-02 (SMP)
 Date Received: 15-MAR-2022 09:50

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:10/19/22
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	207621 exp: 3/15/24
Chlorine Test Strips	0070 exp: 02/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 3/14/2022
Customer: NE-DIST
RQ: RQ-2022-02-21-28
Collected By: Brian Davis, Vincent McClure
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Plummer Creek @ Second Island	 G4NE0301

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 3/14/2022
1600EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By:

IM

Rec'd/Inspected Date:

3/15/22

CALIBRATION AND VERIFICATION LOG (FDEP SOP FT 1000-FT 1500, FD 1000-FD 4000)

Boldly "X" this box if there are qualified data on this page.

Meter ID: STITCH

RQ: 2022-02-21-28

Project: SMP IVSS9 IV Post

- Notes: (1) Always wait for meter to stabilize before recording any readings.
 (2) Report all digits displayed. Do not round before reporting measurements. (See special instructions for depth).
 (3) For Calibrations, record calibrated meter reading. Do not record initial meter reading before calibration.

Temperature (Quarterly) FT 1400

Date of Last Temperature Verification 2/3/22

DO DEP SOP FT 1500	Name	Date	Time CT-ET	Temp °C	Baro- meter mmHg	D.O. Chart mg/L	Meter D.O. mg/L	% DO	Probe Charge	Probe Gain	Pass / Fail	Lab / Field
Calibr.	Vincent Miller	3/14/22	8:31	19.7	771.0	9.3	✓	101.4	✓	1.070	Ⓟ/F	Ⓟ/F
ICV	↓	↓	8:32	19.7	771.0	9.3	9.28	101.5	✓	1.070	Ⓟ/F	Ⓟ/F
CCV	Brian Davis	↓	1424	21.2	770.5	9.0	9.02	101.7	✓	1.070	Ⓟ/F	Ⓟ/F
CCV											P/F	L/F

DO Acceptance criteria from Table ± 0.3 mg/L.

Rapid-Pulse Sensors: DO Gain Range 0.7 to 1.4; DO Charge Range 25-75.

Optical: DO gain range 0.85 to 1.15 (Pro DSS 0.75 to 1.50); DO charge N/A. Steady-state & Galvanic Sensors: DO Gain & Charge N/A.

Spec. Cond. FT 1200	Name	Date	Time CT-ET	Lot #	Expir. Date	Standard μ hos/cm	Meter Reading μ hos/cm	Pass / Fail	Lab / Field
Calibr.	Vincent Miller	3/14/22	8:36	210917B	09/22	1000	1000	Ⓟ/F	Ⓟ/F
ICV	↓	↓	8:39	211122B	12/22	1413	1409	Ⓟ/F	Ⓟ/F
CCV	Brian Davis	↓	1426	210917A	9/22	100	99.8	Ⓟ/F	Ⓟ/F
CCV								P/F	L/F

Conductivity Acceptance criteria $\pm 5\%$

pH DEP SOP FT 1100	Name	Date	Time CT-ET	Lot #	Expir. Date	pH Buffer SU	Temp °C	Meter reading SU	mV	Pass / Fail	Lab / Field
Calibr.	Vincent Miller	3/14/22	8:41	2112819	12/23	7.02	20.0	7.02	-29.6	Ⓟ/F	Ⓟ/F
Calibr.	↓	↓	8:45	2201088	1/24	4.00	20.0	4.00	146.8	Ⓟ/F	Ⓟ/F
Calibr.	↓	↓	8:47	2202A63	7/23	10.05	20.0	10.05	-200.0	Ⓟ/F	Ⓟ/F
ICV	↓	↓	8:53	2112819	12/23	7.02	20.0	7.07	-29.5	Ⓟ/F	Ⓟ/F
CCV	Brian Davis	↓	1429	2112819	12/23	7.02	20.8	7.06	-29.5	P/F	L/F
CCV										P/F	L/F

pH Acceptance criteria ± 0.2 SU; mV pH 7 Range 0 ± 50 ; mV pH 4 Range $+180 \pm 50$; mV pH 10 Range -180 ± 50 ;

If mV are recorded: slope from 7 to 10 170.6, slope from 4 to 7 176.4 (both must be between 165 and 180 mV)

Does meter have a depth sensor that will be used to measure total depth & sample depth? YES / NO / NA (not surf. water project)

If YES, complete daily Calibr. & ICV below and list date of last quarterly depth verification: 2/3/22

If NO, what will be used? (circle one) Secchi Disk Line / Sonar Unique ID: _____; Date of last verification: _____

Depth Sensor (Daily Calibration & ICV)	Name	Date	Time CT-ET	Calibrated Value (0.00 or Offset), meters	ICV Value, meters	Pass/ Fail	Lab/ Field
Pressure mode in air	Vincent Miller	3/14/22	9:02	0.00		P/F	L/F

Report two decimal places. Round numbers ≤ 4 down, ≥ 5 up. ICV acceptance criteria $\pm 5\%$ or ± 0.05 m, whichever is greater.

COMMENTS:



RQ-2022-02-21-28


Customer: NE-DIST

Project ID: STRATEGIC MONITORING PLAN

Collected By: Brian Davis, Vincent McClure

Field Report Prepared By: Brian Davis

Sampling Agency: FDEP

Place Label Here						Comments:				
WIN ID/Field ID:  G4NE0301										
Location: Plummer Creek @ Second Island										
Matrix: Fresh						(Check one) ☒ GRAB ☐ COMPOSITE				
Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
3/14/2022	1230 EST	5.46	56.2	16.7	8.9	0.3	0.5 ☐ VOB (S)	2.6	210.7	0.1
	1235 EST	5.44	56	16.7	9.8	2.1	Central Lab please use top row for login purposes		210.1	0.1
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # S1105060 Exp: 04/30/22				☒ Ice ☒ H2SO4* ☒ x2			1	A
Metals (P-500ML)		☐ W-ICPMS ☐ W-ICP ☐ W-HARD Lot # Exp:				☐ Ice ☐ NO3* ☐ x2				
Filtered Nutrients (P125ML)		☐ W-P04-F ☐ Field Filtered 0.45 µm Filter Filter Lot #				☐ Ice Syringe Lot #				
BOD (BP-1L)		☐ OV-BODUNIN				☐ Ice				
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	A
Physical/Aggregate (Fresh) (P-1L)		☐ Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-S04-IC / W-TPS				☐ Ice				
Physical/Aggregate (Marine) (P-1L)		☒ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				☒ Ice			1	A
Macroinvertebrates (PJ-2L)		☐ MI-FW-QLDC				☐ Formalin				
Periphyton (PT-50ML)		☐ ALGAE-ID				☐ Ice				
Microbiology (Contract Lab Bottle)		☐ Coli ☐ Coli ☒ Enterococci ☐ Contract Lab				☒ Ice			1	A
Molecular (QPCR-P-500ML)		☐ PCR-HF183 ☐ PCR-BacR ☐ CR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD				☐ Ice				
Tracers (BG-500ML)		☐ W-E8321-DI ☐ W-E8321-MS				☐ Ice		MCAA Exp.		
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI WE8321-MS W-PSNP-TQ W-CT-CL-R W-PCL-TQ-R W-CARB-AA (5 ml of MCAA** Buffer Solution) W-TR-SQ-R W-PCB-TQ-R				☐ Ice		MCAA Lot#		
Phytoplankton/Periphyton		DTY-QN-C PKD-QN-C				☐ Ice				
Name: Brian Davis Vincent McClure						Signature: 			Date: 03/14/2022	

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
STRATEGIC MONITORING PLAN FIELD SHEET

January 2022

Meter Passed End
of Day CCV
Yes / No

WIN Station Name: Plummer Creek @ Second Island

Date: 3/14/2022

WIN/Field ID: G4NE0301

WBID: 2130

ENR: -

Latitude: 30.57958

County: NASSAU

Org ID: 21FLA

Longitude: -81.65644

Receiving Body of Water: Nassau - St. Marys

RQ: 2022-02-21-28

Sampling Team Members		WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check
☒	Brian Davis		☒		☒	☒
☒	Vincent McClure		☒	☒		
☐						
☐						

Sampling Equipment	
☒ Sample Container	☐ Carboy
☐ Dipper	☐ Van Dorn
☐ Syringe	☒ Pole
Depth measured with: Secchi	
Secchi Equipment ID: Disco	
Collection Method	
☐ Wading	☐ Canoe/Kayak
☐ From Shore	☐ Electric Motor
☐ Other _____	☒ Gasoline Motor

Water Level: ☒ Normal ☐ Low ☐ High ☐ Dry ☐ Pooled ☐ Flooded						Meter ID# STITCH							
Photos: YES		Flow: NA		Tide: FALLING		Tide Times: High: 1030 Low: 1645							
Biological Samples Collected: ☒ None ☐ HA ☐ SCI ☐ RPS ☐ Algae ID ☐ LVS ☐ LVI Other: _____													
SPIO ID Numbers: _____													
Notes: SUNNY													

Duplicate Sample	
Time Zone: EST Time: _____ Field ID: N/A	(WIN ID_DUP)
WIN DMT Activity ID: _____	

Blank	
Time Zone: _____ Time: _____ Field ID: _____	(Blank Type_DDMMYYYY)
DI Source: _____ Location: _____	
DI Type: _____ Equipment ID: _____	

DI Container (Name/ID): _____	DI Container Type: _____
--------------------------------------	---------------------------------

LIMS EVENT ID: _____ **WIN Import ID:** _____

Enter Field Parameters, Verify Station ID In LIMS DMT: _____ **QC Station ID, Field Parameters In LIMS DMT:** _____
(Initials/Date) (Initials/Date)

Scan/Save Field Sheets _____ **Migrate Data to WIN:** _____ **Verify Data In WIN:** _____
(Initials/Date) (Initials/Date) (Initials/Date)

Date of Request: 21-JAN-2022
 Created By: PARRISH_J On: 21-JAN-2022
 Modified By: JASROTIA_P On: 03-FEB-2022
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Event Description: Nassau North Boat 2022

Send Coolers To:

Phone: 904-256-1700
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Cooler Ship EMail: Jeremy.M.Parrish@dep.state.fl.us

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 03-FEB-2022
 Biology Request Reviewed By: JASROTIA_P On: 03-FEB-2022
 Sampling Kit Required: YES Ship on: 11-FEB-2022
 Sampling Kit Shipped: YES On: 08-FEB-2022
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 21-FEB-2022
 Logged In By:

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Report Notification EMail: Jeremy.M.Parrish@dep.state.fl.us

Comments: Group A: (Surf-Salt) Nutrients, Bacteria
 Group B: (Surf-Fresh Nutrients, Metals, Bacteria)
 Group C: (Surf.Salt) Bacteria

Packing Notes:
 None

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
----------------------	----------------------	--

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L	
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L	
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L	
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices	
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices	
Bottle Type: P-125ML		Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	
Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L	
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices	
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices	
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)	
*Color (true)			
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices	
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices	
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	
Bottle Type: BP-1L		Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry	
Bottle Type: P-250ML-WO-THI		Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems	
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: HNO3
W-HARD	Template: DEFAULT	(SM 2340B) Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3	
Hardness			
W-ICP	Template: SMP-FRESH	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	
Calcium			
Iron			
Magnesium			
Potassium			
Sodium			
Strontium			
Tin			
Titanium			
Vanadium			
Zinc			
W-ICPMS	Template: DEFAULT	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects	
*Boron			
Aluminum			
Antimony			
Arsenic			
Barium			
Beryllium			
Cadmium			
Chromium			
Cobalt			
Copper			
Lead			
Manganese			
Molybdenum			
Nickel			
Selenium			
Silver			
Thallium			

Bottle Group C (Water) With 1 Samples:

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI Number of Bottles: 1 Preserved With: ICE
ENT-24-QT Template: DEFAULT (Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.