

Login Checklist

RQ- **2022 - 06 - 13- 15**

Login Station ID: **# 3**

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: **08/19/2022 / 09:20**

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.8C				10		X			5225 5545 6274

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes **X** No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No **X**

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA **X**

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes **X** No _____

Caps on tight?

Yes **X** No _____

Sufficient Sample Volume:

Yes **X** No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes **X** No _____ Init: **ABS /**

Chlorine detected? (One container checked per Field ID)

Yes _____ No **X** Init: **ABS /**

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes **X** No _____ NA **NE** Init: **ABS /**

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA **X** Init: **ABS /**

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: **ABS /**

Date: **08/19/2022**

Event contains NCRs (Y/N)? **N**

Event ID:

NE - DIST 2022 - 08 - 19 - 0

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IRTG # 3 EXP:10/19/2022
pH Test Strips 0 – 6	LOT#223819AV EXP:8/30/2023
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT 207621 EXP:3/15/2024
Chlorine Test Strips	0064/11/2023/05 abs 0070 / 2023 / 02

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: ABS

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 8/18/2022
Customer: NE-DIST
RQ: RQ-2022-06-13-15
Collected By: Jeremy Parrish, Katherine Halbert
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Omega lake center	 G2NE1225

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 8/18/2022
1630 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: A.SHAIK

Rec'd/Inspected
Date: 08/19/2022



RQ-2022-06-13-15

Collected By: Jeremy Parrish, Katherine Halbert

Customer: FDEP

Field Report Prepared by: Jeremy Parrish,
Katherine Halbert

Project ID: SMP

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G2NE1225

Comments:

Location:

Location: Omega lake center

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
8/18/2022 1020	6.54	89.4	31.7	6.66	0.3	1.5	4.378	114.7	0.05

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group				
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A		
		Lot #	Sa415160		Exp:	6/7/23								
Metals (P-500ML)	X	W-ICPMS	X	W-ICP	X	W-HARD	X	Ice	X	HNO3*	X	<2	1	A
		Lot #	Na115110		Exp:	6/2/23								
Filtered Nutrients (P125ML)	X	W-PO4-F	X	Field Filtered 0.45 µm Filter		X	Ice				1	A		
BOD (BP-1L)		OV-BODUNIN					Ice							
Chlorophyll (BP-1L)	X	CHL5UITE-W				X	Ice				1	A		
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-SO4-IC / W-TDS				X	Ice				1	A		
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY					Ice							
Macroinvertebrates (PJ-2L)		MI-FW-QLDC		Formalin Lot #			Formalin							
Periphyton (PT-50ML)		ALGAE-ID					Ice							
Microbiology (Contract Lab Bottle)		E Coli		F Coli		Enterococci		Ice						
		Contract Lab												
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3		Ice						
		PCR-GULL2		PCR-GFD										
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS			Ice							
Pesticides (BG-500ML) (BG-1L)	X	W-E8321-DI	X	W-E8321-MS	X	W-PSNP-TQ		X	Ice	MCAA Exp.	MCAA Lot#	5	A	
		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R								
	X	W-TR-SQ-R		W-PCB-TQ-R										
Phytoplankton		DTY-QN-C		PKD-QN-BV			Ice							

Date of Request: 29-APR-2022
 Created By: PARRISH_J On: 29-APR-2022
 Modified By: JASROTIA_P On: 26-MAY-2022
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Event Description: Biven LVI

Send Coolers To:

Phone: 904-256-1700
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Cooler Ship EMail: Jeremy.M.Parrish@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 26-MAY-2022
 Biology Request Reviewed By: JASROTIA_P On: 26-MAY-2022
 Sampling Kit Required: YES Ship on: 03-JUN-2022
 Sampling Kit Shipped: YES On: 31-MAY-2022
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 13-JUN-2022
 Logged In By: SHAIK_A On: 19-AUG-2022

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Report Notification EMail: Jeremy.M.Parrish@dep.state.fl.us

Comments: Group A: (Surf-fresh) Nutrients,Metal, Bacteria, tracer, psnptq,trsq

 W-TR-SQ-R (sunscreen)

Wash your hands thoroughly and wear gloves. Refrain from using sunscreens on the day of sample collection.

#####

NE-DIV-ECQ

Packing Notes:

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-DIV-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Collert/QT by Diversified Environmental Laboratories in Jacksonville
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML		Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B)	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: HNO3
W-HARD	Template: DEFAULT	(SM 2340 B-2011)	Hardness by calculation, in aqueous matrices, reported as mg/L CaCO3
Hardness			
W-ICP	Template: SMP-FRESH	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	
Calcium			
Iron			
Magnesium			
Potassium			
Sodium			
Strontium			
Tin			
Titanium			
Vanadium			
Zinc			
W-ICPMS	Template: DEFAULT	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects	
Aluminum			
Antimony			
Arsenic			
Barium			
Beryllium			
Boron			
Cadmium			
Chromium			
Cobalt			
Copper			
Lead			
Manganese			
Molybdenum			
Nickel			
Selenium			
Silver			
Thallium			
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0)	Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011)	Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML		Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-1L		Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E)	Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
W-TR-SQ-R	Template:	(EPA 8270E)	Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.