

Login Checklist

RQ- 2022-11-07-20

Login Station ID: 5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 11/8/22 @ 9:10

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0-5				9		X			585947279141
				11		X			585947279130

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No X

Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes X No _____ Init: C-P

Chlorine detected? (One container checked per Field ID)

Yes _____ No X Init: C-P

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes X No _____ NA _____ Init: C-P

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0?

Yes _____ No _____ NA X Init: C-P

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: C-P

Date: 11/8/22

Event contains NCRs (Y/N)? N

EventID: NE-DIST-2022-11-08-01 (SMP)
Date Received: 08-NOV-2022 09:10

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	221426058 10/17/23
pH Test Strips 0 – 6	223819AV 08/30/23
pH Paper 0 – 3	NA
pH Paper 0 – 13	210620 4/15/2023
Chlorine Test Strips	0070 02/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 11/7/2022 **Collected By:** Brian Davis, Katherine Halbert
Customer: NE-DIST **Sampling Agency:** FDEP
RQ: RQ-2022-11-07-20 **Project ID:** SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 2 **Delivery Method:** FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
MOSES CR AT US 1	 27010050
Unnamed Drain 10M N Eagles Nest Rd. aprox. 0.5MI E US1	 27010078
UNNAMED DRAIN @ EAGLES NEST RD	 27010079

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 11/7/2022

1630 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: *Chin P*

Rec'd/Inspected

Date: *11/08/2022*



RQ-2022-11-07-20	Collected By: Brian Davis, Katherine Halbert
Customer: FDEP	Field Report Prepared by: Brian Davis, Katherine Halbert
Project ID:	Sampling Agency: FDEP

WIN ID/Field ID:  WIN ID/Field ID: 27010050	Comments:
---	------------------

Location: MOSES CR AT US 1

Matrix: Fresh

(Check One) ☒ Grab ☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPTH)							
11/7/2022 1020	5.02	58	22.4	6.57	0.113	0.226	0.226	298.2	0.14							
Parameter Suite		Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group					
Preserved Nutrients (P-500ML)		W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice H2SO4*		<2								
		Lot # Exp:														
Metals (P-500ML)		W-ICPMS W-ICP W-HARD				Ice HNO3*		<2								
		Lot # Exp:														
Filtered Nutrients (P125ML)		W-PO4-F Field Filtered 0.45 µm Filter				Ice										
		Filter Lot # Syringe Lot #														
BOD (BP-1L)		OV-BODUNIN				Ice										
Chlorophyll (BP-1L)		CHLSUITE-W				Ice										
Physical/Aggregate (Fresh) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY / W-CH-IC / W-COLOR / W-SO4-IC / W-TDS				Ice										
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY				Ice										
Macroinvertebrates (PJ-2L)		MI-FW-QLDC Formalin Lot #				Formalin										
Periphyton (PT-50ML)		ALGAE-ID				Ice										
Microbiology (Contract Lab Bottle)		X E Coli Contract Lab F Coli Enterococci				x Ice				1	D					
Molecular (QPCR-P-500ML)		PCR-HF183 PCR-BacR PCR-DG3 PCR-GULL2 PCR-GFD				Ice										
Tracers (BG-500ML)		W-E8321-DI W-E8321-MS				Ice										
Pesticides (BG-500ML) (BG-1L)		X W-E8321-DI	X W-E8321-MS	X W-PSNP-TQ	x Ice	MCAA Exp.		MCAA Lot#	10	D						
		X W-PCL-TQ-R	X W-CARB-AA (5 ml of MCAA Buffer Solution)	X W-CT-CL-R		02/04/23										
		X W-TR-SQ-R	X W-PCB-TQ-R			128343										
Phytoplankton		DTY-QN-C PKD-QN-BV				Ice										
DOC		Field Filtered 0.45 µm Filter				Ice H2SO4*		<2								
		Acid Preservative Expiration Date														
		Acid Preservative Lot Number														



RQ-2022-11-07-20	Collected By: Brian Davis, Katherine Halbert
Customer: FDEP	Field Report Prepared by: Brian Davis, Katherine Halbert
Project ID:	Sampling Agency: FDEP
WIN ID/Field ID:  WIN ID/Field ID: 27010079	Comments:

Location: UNNAMED DRAIN @ EAGLES NEST RD

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)	
11/7/2022 1125	5.05	58	22.2	6.76	0.3	0.4	0.831	582	0.28	
Parameter Suite	Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group	
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				Ice	H2SO4*	<2			
	Lot #		Exp:							
Metals (P-500ML)	W-ICPMS		W-ICP	W-HARD	Ice	HNO3*	<2			
	Lot #		Exp:							
Filtered Nutrients (P125ML)	W-PO4-F		Field Filtered 0.45 µm Filter		Ice					
	Filter Lot #	Syringe Lot #								
BOD (BP-1L)	OV-BODUNIN				Ice					
Chlorophyll (BP-1L)	CHLSUITE-W				Ice					
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS				Ice					
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY				Ice					
Macroinvertebrates (PJ-2L)	MI-FW-QLDC	Formalin Lot #			Formalin					
Periphyton (PT-50ML)	ALGAE-ID				Ice					
Microbiology (Contract Lab Bottle)	X	E Coli	F Coli	Enterococci	x	Ice		1	C	
	Contract Lab									
Molecular (QPCR-P-500ML)	X	PCR-HF183	X	PCR-BacR	X	PCR-DG3	x	Ice	1	C
	PCR-GULL2		PCR-GFD							
Tracers (BG-500ML)	X	W-E8321-DI	X	W-E8321-MS	x	Ice		1	C	
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI	W-E8321-M5	W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#			
	W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)	W-CT-CL-R							
	W-TR-SQ-R	W-PCB-TQ-R								
Phytoplankton	DTY-QN-C		PKD-QN-BV		Ice					
DOC	W-DOC		Field Filtered 0.45 µm Filter		Ice	H2SO4*	<2			
			Acid Preservative Expiration Date							
			Acid Preservative Lot Number							

RQ-2022-11-07-20	Collected By: Brian Davis, Katherine Halbert
Customer: FDEP	Field Report Prepared by: Brian Davis, Katherine Halbert
Project ID:	Sampling Agency: FDEP

WIN ID/Field ID:  WIN ID/Field ID: 27010078	Comments:
---	------------------

Matrix: Fresh

(Check One)

✓ Grab

☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT _h)
11/7/2022 1110	4.13	47.7	22.3	6.53	0.15	0.307	0.307	288.8	0.14

Parameter Suite	Parameter Methods							Preservation			pH Check		# Bottles sent to Lab	Bottle Group					
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP					X	Ice	X	H2SO4*	X	<2	1	B					
	Lot #		21451560		Exp:	06/02/23													
Metals (P-500ML)		W-ICPMS			W-ICP			W-HARD			Ice		HNO3*		<2				
	Lot #				Exp:														
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 um Filter					Ice										
	Filter Lot #			Syringe Lot #															
BOD (BP-1L)		OV-BODUNIN						Ice											
Chlorophyll (BP-1L)	X	CHLSUITE-W					X	Ice											
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W- TD5					X	Ice											
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY						Ice											
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin												
Periphyton (PT-50ML)		ALGAE-ID						Ice											
Microbiology (Contract Lab Bottle)	X	E Coli			F Coli			Enterococci		X							Ice	1	B
	Contract Lab																		
Molecular (QPCR-P-500ML)	X	PCR-HF183		X	PCR-BacR		X	PCR-DG3			Ice								
	PCR-GULL2		PCR-GFD																
Tracers (BG-500ML)	X	W-E8321-DI		X	W-E8321-MS				Ice										
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI			W-E8321-MS			W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#							
		W-PCL-TQ-R			W-CARB-AA (5 ml of MCAA Buffer Solution)			W-CT-CL-R											
		W-TR-SQ-R			W-PCB-TQ-R														
Phytoplankton		DTY-QN-C			PKD-QN-BV				Ice										
DOC		W-DOC		Field Filtered 0.45 um Filter				Ice		H2SO4*		<2							
	Acid Preservative Expiration Date																		
	Acid Preservative Lot Number																		

Date of Request: 10-OCT-2022
 Created By: PARRISH_J On: 10-OCT-2022
 Modified By: JASROTIA_P On: 20-OCT-2022
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Event Description: unnamed run boat

Send Coolers To:

Phone: 904-256-1693
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Cooler Ship EMail: Jeremy.M.Parrish@dep.state.fl.us

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 20-OCT-2022
 Biology Request Reviewed By: JASROTIA_P On: 20-OCT-2022
 Sampling Kit Required: YES Ship on: 28-OCT-2022
 Sampling Kit Shipped: YES On: 24-OCT-2022
 Sampling Kit Packed By: PENDLETO_C
 Preservatives Needed: YES
 Date to Receive Samples: 07-NOV-2022
 Logged In By:

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Report Notification EMail: Jeremy.M.Parrish@dep.state.fl.us

Comments:

Group A: (Surf.-Salt) Nutrients, Bacteria
 Group B: (Surf-Fresh) Nutrients, Bacteria, Tracer, Markers
 Group C: (Srf.-Fresh) Bacteria, Tracer, Marker
 Group D: (Surf.Fresh) Bacteria, Pesticides

#####

Buffer Solution for W-CARB-AA Bottle
 1 vial per bottle

 W-TR-SQ-R (sunscreen)

Wash your hands thoroughly and wear gloves. Refrain from using sunscreens on the day of sample collection.

#####

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
FCOLI-MF	Template: DEFAULT	(SM 9222 D) Fecal coliforms by membrane filter method - non-chlorinated water systems

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2015) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2015) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2ClCOOH and Ice
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS

Bottle Group D (Water) With 1 Samples:

Bottle Type: BG-500ML FILL TO	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCB-TQ-R	Template: DEFAULT	(EPA 8270E) PCBs in water matrices by GC/MS/MS
W-PCL-TQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: SMP	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
W-TR-SQ-R	Template: DEFAULT	(EPA 8270E) Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.

Cooler Packing Worksheet for Request: RQ-2022-11-07-20

unnamed run boat

Ship Cooler On: 10/28/2022

Customer/Project: NE-DIST/SMP

Assigned To: PENDLETO_C
Requester: Jeremy M. Parrish
Priority: 3

904-256-1693
8800 Baymeadows Way West
Suite 100
Jacksonville, FL 32256
Attn: Jeremy Parrish

Please return
packing list with
sample submittal
forms.

Comments:

Group A: (Surf.-Salt) Nutrients, Bacteria
Group B: (Surf-Fresh) Nutrients, Bacteria, Tracer, Markers
Group C: (Srf.-Fresh) Bacteria, Tracer, Marker

Group D: (Surf.Fresh) Bacteria, Pesticides

#####

Buffer Solution for W-CARB-AA Bottle
1 vial per bottle

#####

W-TR-SQ-R (sunscreens)

Wash your hands thoroughly and wear gloves. Refrain from using sunscreens on the day of sample collection.

#####

Requested Analyses:

Bottle Group: A

of Sites: 1

Container ID: P-1L

Qty: 1 Preservation: ICE

Lot # 00083575

Description: Plastic Bottle 1L

Analysis

ALKALINITY

TURBIDITY

W-F

W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO₃/L

Turbidity in aqueous matrices

Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)

Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 1 Preservation: ICE

Lot # 1362301

Description: Brown Plastic Bottle 1L

Analysis

Description

Container ID: P-250ML-WO-THI
Description: 250 ml Sterilized no tablet

Qty: 1 Preservation: ICE

Lot # L22143

Analysis
ENT-24-QT

Description

Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems

Container ID: P-250ML-WO-THI
Description: 250 ml Sterilized no tablet

Qty: 1 Preservation: ICE

Lot # L22143

Analysis
FCOLI-MF

Description

Fecal coliforms by membrane filter method - non-chlorinated water systems

Container ID: P-500ML
Description: Plastic Bottle 500 mL

Qty: 1 Preservation: ICE And H2SO4

Lot # 00084030

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3

W-NO2NO3

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group: B

of Sites: 1

Container ID: P-1L
Description: Plastic Bottle 1L

Qty: 1 Preservation: ICE

Lot # 00083575

Analysis

ALKALINITY

TURBIDITY

W-CL-IC

W-COLOR

W-F

W-SO4-IC

W-TDS

W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO3/L

Turbidity in aqueous matrices

Chloride in aqueous matrices

True Color measured at 450 nm (not valid for NPDES monitoring)

Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)

Sulfate in aqueous matrices

Total Dissolved Solids in aqueous matrices

Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L
Description: Brown Plastic Bottle 1L

Qty: 1 Preservation: ICE

Lot # 1302301

Analysis

Description

Container ID: P-250ML-WO-THI

Qty: 1

Preservation: ICE

Lot # L22143

Description: 250 ml Sterilized no tablet

Analysis

ECOLI-18QT

Description

Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Container ID: QPCR-P-500ML

Qty: 1

Preservation: ICE

Lot # 06076606

Description: 500ml Sterile Nalgene

Analysis

PCR-BACR

PCR-DG3

PCR-HF183

Description

Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction

Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction

Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Container ID: BG-500ML

Qty: 1

Preservation: ICE

Lot # 00083238

Description: Brown Glass Bottle 500ML *FILL Completely*

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: P-500ML

Qty: 1

Preservation: ICE And H2SO4

Lot # 00084030

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3

W-NO2NO3

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group: C# of Sites: 1

Container ID: P-250ML-WO-THI

Qty: 1

Preservation: ICE

Lot # L22143

Description: 250 ml Sterilized no tablet

Analysis

ECOLI-18QT

Description

Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Container ID: QPCR-P-500ML
Description: 500ml Sterile Nalgene

Qty: 1 Preservation: ICE

Lot # 00075606

Analysis

PCR-BACR

PCR-DG3

PCR-HF183

Description

Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction

Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction

Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Container ID: BG-500ML

Qty: 1 Preservation: ICE

Lot # 00083238

Description: Brown Glass Bottle 500ML *FILL Completely* Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group: D

of Sites: 1

Container ID: P-250ML-WO-THI

Qty: 1 Preservation: ICE

Lot # L22143

Description: 250 ml Sterilized no tablet

Analysis

ECOLI-18QT

Description

Escherichia coli by Collert 18 Quanti-Tray method - non-chlorinated water systems

Container ID: BG-500ML

Qty: 1 Preservation: CH2CICOOH and Ice

Lot # 06083894

Description: Brown Glass Bottle 500ML *FILL Completely* Affix BLUE dot to container.

Analysis

W-CARB-AA

Description

Carbamates in water matrices by HPLC/MS/MS

Container ID: BG-500ML FILL TO TOP Qty: 4

Preservation: ICE

Lot # 06083894

Description: Brown Glass Bottle 500ML *FILL Completely* Affix BLUE dot to container.

Analysis

W-CT-CI-R

W-PCB-TQ-R

W-PCL-TQ-R

Description

Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

PCBs in water matrices by GC/MS/MS

Organochlorine pesticides, pyrethroids and tracers in water matrices by GC/MS/MS

Container ID: BG-500ML

Qty: 1 Preservation: ICE

Lot # 00083894

Description: Brown Glass Bottle 500ML *FILL Completely*

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: BG-1L

Qty: 4 Preservation: ICE

Lot # 00083894

Description: Brown Glass Bottle 1L

Affix BLUE dot to container.

Analysis

W-PSNP-TQ

W-TR-SQ-R

Description

Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM

Cooler Packed By: E. R Number of Coolers: 3 Date: 10-24-2022

Kit must also include:

- ☒ Field Sheets
- ☒ Temperature Control Bottle
- ☒ FedEx Bills, if applicable
- ☒ Plastic Bags/Zip Ties
- ☒ Acid Labels (sets of 24)

If Preservation Included:

IC	MCAA BUFFER SOL	Exp	_____	Lot #	_____
IC	SER: # 128343	Exp	_____	Lot #	_____
ID	EXP: 02/04/2023	Exp	_____	Lot #	_____
ID	_____	Exp	_____	Lot #	_____
ID	_____	Exp	_____	Lot #	_____

PLEASE RETURN ALL COOLERS FOR RQ-2022-11-07-20

