

RQ-2022-04-11-56

Login Checklist

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | GreyhoundDate/Time of Receipt: 04/29/22 @ 9:17

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #	
		YES	HNO ₃		Formalin	Present?		*Intact?		
						Yes	No	Yes		No
1.7				1		X			5225543 2369	

COOLER CHECK

- *All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.
- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
 - DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
 - If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
 - If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X

If Criminal, photographs taken?

Yes ✓ No _____

Caps on tight?

Yes ✓ No _____

Sufficient Sample Volume:

Yes ✓ No _____

Evidence Tape intact? Yes _____ No _____

Containers intact? Yes ✓ No _____If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Chlorine detected? (One container checked per Field ID)

Yes _____ No X Init: R

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes _____ No _____ NA X Init: R**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes _____ No _____ NA X Init: R

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: RDate: 04/29/22Event contains NCRs (Y/N)? N

Lake Asher
Event ID CEN-DIST-2022-04-29-02 (SMP)
Date Received: 29-APR-2022 09:17

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Infrared Thermometer ID:	#4 Temp Gun EXP:10/19/2022
pH Test Strips 0 – 6	223819AV EXP:08/30/2023
pH Paper 0 – 3	N/A
pH Paper 0 – 13	207621 EXP:03/15/2024
Chlorine Test Strips	0070 EXP:02/2023

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____



RQ-2022- 04-11-56
Customer: CEN-DIST
Project ID: SMP

Lab Page ____ of ____

Collected By: H. Hazelwood
Field Report Prepared By: C. Hammel
Sampling Agency: Seminole County

WIN ID / Field ID →							Comments:			
Lake Asher @ Center of Lake										
 G2CE0130										
Matrix: Fresh / Marine							(Check one) ☒ GRAB ☐ COMPOSITE			
Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
4/28/22	1050	8.10	102.3	27.32	7.38	0.3	1.1	1.6	145	N/A
EST / CST										
Central Lab please use top row for login purposes										
EST / CST										
Parameter Suite		Parameter Methods				Preservation		pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)		☐ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP				☐ Ice ☐ H2SO4*		☐ <2		
		Lot #		Exp:						
Metals (P-500ML)		☐ W-ICPMS ☐ W-ICP ☐ W-HARD				☐ Ice ☐ HNO3*		☐ <2		
		Lot #		Exp:						
Filtered Nutrients (P125ML)		☐ W-PO4-F ☐ Field Filtered 0.45 µm Filter				☐ Ice				
		Filter Lot #								
		Syringe Lot #								
Chlorophyll		☐ CHLSUITE-W				☐ Ice				
Physical/Aggregate (Fresh) (P-1L)		☐ Alkalinity / W-F / W-TSS / TURBIDITY / W-CL-IC / W-COLOR / W-SO4-IC / W-TDS				☐ Ice				
Physical/Aggregate (Marine) (P-1L)		☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY				☐ Ice				
Macroinvertebrates (PJ-2L)		☐ MI-FW-QLDC				☐ Formalin				
Periphyton (PT-50ML)		☐ ALGAE-ID				☐ Ice				
Microbiology (Contract Lab Bottle)		☒ E Coli ☐ F Coli ☐ Enterococci				☒ Ice			1	A
		☐ Contract Lab								
Molecular (QPCR-P-500ML)		☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3				☐ Ice				
		☐ PCR-GULL2 ☐ PCR-GFD ☐ See Notes								
Tracers (BG-500ML)		☐ W-E8321-DI ☐ W-E8321-MS				☐ Ice				
Pesticides (BG-500ML) (BG-1L)		☐ W-E8321-DI ☐ WE8321-MS ☐ W-PSNP-TQ ☐ W-CT-CL-R				☐ Ice				
		☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution)								
Phytoplankton (BP-1L)		TY-QN-C ☐ PKD-QN-BV Lugols not added				Ice				
Name: Cheyenne Hammel		Signature: Cheyenne Hammel						Date: 4/28/2022		

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution

Received by: R 4/29/2022



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION STRATEGIC MONITORING PROGRAM FIELD SHEET

January 2020

Meter Passed End

of Day CCV

Yes / No

WIN Station Name: Lake Asher @ Center of Lake

Date: 4/28/2022
(mm/dd/yyyy)

WIN/ Field ID: G2CE0130

WBID: 30040

Latitude: 28.65938832

(Decimal Degrees)

County: Seminole

ORG ID: 21FLCEN

Longitude: -81.44697292

(Decimal Degrees)

Receiving Body of Water: Middle St. Johns

RQ-2022-04-11-56

Sampling Team Members	WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check
Cheyenne Hammel	X	X			
Haley Hazelwood		X	X	X	

Sampling Equipment	
☐ Sample Container	☐ Van Dorn
☐ Syringe	☐ Pole
☐ Dipper	☒ Other TSS Bottle
Depth Measured with Depth Gauge	
Equipment ID 67372	
Collection Method	
☐ Wading	☒ Canoe/Kayak
☐ From Shore	☐ Electric Motor
☐ Other	☐ Gasoline Motor

Water Level: Dry/ Pooled/ Low / Normal / High / Flooded		Meter ID# "maggie"	
Photos: Yes / No	Flow: No Flow / Flowing / NA	Tide: Rising/ Falling/ Slack/ NA	Tide Times: High Low
Biological Samples Collected: None HA SCI RPS Algae ID LVS LVI Other: Phytoplankton			
SBIO ID Numbers:	SBIO-ID:	HA-ID:	RPS-ID:
Macrophyte-ID:		LIMS#:	
Notes:			

Duplicate Sample

Time Zone: EST CEN Time:	Field ID: (WIN ID_DUP)
WIN DMT Activity ID:	

Blank

Time Zone: EST CEN Time:	Field ID: (Blank Type_DDMYYYY)
DI Source:	Location:
☐ Field Blank ☐ Equipment Blank ☐ Field Cleaned Equipment Blank	Equipment ID:

CEROC -DO NOT ENTER FIELD DATA INTO LIMS

LIMS EVENT ID: WIN Import ID:

Enter Field Parameters, Verify Station ID In LIMS DMT: QC Station ID, Field Parameters In LIMS DMT:

Scan/Save Field Sheets Migrate Data to WIN: Verify Data In WIN:

Date of Request: 05-APR-2022
Created By: BOMAN_L On: 05-APR-2022
Modified By: JASROTIA_P On: 06-APR-2022
Customer: CEN-DIST
Project: SMP
Division:
District: Central District
Event Description: Lake Asher

Send Coolers To:

Phone: 407-897-4181
FL Dept. of Environmental Protection
3319 Maguire Blvd., Suite 232
Orlando, FL 32803-3767
Attn: Leif Boman
Cooler Ship EMail: Leif.Boman@FloridaDEP.gov

Priority: 3
Event Status: A
Criminal Investigation: NO
Chemistry Request Reviewed By:
Biology Request Reviewed By: JASROTIA_P On: 06-APR-2022
Sampling Kit Required: NO Ship on:
Sampling Kit Shipped:
Sampling Kit Packed By:
Preservatives Needed: NO
Date to Receive Samples: 11-APR-2022
Logged In By:

Send Final Report To:

3319 Maguire Blvd., Suite 232

Orlando, FL 32803-3767
Attn: Matt Bearden
Report Notification EMail: Matthew.Bearden@FloridaDEP.gov

Comments:

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI Number of Bottles: 1 Preserved With: ICE
ECOLI-18QT Template: DEFAULT (SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Escherichia Coli-Quanti-Tray

