

Login Checklist

RQ- **2022 - 05 - 16 - 46**

Login Station ID: **# 3**

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: **05/19/2022 / 11:40**

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.1c				2		X			5225 5545 14293

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. **NCR#** _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. **NCR#** _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. **NCR#** _____
- If coolers or samples are received late; identify the affected samples in an NCR. **NCR#** _____

Chain of Custody/ Field Sheet(s) Included?

Yes **X** No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No **X**

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA **X**

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes **X** No _____

Caps on tight?

Yes **X** No _____

Sufficient Sample Volume:

Yes **X** No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. **NCR#** _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No **x** Init: **ABS /**

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: **ABS /**

If chlorine is detected, generate an NCR listing affected sample IDs . **NCR#** _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS "OV-")

ABS

**Acid Preserved Samples: pH< 2.0?

Yes **X** No _____ NA **x** Init: **ABS /**

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA **x** Init: **ABS /**

If samples were not preserved correctly, generate an NCR listing affected sample IDs . **NCR#** _____

Coolers Unpacked/Checked by: **ABS /**

Date: **05/19/2022**

Event contains NCRs (Y/N)? **n**

Event ID:

CEN - DIST - 2022 - 05 -19 - 0 2

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IRTG # 3 EXP:10/19/2022
pH Test Strips 0 – 6	LOT#223819AV EXP:8/30/2023
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT 207621 EXP:3/15/2024
Chlorine Test Strips	0070 / 2023 / 02 0070 / 2023 / 02 abs

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: ABS

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____



RQ-2022- 05-16-46
 Customer: CEN-DIST
 Project ID: SMP

Collected By: Jessica L. Sones
 Field Report Prepared By: Jessica L. Sones
 Sampling Agency: City of Orlando

WIN ID / Field ID →

Lake Giles @ Center



G4CE0193

Comments:

* Please log in PKD-QN-B1
 & DTY-QN-C under a
 separate event w/ priority to
 Bottle Group B.

Matrix: Fresh Marine

(Check one)

☒ GRAB☐ COMPOSITE

Date	Time	DO (mg/L)	DO (%SAT)	Temp. (C°)	pH	Sample Depth (m)	Secchi Disk (m)	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
5/18/2022	12:14	9.16	119.0	28.65	9.62	0.3	1.27		158.0	
EST / CST		Central Lab please use top row for login purposes								
EST / CST										

Parameter Suite	Parameter Methods	Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	☐ W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP Lot # _____ Exp: _____	☐ Ice ☐ H2SO4* ☐ <2	☐ <2		
Metals (P-500ML)	☐ W-ICPMS ☐ W-ICP ☐ W-HARD Lot # _____ Exp: _____	☐ Ice ☐ HNO3* ☐ <2	☐ <2		
Filtered Nutrients (P125ML)	☐ W-PO4-F ☐ Field Filtered 0.45 µm Filter Filter Lot # _____ Syringe Lot # _____	☐ Ice			
Chlorophyll	☒ CHLSUITE-W	☒ Ice		1	A
Physical/Aggregate (Fresh) (P-1L)	☐ Alkalinity / W-F / W-TSS / TURBIDITY / W-CHC / W-COLOR / W-SO4-IC / W-TDS	☐ Ice			
Physical/Aggregate (Marine) (P-1L)	☐ Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY	☐ Ice			
Macroinvertebrates (PJ-2L)	☐ MI-FW-QLDC	☐ Formalin			
Periphyton (PT-50ML)	☐ ALGAE-ID	☐ Ice			
Microbiology (Contract Lab Bottle)	☐ E Coli ☐ F Coli ☐ Enterococci ☐ Contract Lab	☐ Ice			
Molecular (QPCR-P-500ML)	☐ PCR-HF183 ☐ PCR-BacR ☐ PCR-DG3 ☐ PCR-GULL2 ☐ PCR-GFD ☐ See Notes	☐ Ice			
Tracers (BG-500ML)	☐ W-E8321-DI ☐ W-E8321-MS	☐ Ice			
Pesticides (BG-500ML) (BG-1L)	☐ W-E8321-DI ☐ WE8321-MS ☐ W-PSNP-TQ ☐ W-CT-CL-R ☐ W-PCL-SQ-R ☐ W-CARB-AA (5 ml of MCAA** Buffer Solution)	☐ Ice			
Phytoplankton (BP-1L)	☒ DTY-QN-C ☒ PKD-QN-BV	☒ Ice Lugols not added in the field*		1	B

Name:

Jessica Sones

Signature:

Date:

5/18/22

*2.0 ml of Preservative used unless noted otherwise.

**MCAA: Monochloroacetic acid buffer solution

5/19/22 / 11:40



FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION STRATEGIC MONITORING PROGRAM FIELD SHEET

January 2020

Meter Passed End
of Day CCV
Yes / No

WIN Station Name: Lake Giles @ Center

Date: 5/18/2022
(mm/dd/yyyy)

WIN/ Field ID: G4CE0193

WBID: 3168Z4

Latitude: 28.530153

(Decimal Degrees)

County: Orange

ORG ID: 21FLCEN

Longitude: -81.334196

(Decimal Degrees)

Receiving Body of Water: Kissimmee River

RQ-2022-05-16-46

Sampling Team Members	WQ Measurements	Sample Collection	Documentation	Preservation	Preservation Check
Jessica Jones	✓	✓	✓	✓	✓

Sampling Equipment	
☒ Sample Container	☐ Van Dorn
☐ Syringe	☐ Pole
☐ Dipper	☐ Other
Depth Measured with	
Equipment ID	
Collection Method	
☐ Wading	☐ Canoe/Kayak
☐ From Shore	☐ Electric Motor
☐ Other	☒ Gasoline Motor

Water Level: Dry/ Pooled/ Low / <u>Normal</u> / High / Flooded		Meter ID#	
Photos: Yes / No	Flow: No Flow / Flowing / <u>NA</u>	Tide: Rising/ Falling/ Slack/ NA	Tide Times: High Low
Biological Samples Collected: None HA SCI RPS Algae ID LVS LVI Other:			
SBIO ID Numbers:	SBIO-ID:	HA-ID:	RPS-ID:
Macrophyte-ID:		LIMS#:	
Notes:			

Duplicate Sample

Time Zone: EST CEN Time: Field ID: (WIN ID_DUP)

WIN DMT Activity ID:

Blank

Time Zone: EST CEN Time: Field ID: (Blank Type_DDMMYY)
DI Source: Location:
☐ Field Blank ☐ Equipment Blank ☐ Field Cleaned Equipment Blank
Equipment ID:

CEROC -DO NOT ENTER FIELD DATA INTO LIMS

LIMS EVENT ID: WIN Import ID:

Enter Field Parameters, Verify Station ID In LIMS DMT: (Initials/Date) QC Station ID, Field Parameters In LIMS DMT: (Initials/Date)

Scan/Save Field Sheets (Initials/Date) Migrate Data to WIN: (Initials/Date) Verify Data In WIN: (Initials/Date)

Printed: 5/19/2022 13:05:14

Page 1 of 1

Date of Request: 28-APR-2022
Created By: BEARDEN_M On: 28-APR-2022
Modified By: JASROTIA_P On: 28-APR-2022
Customer: CEN-DIST
Project: SMP
Division: Division of Environmental Assessment and Restoration
District: Central District
Event Description: Orange Co Sampling - Giles

Send Coolers To:

Phone: 407-897-4123
FL Dept. of Environmental Protection
3319 Maguire Blvd., Suite 232
Orlando, FL 32803-3767
Attn: Matthew Bearden
Cooler Ship EMail: matthew.bearden@floridadep.gov

Priority: 3
Event Status: R
Criminal Investigation: NO
Chemistry Request Reviewed By:
Biology Request Reviewed By: JASROTIA_P On: 28-APR-2022
Sampling Kit Required: YES Ship on: 13-MAY-2022
Sampling Kit Shipped: YES On: 11-MAY-2022
Sampling Kit Packed By: SHAIK_A
Preservatives Needed: NO
Date to Receive Samples: 19-MAY-2022
Logged In By: SHAIK_A On: 19-MAY-2022

Send Final Report To:

FL Dept. of Environmental Protection
3319 Maguire Blvd., Suite 232
Orlando, FL 32803-3767
Attn: Matthew Bearden
Report Notification EMail:
matthew.bearden@floridadep.gov; victoria.schwartz@floridadep.gov

Comments: Please log in PKD-QN-BV & DTY-QN-C under a separate event with priority 12, Bottle Group - B

Bottle Group A (Water) With 1 Samples:

Bottle Type: BP-1L Number of Bottles: 1 Preserved With: ICE
CHLSUITE-W Template: DEFAULT (SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Group B (Water) With 1 Samples:

Bottle Type: BP-1L Number of Bottles: 1 Preserved With: Lugols
DTY-QN-C Template: DEFAULT (SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-BV Template: DEFAULT (SOP-AB05) No. of wet taxa of quantitative phytoplankton sample w/speciation and cell counts.

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.

