

Login Checklist

RQ- **2022 - 06 - 20 - 17**

Login Station ID: **# 3**

Shipping Method: **FedEx** | UPS | HD | Greyhound

Date/Time of Receipt: **06/30/2022 / 09:20**

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.1				5		X			5225 5548 1702

COOLER CHECK

***All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.**

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. **NCR#** _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. **NCR#** _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. **NCR#** _____
- If coolers or samples are received late; identify the affected samples in an NCR. **NCR#** _____

Chain of Custody/ Field Sheet(s) Included?

Yes **X** No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No **X**

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA **X**

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes **X** No _____

Caps on tight?

Yes **X** No _____

Sufficient Sample Volume:

Yes **X** No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. **NCR#** _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No **X** Init: **ABS /**

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: **ABS /**

If chlorine is detected, generate an NCR listing affected sample IDs . **NCR#** _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

****Acid Preserved Samples:** pH< 2.0?

Yes **X** No _____ NA _____ Init: **ABS /**

****W-1-4-DIOX** (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA **X** Init: **ABS /**

If samples were not preserved correctly, generate an NCR listing affected sample IDs . **NCR#** _____

Coolers Unpacked/Checked by: **ABS /**

Date: **06/30/2022**

Event contains NCRs (Y/N)? **X**

Event ID:

CEN - DIST - 2022 - 06 - 30 - 0

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IRTG # 3 EXP:10/19/2022
pH Test Strips 0 – 6	LOT#223819AV EXP:8/30/2023
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT 207621 EXP:3/15/2024
Chlorine Test Strips	0264/12023/05 abs 0070 / 2023 / 02

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: ABS

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 6/29/2022
Customer: CEN-DIST
RQ: RQ-2022-06-20-17
Collected By: Matt Bearden,
Sampling Agency: FDEP
Project ID: SMP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Addison Creek @ Enchanted Forest Nature Preserve	 G5CE0112
Addison Creek @ US1	 G5CE0111

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 6/29/2022
1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: A.SHAIK

Rec'd/Inspected

Date: 06/30/2022 / 09:20



RQ-2022-06-20-17	Collected By: Matt Bearden,
Customer: FDEP	Field Report Prepared by: Matt Bearden,
Project ID: SMP	Sampling Agency: FDEP

WIN ID/Field ID:  WIN ID/Field ID: G5CE0112	Comments:
---	-----------

Location:

Location: Addison Creek @ Enchanted Forest Nature Preserve

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos/cm)	Salinity (PPT)
6/29/2022 1010	2.17	27	26.4	6.46	0.25	0.5	0.5	622	0.3

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group		
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A
		Lot # SA1105060		Exp:	4/30/2022							
Metals (P-500ML)		W-ICPMS		W-ICP	W-HARD	Ice	HNO3*		<2			
		Lot #		Exp:								
Filtered Nutrients (P125ML)		W-PO4-F		Field Filtered 0.45 µm Filter								
		Filter Lot #	Syringe Lot #			Ice						
BOD (BP-1L)		OV-BODUNIN					Ice					
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice			1	A	
Physical/Aggregate (Fresh) (P-1L)		Alkalinity / W-F / W-TSS / TURBIDITY / W-CHC / W-COLOR / W-SO4-IC / W-TDS					Ice					
Physical/Aggregate (Marine) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY				X	Ice			1	A	
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #			Formalin						
Periphyton (PT-50ML)		ALGAE-ID					Ice					
Microbiology (Contract Lab Bottle)		E Coli		F Coli	X	Enterococci	X	Ice		1	A	
		Contract Lab										
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3		Ice				
		PCR-GULL2		PCR-GFD								
Tracers (BG-500ML)		W-E8321-DI		W-E8321-MS				Ice				
Pesticides (BG-500ML) (BG-1L)		W-E8321-DI		W-E8321-MS		W-PSNP-TQ		Ice	MCAA Exp.	MCAA Lot#		
		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA Buffer Solution)		W-CT-CL-R						
		W-TR-SQ-R		W-PCB-TQ-R								
Phytoplankton		DTY-QN-C		PKD-QN-BV				Ice				



RQ-2022-06-20-17

Customer: FDEP

Project ID: SMP

Collected By: Matt Bearden,

Field Report Prepared by: Matt Bearden,

Sampling Agency: FDEP

WIN ID/Field ID:



WIN ID/Field ID: G5CE0111

Comments:

Location:

Location: Addison Creek @ US1

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. @	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPTH)
6/29/2022 1045	4.08	50.6	26.1	6.85	0.2	0.4	0.4	888	0.43

Parameter Suite	Parameter Methods		Preservation	pH Check	# Bottles sent to Lab	Bottle Group
Preserved Nutrients (P-500ML)	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP		Ice	H2SO4*		
	Lot #	Exp:		<2		
Metals (P-500ML)	W-ICPMS / W-ICP / W-HARD		Ice	HNO3*		
	Lot #	Exp:		<2		
Filtered Nutrients (P125ML)	W-PO4-F / Field Filtered 0.45 µm Filter		Ice			
	Filter Lot #	Syringe Lot #				
BOD (BP-1L)	OV-BODUNIN		Ice			
Chlorophyll (BP-1L)	CHLSUITE-W		Ice			
Physical/Aggregate (Fresh) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY / W-Cl-IC / W-COLOR / W-SO4-IC / W-TDS		Ice			
Physical/Aggregate (Marine) (P-1L)	Alkalinity / W-F / W-TSS / TURBIDITY		Ice			
Macroinvertebrates (PJ-2L)	MI-FW-QLDC	Formalin Lot #	Formalin			
Periphyton (PT-50ML)	ALGAE-ID		Ice			
Microbiology (Contract Lab Bottle)	E Coli	F Coli	X	Enterococci	x	Ice
	Contract Lab					
Molecular (QPCR-P-500ML)	PCR-HF183	PCR-BacR		PCR-DG3		Ice
	PCR-GULL2	PCR-GFD				
Tracers (BG-500ML)	W-E8321-DI / W-E8321-MS		Ice			
Pesticides (BG-500ML) (BG-1L)	W-E8321-DI	W-E8321-MS	W-PSNP-TQ			
	W-PCL-TQ-R	W-CARB-AA (5 ml of MCAA Buffer Solution)	W-CT-CL-R			
	W-TR-SQ-R	W-PCB-TQ-R				
Phytoplankton	DTY-QN-C		PKD-QN-BV			

Printed: 6/30/2022 11:31:22

Page 1 of 1

Date of Request: 17-MAY-2022
 Created By: BEARDEN_M On: 17-MAY-2022
 Modified By: JASROTIA_P On: 01-JUN-2022
 Customer: CEN-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Central District
 Event Description: Addison Creek retrieval and other Addison

Send Coolers To:

Phone: 407-897-4123
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Matthew Bearden
 Cooler Ship EMail: matthew.bearden@floridadep.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 31-MAY-2022
 Biology Request Reviewed By: JASROTIA_P On: 01-JUN-2022
 Sampling Kit Required: YES Ship on: 10-JUN-2022
 Sampling Kit Shipped: YES On: 06-JUN-2022
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: NO
 Date to Receive Samples: 23-JUN-2022
 Logged In By: SHAIK_A On: 30-JUN-2022

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Matthew Bearden
 Report Notification EMail:
 matthew.bearden@floridadep.gov; victoria.schwartz@floridadep.gov

Comments:

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500-F- C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems

