

Chemical Analysis Report

CEN-DIST-2022-07-12-01

Florida Department of Environmental Protection
Central Laboratory
2600 Blair Stone Road
Tallahassee, FL 32399-2400
DOH Accreditation E31780

Event Description: **Lakes Floyd and Mary Gem LVIs**

Request ID: **RQ-2022-07-11-27**

Customer: **CEN-DIST**

Project ID: **SMP**

Send Reports to:


FL Dept. of Environmental Protection
FL Dept. of Environmental Protection
3319 Maguire Blvd., Suite 232
Orlando, FL 32803-3767
Attn: Matthew Bearden

For additional information please contact

Colin Wright, Ph.D.
Liang-Tsair Lin, Ph.D.
Kerry Tate, Ph.D.
Dr. rer. nat. Bettina Steinbock
Thekkekalathil Chandrasekhar, Ph.D, QA Officer
Phone (850) 245-8085

Certified by: Dr. rer. nat. Bettina Steinbock, Environmental Administrator

Date Certified: 01-AUG-2022 17:57



Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Metals, Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to 1.3×10^3 or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (**) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited by the Florida Department of Health Environmental Laboratory Certification Program or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: Lake Floyd @ Center

Collection Date/Time: 07/11/2022 10:55

Field ID: G4CE0229

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2340373	DEP SOP: NU-094-1	Color (true)	67		PCU	P416502	
	EPA 180.1 Rev. 2.0	Turbidity	0.60	I	NTU	P416507	
	EPA 300.0 Rev. 2.1	Chloride	36		mg Cl/L	P416959	
		Sulfate	8.0		mg SO4/L	P416963	
	SM 2320 B-2011	Total Alkalinity	32		mg CaCO3/L	P416838	
	SM 2540 C-2011	TDS	125		mg/L	P416902	
	SM 2540 D-2011	TSS	2	U	mg/L	P416816	
	SM 4500-F- C-2011	Fluoride	0.039	I	mg F/L	P417357	MS
	EPA 350.1 Rev. 2.0	Ammonia-N	0.01		mg N/L	P417004	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	0.62		mg N/L	P416706	
2340375	EPA 353.2 Rev. 2.0	NO2NO3-N	0.005	I	mg N/L	P416739	
	EPA 365.1 Rev. 2.0	Total-P	0.016		mg P/L	P416802	
	SM 5310 B-2011	Organic Carbon	10		mg C/L	P416723	
	EPA 365.1 Rev. 2.0	O-Phosphate-P	0.004	U	mg P/L	P416494	MS
	dissolved						
2340386	EPA 8321B	2,4-D	0.032		ug/L	P416433	
		Acesulfame K	0.10	U	ug/L	P416342	
		2,4,5-T	0.0040	U	ug/L	P416433	
		AMPA	0.10	U	ug/L	P416342	
		Acetaminophen	0.0080	U	ug/L	P416433	
		Acetamiprid	0.0020	U	ug/L	P416433	
		Endothall	0.25	U	ug/L	P416342	
		Glufosinate	0.10	U	ug/L	P416342	
		Glyphosate	0.10	U	ug/L	P416342	
		Afidopyropen	0.0020	U	ug/L	P416433	
		Bentazon	0.033		ug/L	P416433	
		Sucralose	0.89		ug/L	P416342	
		Benzovindiflupyr	0.0020	U	ug/L	P416433	
		Carbamazepine	0.0012	I	ug/L	P416433	
		Clothianidin	0.0051	I	ug/L	P416433	
		Dinotefuran	0.0054	I	ug/L	P416433	
		Diuron	0.0020	U	ug/L	P416433	
		Fenuron	0.032	U	ug/L	P416433	
		Fluridone	0.026		ug/L	P416433	
		Imazapyr	0.089		ug/L	P416433	
		Hydrocodone	0.0020	U	ug/L	P416433	
		Ibuprofen	0.080	U	ug/L	P416433	
		Imidacloprid	0.010		ug/L	P416433	
		Linuron	0.0040	U	ug/L	P416433	
		Mandestrobin	0.0020	U	ug/L	P416433	
		MCP	0.0040	U	ug/L	P416433	
		Naproxen	0.0080	U	ug/L	P416433	RPD
		Primidone	0.0040	U	ug/L	P416433	
		Pyraclostrobin	0.0020	U	ug/L	P416433	

Field ID: G4CE0229

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2340386	EPA 8321B	Silvex	0.0040	U	ug/L	P416433	
		Thiamethoxam	0.0020	U	ug/L	P416433	
		Tolfenpyrad	0.0020	U	ug/L	P416433	
		Triclopyr	0.0040	U	ug/L	P416433	
2340393	EPA 200.7 Rev. 4.4	Calcium	15.0		mg/L	P416617	
		Iron	41	I	ug/L	P416617	
		Magnesium	2.35		mg/L	P416617	
		Potassium	1.8		mg/L	P416617	
		Sodium	20.6		mg/L	P416617	
		Strontium	46.8		ug/L	P416617	
		Tin	3.0	U	ug/L	P416617	
		Titanium	0.75	U	ug/L	P416617	
		Vanadium	2.0	U	ug/L	P416617	
		Zinc	5.0	U	ug/L	P416617	
	EPA 200.8 Rev. 5.4	Aluminum	25		ug/L	P416617	
		Antimony	0.093	I	ug/L	P416617	
		Arsenic	0.22		ug/L	P416617	
		Barium	4.21		ug/L	P416617	
		Beryllium	0.010	U	ug/L	P416617	
		Boron	41.7		ug/L	P416617	
		Cadmium	0.020	U	ug/L	P416617	
		Chromium	0.40	U	ug/L	P416617	
		Cobalt	0.020	U	ug/L	P416617	
		Copper	0.45	I	ug/L	P416617	
		Lead	0.20	U	ug/L	P416617	
		Manganese	9.42		ug/L	P416617	
		Molybdenum	0.17	I	ug/L	P416617	
		Nickel	0.50	U	ug/L	P416617	
		Selenium	0.20	U	ug/L	P416617	
		Silver	0.010	U	ug/L	P416617	
		Thallium	0.10	U	ug/L	P416617	
	SM 2340 B-2011	Hardness	47.1		mg/L	P416617	
2340395	EPA 8270E	Oxybenzone**	9.6	U	ng/L	P416699	
		Acetochlor	0.24	U	ng/L	P416699	
		Octinoxate**	30	I	ng/L	P416699	
		Alachlor	0.24	U	ng/L	P416699	
		Avobenzone**	96	U	ng/L	P416699	
		Ametryn	1.1	I	ng/L	P416699	
		Atrazine	7.9		ng/L	P416699	
		PBDE-47**	3.8	U	ng/L	P416699	
		Atrazine Desethyl	1.4	U	ng/L	P416699	
		PBDE-99**	4.8	U	ng/L	P416699	
		Azinphos Methyl	1.9	U	ng/L	P416699	
		Tri-o-cresyl Phosphate**	5.8	U	ng/L	P416699	
		Azoxystrobin	1.1	I	ng/L	P416699	

Field ID: G4CE0229

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2340395	EPA 8270E	Bromacil	0.48	U	ng/L	P416699	
		2-Ethylhexyl	12	U	ng/L	P416699	
		2,3,4,5-tetrabromobenzoate (EHTBB)**					
		Butylate	0.38	U	ng/L	P416699	
		Caffeine**	11	I	ng/L	P416699	
		Carbophenothion	0.19	U	ng/L	P416699	
		Carfentrazone Ethyl	0.096	U	ng/L	P416699	
		Chlorfenapyr	0.17	U	ng/L	P416699	
		Chlorpyrifos Ethyl	0.24	U	ng/L	P416699	
		Chlorpyrifos Methyl	0.048	U	ng/L	P416699	
		Coumaphos	0.48	U	ng/L	P416699	
		Cyanazine	3.1	U	ng/L	P416699	
		Cyprodinil	0.096	U	ng/L	P416699	
		Demeton	1.4	U	ng/L	P416699	
		Diazinon	0.12	U	ng/L	P416699	
		Difenoconazole	0.58	U	ng/L	P416699	
		Dimethenamid	0.096	U	ng/L	P416699	
		Dimethomorph	0.17	U	ng/L	P416699	MS
		Disulfoton	0.48	U	ng/L	P416699	
		Dithiopyr	0.49	IV	ng/L	P416699	
		EPTC	1.2	U	ng/L	P416699	
		Ethion	0.14	U	ng/L	P416699	
		Ethoprop	0.096	U	ng/L	P416699	
		Etridiazole	0.14	U	ng/L	P416699	
		Fenamiphos	0.48	U	ng/L	P416699	
		Fenbuconazole	0.19	I	ng/L	P416699	
		Fipronil	0.56	I	ng/L	P416699	
		Fipronil Desulfinyl**	1.9		ng/L	P416699	
		Fipronil Sulfide	1.6		ng/L	P416699	
		Fipronil Sulfone	2.0		ng/L	P416699	
		Fluazifop-P-butyl	0.096	U	ng/L	P416699	
		Fludioxonil	0.12	U	ng/L	P416699	
		Flumioxazin	3.4	I	ng/L	P416699	
		Flutolanil	0.096	U	ng/L	P416699	
		Fluxapyroxad	0.096	U	ng/L	P416699	
		Fonofos	0.19	U	ng/L	P416699	
		Hexazinone	0.59	I	ng/L	P416699	
		Imazalil	0.72	U	ng/L	P416699	
		Iprodione	0.58	U	ng/L	P416699	
		Loratadine**	0.096	UJ	ng/L	P416699	LCS
		Malathion	0.34	U	ng/L	P416699	
		Metaxyl	0.72	U	ng/L	P416699	
		Metolachlor	0.34	U	ng/L	P416699	
		Metribuzin	2.4	U	ng/L	P416699	
		Mevinphos	1.0	U	ng/L	P416699	

Field ID: G4CE0229

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2340395	EPA 8270E	Molinate	0.29	U	ng/L	P416699	
		Myclobutanil	0.24	U	ng/L	P416699	
		Naled	1.4	U	ng/L	P416699	
		Napropamide	0.38	U	ng/L	P416699	
		Norflurazon	0.48	U	ng/L	P416699	
		Oxadiazon	1.4		ng/L	P416699	
		Oxyfluorfen	0.14	U	ng/L	P416699	
		Parathion Ethyl	0.24	U	ng/L	P416699	
		Parathion Methyl	0.53	U	ng/L	P416699	
		Pendimethalin	0.96	U	ng/L	P416699	
		Phenytol**	3.4	UJ	ng/L	P416699	LCS, MS
		Phorate	0.50	U	ng/L	P416699	
		Prodiamine	0.17	U	ng/L	P416699	
		Prometon	0.86	U	ng/L	P416699	
		Prometryn	0.19	U	ng/L	P416699	
		Pronamide	0.14	U	ng/L	P416699	
		Propanil	0.12	U	ng/L	P416699	
		Propargite	1.4	U	ng/L	P416699	RPD
		Propiconazole	0.84	I	ng/L	P416699	
		Pyraflufen Ethyl	0.24	U	ng/L	P416699	
		Pyridaben	3.5		ng/L	P416699	
		Pyriproxyfen	0.12	U	ng/L	P416699	
		Simazine	0.48	U	ng/L	P416699	
		Stirophos	0.12	U	ng/L	P416699	MS
		Sulfentrazone	2.1		ng/L	P416699	
		Tebuconazole	0.48	U	ng/L	P416699	RPD
		Terbufos	0.096	U	ng/L	P416699	
		Terbutylazine	0.41	U	ng/L	P416699	
		Thiobencarb	0.58	U	ng/L	P416699	
		Triadimefon	0.24	U	ng/L	P416699	

Ref. Method and Comment:

SM 2540 D-2011: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

EPA 8270E: V - Due to the presence of dithiopyr in both the Method Blank and the sample. MS accuracy for multiple parameters not assessed due to high content of these parameters in the sample spiked. Refer to the Lab Analysis Report for an explanation of QC Codes.

Sample Location: Lake Gem Mary, Center of lake

Collection Date/Time: 07/11/2022 12:24

Field ID: G4CE0222

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2340374	DEP SOP: NU-094-1	Color (true)	3.1	I	PCU	P416502	
	EPA 180.1 Rev. 2.0	Turbidity	2.1		NTU	P416507	
	EPA 300.0 Rev. 2.1	Chloride	37		mg Cl/L	P416959	
		Sulfate	60		mg SO4/L	P416963	
	SM 2320 B-2011	Total Alkalinity	21		mg CaCO3/L	P416839	
	SM 2540 C-2011	TDS	172	A	mg/L	P416903	
	SM 2540 D-2011	TSS	2	IA	mg/L	P416817	
	SM 4500-F- C-2011	Fluoride	0.035	U	mg F/L	P417357	MS
2340376	EPA 350.1 Rev. 2.0	Ammonia-N	0.004	I	mg N/L	P417004	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	0.38		mg N/L	P416708	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.004	U	mg N/L	P416739	
	EPA 365.1 Rev. 2.0	Total-P	0.011		mg P/L	P416802	
	SM 5310 B-2011	Organic Carbon	3.7		mg C/L	P416723	
2340378	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.004	U	mg P/L	P416495	
2340387	EPA 8321B	2,4-D	0.032		ug/L	P416544	
		Acesulfame K	0.10	U	ug/L	P416474	
		2,4,5-T	0.0040	U	ug/L	P416544	
		AMPA	0.10	U	ug/L	P416474	
		Acetaminophen	0.0080	U	ug/L	P416544	
		Acetamiprid	0.0020	U	ug/L	P416544	
		Endothall	0.25	U	ug/L	P416474	
		Glufosinate	0.10	U	ug/L	P416474	
		Glyphosate	0.10	U	ug/L	P416474	
		Afidopyrophen	0.0020	U	ug/L	P416544	
		Bentazon	0.0031	I	ug/L	P416544	
		Sucralose	1.1		ug/L	P416474	
		Benzovindiflupyr	0.0020	U	ug/L	P416544	
		Carbamazepine	8.0E-04	U	ug/L	P416544	
		Clothianidin	0.0020	U	ug/L	P416544	
		Dinotefuran	0.0020	U	ug/L	P416544	
		Diuron	0.0021	I	ug/L	P416544	
		Fenuron	0.032	U	ug/L	P416544	
		Fluridone	8.0E-04	U	ug/L	P416544	
		Imazapyr	0.0040	U	ug/L	P416544	
		Hydrocodone	0.0020	U	ug/L	P416544	
		Ibuprofen	0.080	U	ug/L	P416544	
		Imidacloprid	0.0025	I	ug/L	P416544	
		Linuron	0.0040	U	ug/L	P416544	
		Mandestrobin	0.0020	U	ug/L	P416544	
		MCP	0.0040	U	ug/L	P416544	
		Naproxen	0.0080	U	ug/L	P416544	
		Primidone	0.0040	U	ug/L	P416544	
		Pyraclostrobin	0.0020	U	ug/L	P416544	

Field ID: G4CE0222

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2340387	EPA 8321B	Silvex	0.0040	U	ug/L	P416544	
		Thiamethoxam	0.0020	U	ug/L	P416544	
		Tolfenpyrad	0.0020	U	ug/L	P416544	
		Triclopyr	0.0040	U	ug/L	P416544	
2340394	EPA 200.7 Rev. 4.4	Calcium	26.7		mg/L	P416617	
		Iron	30	U	ug/L	P416617	
		Magnesium	4.28		mg/L	P416617	
		Potassium	3.4		mg/L	P416617	
		Sodium	22.9		mg/L	P416617	
		Strontium	68.2		ug/L	P416617	
		Tin	3.0	U	ug/L	P416617	
		Titanium	0.79	I	ug/L	P416617	
		Vanadium	2.0	U	ug/L	P416617	
		Zinc	5.0	U	ug/L	P416617	
	EPA 200.8 Rev. 5.4	Aluminum	57		ug/L	P416617	
		Antimony	0.44		ug/L	P416617	
		Arsenic	0.55		ug/L	P416617	
		Barium	18.2		ug/L	P416617	
		Beryllium	0.010	U	ug/L	P416617	
		Boron	52.1		ug/L	P416617	
		Cadmium	0.020	U	ug/L	P416617	
		Chromium	0.40	U	ug/L	P416617	
		Cobalt	0.028	I	ug/L	P416617	
		Copper	1.10		ug/L	P416617	
		Lead	0.20	U	ug/L	P416617	
		Manganese	3.82		ug/L	P416617	
		Molybdenum	0.26	I	ug/L	P416617	
		Nickel	0.50	U	ug/L	P416617	
		Selenium	0.20	U	ug/L	P416617	
		Silver	0.010	U	ug/L	P416617	
		Thallium	0.10	U	ug/L	P416617	
		Hardness	84.4		mg/L	P416617	
2340396	SM 2340 B-2011	Oxybenzone**	9.8	U	ng/L	P416699	
	EPA 8270E	Acetochlor	0.24	U	ng/L	P416699	
		Octinoxate**	28	I	ng/L	P416699	
		Alachlor	0.24	U	ng/L	P416699	
		Avobenzone**	98	U	ng/L	P416699	
		Ametryn	1.2	I	ng/L	P416699	
		Atrazine	96		ng/L	P416699	
		PBDE-47**	3.9	U	ng/L	P416699	
		Atrazine Desethyl	16		ng/L	P416699	
		PBDE-99**	4.9	U	ng/L	P416699	
		Azinphos Methyl	2.0	U	ng/L	P416699	
		Tri-o-cresyl Phosphate**	5.9	U	ng/L	P416699	
		Azoxystrobin	1.8	I	ng/L	P416699	

Field ID: G4CE0222

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2340396	EPA 8270E	Bromacil	0.49	U	ng/L	P416699	MS
		2-Ethylhexyl	12	U	ng/L	P416699	
		2,3,4,5-tetrabromobenzoate (EHTBB)**					
		Butylate	0.39	U	ng/L	P416699	
		Caffeine**	15	I	ng/L	P416699	
		Carbophenothion	0.20	U	ng/L	P416699	
		Carfentrazone Ethyl	0.098	U	ng/L	P416699	
		Chlorfenapyr	0.17	U	ng/L	P416699	
		Chlorpyrifos Ethyl	0.24	U	ng/L	P416699	
		Chlorpyrifos Methyl	0.049	U	ng/L	P416699	
		Coumaphos	0.49	U	ng/L	P416699	
		Cyanazine	3.2	U	ng/L	P416699	
		Cyprodinil	0.098	U	ng/L	P416699	
		Demeton	1.5	U	ng/L	P416699	
		Diazinon	0.12	U	ng/L	P416699	
		Difenoconazole	0.59	U	ng/L	P416699	
		Dimethenamid	0.098	U	ng/L	P416699	
		Dimethomorph	0.17	U	ng/L	P416699	
		Disulfoton	0.49	U	ng/L	P416699	
		Dithiopyr	0.54	IV	ng/L	P416699	
		EPTC	1.2	U	ng/L	P416699	
		Ethion	0.15	U	ng/L	P416699	
		Ethoprop	0.098	U	ng/L	P416699	
		Etridiazole	0.15	U	ng/L	P416699	
		Fenamiphos	0.49	U	ng/L	P416699	
		Fenbuconazole	0.12	U	ng/L	P416699	
		Fipronil	0.24	U	ng/L	P416699	
		Fipronil Desulfinyl**	0.30	I	ng/L	P416699	
		Fipronil Sulfide	0.15	U	ng/L	P416699	
		Fipronil Sulfone	0.19	I	ng/L	P416699	
		Fluazifop-P-butyl	0.098	U	ng/L	P416699	
		Fludioxonil	0.12	U	ng/L	P416699	
		Flumioxazin	1.7	U	ng/L	P416699	
		Flutolanil	0.098	U	ng/L	P416699	
		Fluxapyroxad	0.098	U	ng/L	P416699	
		Fonofos	0.20	U	ng/L	P416699	
		Hexazinone	0.49	U	ng/L	P416699	
		Imazalil	0.73	U	ng/L	P416699	
		Iprodione	0.59	U	ng/L	P416699	
		Loratadine**	0.098	UJ	ng/L	P416699	LCS
		Malathion	0.34	U	ng/L	P416699	
		Metaxyl	0.73	U	ng/L	P416699	
		Metolachlor	0.34	U	ng/L	P416699	
		Metribuzin	2.4	U	ng/L	P416699	
		Mevinphos	1.0	U	ng/L	P416699	

Field ID: G4CE0222

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2340396	EPA 8270E	Molinate	0.29	U	ng/L	P416699	
		Myclobutanil	0.24	U	ng/L	P416699	
		Naled	1.5	U	ng/L	P416699	
		Napropamide	0.39	U	ng/L	P416699	
		Norflurazon	0.49	U	ng/L	P416699	
		Oxadiazon	0.30	I	ng/L	P416699	
		Oxyfluorfen	0.15	U	ng/L	P416699	
		Parathion Ethyl	0.24	U	ng/L	P416699	
		Parathion Methyl	0.54	U	ng/L	P416699	
		Pendimethalin	0.98	U	ng/L	P416699	
		Phenytol**	3.4	UJ	ng/L	P416699	LCS, MS
		Phorate	0.51	U	ng/L	P416699	
		Prodiamine	0.17	U	ng/L	P416699	
		Prometon	0.88	U	ng/L	P416699	
		Prometryn	0.20	U	ng/L	P416699	
		Pronamide	0.15	U	ng/L	P416699	
		Propanil	0.12	U	ng/L	P416699	
		Propargite	1.5	U	ng/L	P416699	RPD
		Propiconazole	1.5	I	ng/L	P416699	
		Pyraflufen Ethyl	0.24	U	ng/L	P416699	
		Pyridaben	0.44	U	ng/L	P416699	
		Pyriproxyfen	0.12	U	ng/L	P416699	
		Simazine	1.8	I	ng/L	P416699	
		Stirophos	0.12	U	ng/L	P416699	MS
		Sulfentrazone	0.49	U	ng/L	P416699	
		Tebuconazole	0.74	I	ng/L	P416699	RPD
		Terbufos	0.098	U	ng/L	P416699	
		Terbutylazine	0.42	U	ng/L	P416699	
		Thiobencarb	0.59	U	ng/L	P416699	
		Triadimefon	0.24	U	ng/L	P416699	

Ref. Method and Comment:

SM 2540 D-2011: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

EPA 8270E: V - Due to the presence of dithiopyr in both the Method Blank and the sample. MS accuracy for multiple parameters not assessed due to high content of these parameters in the sample spiked. Refer to the Lab Analysis Report for an explanation of QC Codes.

Quality Assurance Report

Method Blank Results

Reference Method: DEP SOP: NU-094-1
Batch ID: P416502

Component	Result	Code	Units
Color (true)	2.5	U	PCU

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P416507

Component	Result	Code	Units
Turbidity	0.10	U	NTU

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P416617

Component	Result	Code	Units
Calcium	0.075	U	mg/L
Iron	30	U	ug/L
Magnesium	0.040	U	mg/L
Potassium	0.30	U	mg/L
Sodium	0.50	U	mg/L
Strontium	2.0	U	ug/L
Tin	3.0	U	ug/L
Titanium	0.75	U	ug/L
Vanadium	2.0	U	ug/L
Zinc	5.0	U	ug/L

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P416617

Component	Result	Code	Units
Aluminum	5.0	U	ug/L
Antimony	0.050	U	ug/L
Arsenic	0.050	U	ug/L
Barium	0.20	U	ug/L
Beryllium	0.010	U	ug/L
Boron	2.0	U	ug/L
Cadmium	0.020	U	ug/L
Chromium	0.40	U	ug/L
Cobalt	0.020	U	ug/L
Copper	0.40	U	ug/L
Lead	0.20	U	ug/L
Manganese	0.10	U	ug/L
Molybdenum	0.15	U	ug/L
Nickel	0.50	U	ug/L
Selenium	0.20	U	ug/L
Silver	0.010	U	ug/L
Thallium	0.10	U	ug/L

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P416959

Component	Result	Code	Units
Chloride	0.20	U	mg Cl/L

Quality Assurance Report Method Blank Results

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P416963

Component	Result	Code	Units
Sulfate	0.20	U	mg SO4/L

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P417004

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P416706

Component	Result	Code	Units
Kjeldahl Nitrogen	0.080	U	mg N/L

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P416708

Component	Result	Code	Units
Kjeldahl Nitrogen	0.080	U	mg N/L

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P416739

Component	Result	Code	Units
NO2NO3-N	0.004	U	mg N/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P416802

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P416494

Component	Result	Code	Units
O-Phosphate-P	0.004	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P416495

Component	Result	Code	Units
O-Phosphate-P	0.004	U	mg P/L

Reference Method: EPA 8270E
Batch ID: P416699

Component	Result	Code	Units
2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	12	U	ng/L
2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	12	U	ng/L
Acetochlor	0.25	U	ng/L
Acetochlor	0.25	U	ng/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8270E

Batch ID: P416699

Component	Result	Code	Units
Alachlor	0.25	U	ng/L
Alachlor	0.25	U	ng/L
Ametryn	0.60	U	ng/L
Ametryn	0.60	U	ng/L
Atrazine	0.25	U	ng/L
Atrazine	0.25	U	ng/L
Atrazine Desethyl	1.5	U	ng/L
Atrazine Desethyl	1.5	U	ng/L
Avobenzone	100	U	ng/L
Avobenzone	100	U	ng/L
Azinphos Methyl	2.0	U	ng/L
Azinphos Methyl	2.0	U	ng/L
Azoxystrobin	0.50	U	ng/L
Azoxystrobin	0.50	U	ng/L
Bromacil	0.50	U	ng/L
Bromacil	0.50	U	ng/L
Butylate	0.40	U	ng/L
Butylate	0.40	U	ng/L
Caffeine	7.5	U	ng/L
Caffeine	7.5	U	ng/L
Carbophenothion	0.20	U	ng/L
Carbophenothion	0.20	U	ng/L
Carfentrazone Ethyl	0.10	U	ng/L
Carfentrazone Ethyl	0.10	U	ng/L
Chlorfenapyr	0.18	U	ng/L
Chlorfenapyr	0.18	U	ng/L
Chlorpyrifos Ethyl	0.25	U	ng/L
Chlorpyrifos Ethyl	0.25	U	ng/L
Chlorpyrifos Methyl	0.050	U	ng/L
Chlorpyrifos Methyl	0.050	U	ng/L
Coumaphos	0.50	U	ng/L
Coumaphos	0.50	U	ng/L
Cyanazine	3.2	U	ng/L
Cyanazine	3.2	U	ng/L
Cyprodinil	0.10	U	ng/L
Cyprodinil	0.10	U	ng/L
Demeton	1.5	U	ng/L
Demeton	1.5	U	ng/L
Diazinon	0.12	U	ng/L
Diazinon	0.12	U	ng/L
Difenoconazole	0.60	U	ng/L
Difenoconazole	0.60	U	ng/L
Dimethenamid	0.10	U	ng/L
Dimethenamid	0.10	U	ng/L
Dimethomorph	0.18	U	ng/L
Dimethomorph	0.18	U	ng/L
Disulfoton	0.50	U	ng/L
Disulfoton	0.50	U	ng/L
Dithiopyr	0.26	I	ng/L
Dithiopyr	0.18	U	ng/L
EPTC	1.2	U	ng/L
EPTC	1.2	U	ng/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8270E
 Batch ID: P416699

Component	Result	Code	Units
Ethion	0.15	U	ng/L
Ethion	0.15	U	ng/L
Ethoprop	0.10	U	ng/L
Ethoprop	0.10	U	ng/L
Etridiazole	0.15	U	ng/L
Etridiazole	0.15	U	ng/L
Fenamiphos	0.50	U	ng/L
Fenamiphos	0.50	U	ng/L
Fenbuconazole	0.12	U	ng/L
Fenbuconazole	0.12	U	ng/L
Fipronil	0.25	U	ng/L
Fipronil	0.25	U	ng/L
Fipronil Desulfinyl	0.12	U	ng/L
Fipronil Desulfinyl	0.12	U	ng/L
Fipronil Sulfide	0.15	U	ng/L
Fipronil Sulfide	0.15	U	ng/L
Fipronil Sulfone	0.15	U	ng/L
Fipronil Sulfone	0.15	U	ng/L
Fluazifop-P-butyl	0.10	U	ng/L
Fluazifop-P-butyl	0.10	U	ng/L
Fludioxonil	0.12	U	ng/L
Fludioxonil	0.12	U	ng/L
Flumioxazin	1.8	U	ng/L
Flumioxazin	1.8	U	ng/L
Flutolanil	0.10	U	ng/L
Flutolanil	0.10	U	ng/L
Fluxapyroxad	0.10	U	ng/L
Fluxapyroxad	0.10	U	ng/L
Fonofos	0.20	U	ng/L
Fonofos	0.20	U	ng/L
Hexazinone	0.50	U	ng/L
Hexazinone	0.50	U	ng/L
Imazalil	0.75	U	ng/L
Imazalil	0.75	U	ng/L
Iprodione	0.60	U	ng/L
Iprodione	0.60	U	ng/L
Loratadine	0.10	U	ng/L
Loratadine	0.10	U	ng/L
Malathion	0.35	U	ng/L
Malathion	0.35	U	ng/L
Metalaxyl	0.75	U	ng/L
Metalaxyl	0.75	U	ng/L
Metolachlor	0.35	U	ng/L
Metolachlor	0.35	U	ng/L
Metribuzin	2.5	U	ng/L
Metribuzin	2.5	U	ng/L
Mevinphos	1.0	U	ng/L
Mevinphos	1.0	U	ng/L
Molinate	0.30	U	ng/L
Molinate	0.30	U	ng/L
Myclobutanil	0.25	U	ng/L
Myclobutanil	0.25	U	ng/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8270E

Batch ID: P416699

Component	Result	Code	Units
Naled	1.5	U	ng/L
Naled	1.5	U	ng/L
Napropamide	0.40	U	ng/L
Napropamide	0.40	U	ng/L
Norflurazon	0.50	U	ng/L
Norflurazon	0.50	U	ng/L
Octinoxate	20	U	ng/L
Octinoxate	20	U	ng/L
Oxadiazon	0.30	U	ng/L
Oxadiazon	0.30	U	ng/L
Oxybenzone	10	U	ng/L
Oxybenzone	10	U	ng/L
Oxyfluorfen	0.15	U	ng/L
Oxyfluorfen	0.15	U	ng/L
Parathion Ethyl	0.25	U	ng/L
Parathion Ethyl	0.25	U	ng/L
Parathion Methyl	0.55	U	ng/L
Parathion Methyl	0.55	U	ng/L
PBDE-47	4.0	U	ng/L
PBDE-47	4.0	U	ng/L
PBDE-99	5.0	U	ng/L
PBDE-99	5.0	U	ng/L
Pendimethalin	1.0	U	ng/L
Pendimethalin	1.0	U	ng/L
Phenytoin	3.5	U	ng/L
Phenytoin	3.5	U	ng/L
Phorate	0.52	U	ng/L
Phorate	0.52	U	ng/L
Prodiamine	0.18	U	ng/L
Prodiamine	0.18	U	ng/L
Prometon	0.90	U	ng/L
Prometon	0.90	U	ng/L
Prometryn	0.20	U	ng/L
Prometryn	0.20	U	ng/L
Pronamide	0.15	U	ng/L
Pronamide	0.15	U	ng/L
Propanil	0.12	U	ng/L
Propanil	0.12	U	ng/L
Propargite	1.5	U	ng/L
Propargite	1.5	U	ng/L
Propiconazole	0.50	U	ng/L
Propiconazole	0.50	U	ng/L
Pyraflufen Ethyl	0.25	U	ng/L
Pyraflufen Ethyl	0.25	U	ng/L
Pyridaben	0.45	U	ng/L
Pyridaben	0.45	U	ng/L
Pyriproxyfen	0.12	U	ng/L
Pyriproxyfen	0.12	U	ng/L
Simazine	0.50	U	ng/L
Simazine	0.50	U	ng/L
Stirophos	0.12	U	ng/L
Stirophos	0.12	U	ng/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8270E

Batch ID: P416699

Component	Result	Code	Units
Sulfentrazone	0.50	U	ng/L
Sulfentrazone	0.50	U	ng/L
Tebuconazole	0.50	U	ng/L
Tebuconazole	0.50	U	ng/L
Terbufos	0.10	U	ng/L
Terbufos	0.10	U	ng/L
Terbuthylazine	0.42	U	ng/L
Terbuthylazine	0.42	U	ng/L
Thiobencarb	0.60	U	ng/L
Thiobencarb	0.60	U	ng/L
Tri-o-cresyl Phosphate	6.0	U	ng/L
Tri-o-cresyl Phosphate	6.0	U	ng/L
Triadimefon	0.25	U	ng/L
Triadimefon	0.25	U	ng/L

Reference Method: EPA 8321B

Batch ID: P416342

Component	Result	Code	Units
Acesulfame K	0.10	U	ug/L
AMPA	0.10	U	ug/L
Endothall	0.25	U	ug/L
Glufosinate	0.10	U	ug/L
Glyphosate	0.10	U	ug/L
Sucralose	0.010	U	ug/L

Reference Method: EPA 8321B

Batch ID: P416433

Component	Result	Code	Units
2,4-D	0.0020	U	ug/L
2,4,5-T	0.0040	U	ug/L
Acetaminophen	0.0080	U	ug/L
Acetamiprid	0.0020	U	ug/L
Afidopyropen	0.0020	U	ug/L
Bentazon	8.0E-04	U	ug/L
Benzovindiflupyr	0.0020	U	ug/L
Carbamazepine	8.0E-04	U	ug/L
Clothianidin	0.0020	U	ug/L
Dinotefuran	0.0020	U	ug/L
Diuron	0.0020	U	ug/L
Fenuron	0.032	U	ug/L
Fluridone	8.0E-04	U	ug/L
Hydrocodone	0.0020	U	ug/L
Ibuprofen	0.080	U	ug/L
Imazapyr	0.0040	U	ug/L
Imidacloprid	0.0020	U	ug/L
Linuron	0.0040	U	ug/L
Mandestrobin	0.0020	U	ug/L
MCPP	0.0040	U	ug/L
Naproxen	0.0080	U	ug/L
Primidone	0.0040	U	ug/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8321B

Batch ID: P416433

Component	Result	Code	Units
Pyraclostrobin	0.0020	U	ug/L
Silvex	0.0040	U	ug/L
Thiamethoxam	0.0020	U	ug/L
Tolfenpyrad	0.0020	U	ug/L
Triclopyr	0.0040	U	ug/L

Reference Method: EPA 8321B

Batch ID: P416474

Component	Result	Code	Units
Acesulfame K	0.10	U	ug/L
AMPA	0.10	U	ug/L
Endothall	0.25	U	ug/L
Glufosinate	0.10	U	ug/L
Glyphosate	0.10	U	ug/L
Sucralose	0.010	U	ug/L

Reference Method: EPA 8321B

Batch ID: P416544

Component	Result	Code	Units
2,4-D	0.0020	U	ug/L
2,4,5-T	0.0040	U	ug/L
Acetaminophen	0.0080	U	ug/L
Acetamiprid	0.0020	U	ug/L
Afidopyropen	0.0020	U	ug/L
Bentazon	8.0E-04	U	ug/L
Benzovindiflupyr	0.0020	U	ug/L
Carbamazepine	8.0E-04	U	ug/L
Clothianidin	0.0020	U	ug/L
Dinotefuran	0.0020	U	ug/L
Diuron	0.0020	U	ug/L
Fenuron	0.032	U	ug/L
Fluridone	8.0E-04	U	ug/L
Hydrocodone	0.0020	U	ug/L
Ibuprofen	0.080	U	ug/L
Imazapyr	0.0040	U	ug/L
Imidacloprid	0.0020	U	ug/L
Linuron	0.0040	U	ug/L
Mandestrobin	0.0020	U	ug/L
MCPP	0.0040	U	ug/L
Naproxen	0.0080	U	ug/L
Primidone	0.0040	U	ug/L
Pyraclostrobin	0.0020	U	ug/L
Silvex	0.0040	U	ug/L
Thiamethoxam	0.0020	U	ug/L
Tolfenpyrad	0.0020	U	ug/L
Triclopyr	0.0040	U	ug/L

Quality Assurance Report

Method Blank Results

Reference Method: SM 2320 B-2011
Batch ID: P416838

Component	Result	Code	Units
Total Alkalinity	0.65	U	mg CaCO ₃ /L

Reference Method: SM 2320 B-2011
Batch ID: P416839

Component	Result	Code	Units
Total Alkalinity	0.65	U	mg CaCO ₃ /L

Reference Method: SM 2540 C-2011
Batch ID: P416902

Component	Result	Code	Units
TDS	15	U	mg/L

Reference Method: SM 2540 C-2011
Batch ID: P416903

Component	Result	Code	Units
TDS	15	U	mg/L

Reference Method: SM 2540 D-2011
Batch ID: P416816

Component	Result	Code	Units
TSS	2	U	mg/L

Reference Method: SM 2540 D-2011
Batch ID: P416817

Component	Result	Code	Units
TSS	2	U	mg/L

Reference Method: SM 4500-F- C-2011
Batch ID: P417357

Component	Result	Code	Units
Fluoride	0.035	U	mg F/L

Reference Method: SM 5310 B-2011
Batch ID: P416723

Component	Result	Code	Units
Organic Carbon	0.50	U	mg C/L

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: DEP SOP: NU-094-1
Batch ID: P416502

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Color (true)	98.5		P	90 - 110

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P416507

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Turbidity	95.0		P	90 - 110

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P416617

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Calcium	100		P	85 - 115
Iron	101		P	85 - 115
Magnesium	99.3		P	85 - 115
Potassium	104		P	85 - 115
Sodium	103		P	85 - 115
Strontium	106		P	85 - 115
Tin	99.9		P	85 - 115
Titanium	104		P	85 - 115
Vanadium	103		P	85 - 115
Zinc	99.1		P	85 - 115

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P416617

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Aluminum	104		P	85 - 115
Antimony	105		P	85 - 115
Arsenic	101		P	85 - 115
Barium	97.6		P	85 - 115
Beryllium	95.3		P	85 - 115
Boron	103		P	85 - 115
Cadmium	99.4		P	85 - 115
Chromium	102		P	85 - 115
Cobalt	103		P	85 - 115
Copper	97.9		P	85 - 115
Lead	99.5		P	85 - 115
Manganese	104		P	85 - 115
Molybdenum	101		P	85 - 115
Nickel	101		P	85 - 115
Selenium	102		P	85 - 115
Silver	104		P	85 - 115
Thallium	102		P	85 - 115

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P416959

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Chloride	98.5		P	90 - 110

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 300.0 Rev. 2.1
 Batch ID: P416963

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Sulfate	98.1		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
 Batch ID: P417004

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	97.4		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
 Batch ID: P416706

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	107		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
 Batch ID: P416708

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	102		P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
 Batch ID: P416739

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
NO2NO3-N	103		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
 Batch ID: P416802

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	101		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
 Batch ID: P416494

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
O-Phosphate-P	99.7		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
 Batch ID: P416495

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
O-Phosphate-P	101		P	90 - 110

Reference Method: EPA 8270E
 Batch ID: P416699

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	99.1		P	50 - 150
Acetochlor	95.7		P	65 - 124
Alachlor	95.5		P	61 - 121
Ametryn	88.4		P	52 - 216

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: EPA 8270E
Batch ID: P416699

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Atrazine	91.4		P	68 - 133
Atrazine Desethyl	57.2		P	15 - 160
Avobenzone	91.3		P	76 - 212
Azinphos Methyl	121		P	40 - 292
Azoxystrobin	98.1		P	12 - 242
Bromacil	94.2		P	54 - 167
Butylate	58.7		P	14 - 94.0
Caffeine	74.4		P	10 - 226
Carbophenothion	92.4		P	56 - 129
Carfentrazone Ethyl	137		P	60 - 141
Chlorfenapyr	87.0		P	50 - 150
Chlorpyrifos Ethyl	93.1		P	52 - 122
Chlorpyrifos Methyl	94.6		P	66 - 117
Coumaphos	124		P	50 - 220
Cyanazine	85.6		P	43 - 245
Cyprodinil	94.8		P	50 - 150
Demeton	73.7		P	43 - 188
Diazinon	100		P	69 - 131
Difenoconazole	161		P	34 - 231
Dimethenamid	80.7		P	55 - 118
Dimethomorph	92.0		P	50 - 150
Disulfoton	88.7		P	38 - 141
Dithiopyr	98.0		P	42 - 116
EPTC	48.7		P	18 - 85.0
Ethion	103		P	10 - 131
Ethoprop	80.4		P	65 - 129
Etridiazole	51.2		P	50 - 150
Fenamiphos	93.5		P	31 - 137
Fenbuconazole	128		P	57 - 160
Fipronil	96.8		P	62 - 132
Fipronil Desulfinyl	96.5		P	57 - 131
Fipronil Sulfide	83.4		P	15 - 138
Fipronil Sulfone	93.7		P	21 - 134
Fluazifop-P-butyl	102		P	54 - 133
Fludioxonil	94.8		P	58 - 127
Flumioxazin	153		P	33 - 300
Flutolanil	99.9		P	42 - 130
Fluxapyroxad	101		P	23 - 141
Fonofos	84.3		P	58 - 119
Hexazinone	103		P	68 - 172
Imazalil	80.3		P	48 - 283
Iprodione	134		P	38 - 140
Loratadine	162		F	50 - 150
Malathion	104		P	40 - 137
Metalaxyl	92.5		P	21 - 129
Metolachlor	89.9		P	55 - 122
Metribuzin	94.7		P	38 - 187
Mevinphos	64.9		P	54 - 134
Molinate	68.1		P	41 - 97.0
Myclobutanil	100		P	56 - 125
Naled	82.8		P	10 - 108
Napropamide	85.1		P	50 - 150

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 8270E

Batch ID: P416699

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Norflurazon	105		P	61 - 126
Octinoxate	131		P	30 - 159
Oxadiazon	85.7		P	40 - 119
Oxybenzone	87.2		P	61 - 139
Oxyfluorfen	114		P	61 - 153
Parathion Ethyl	101		P	59 - 130
Parathion Methyl	102		P	65 - 155
PBDE-47	90.6		P	50 - 150
PBDE-99	96.5		P	50 - 150
Pendimethalin	105		P	49 - 138
Phenytoin	42.7		F	50 - 200
Phorate	80.3		P	54 - 161
Prodiamine	77.3		P	33 - 161
Prometon	82.8		P	48 - 140
Prometryn	94.4		P	55 - 134
Pronamide	92.8		P	66 - 137
Propanil	92.4		P	50 - 150
Propargite	123		P	50 - 200
Propiconazole	65.3		P	36 - 150
Pyraflufen Ethyl	121		P	70 - 138
Pyridaben	126		P	50 - 200
Pyriproxyfen	122		P	10 - 165
Simazine	91.8		P	57 - 145
Stiophos	98.0		P	50 - 150
Sulfentrazone	115		P	34 - 140
Tebuconazole	97.6		P	10 - 127
Terbufos	102		P	59 - 138
Terbuthylazine	93.6		P	68 - 119
Thiobencarb	89.4		P	50 - 150
Tri-o-cresyl Phosphate	96.2		P	50 - 150
Triadimefon	95.6		P	50 - 150

Reference Method: EPA 8321B

Batch ID: P416342

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Acesulfame K	95.5		P	40 - 150
AMPA	108		P	40 - 150
Endothall	93.8		P	40 - 150
Glufosinate	104		P	40 - 150
Glyphosate	99.2		P	40 - 150
Sucralose	96.4		P	40 - 150

Reference Method: EPA 8321B

Batch ID: P416433

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2,4-D	86.0		P	40 - 150
2,4,5-T	74.9		P	40 - 150
Acetaminophen	86.0		P	30 - 150
Acetamiprid	89.8		P	40 - 150
Afidopyropen	62.8		P	30 - 150

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: EPA 8321B

Batch ID: P416433

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Bentazon	84.2		P	30 - 150
Benzovindiflupyr	74.1		P	40 - 150
Carbamazepine	83.3		P	40 - 150
Clothianidin	92.5		P	40 - 150
Dinotefuran	91.6		P	40 - 150
Diuron	53.5		P	40 - 150
Fenuron	84.9		P	40 - 150
Fluridone	79.6		P	40 - 150
Hydrocodone	86.0		P	40 - 150
Ibuprofen	75.1		P	40 - 150
Imazapyr	90.6		P	40 - 150
Imidacloprid	115		P	40 - 150
Linuron	80.3		P	40 - 150
Mandestrobin	76.7		P	40 - 150
MCPP	84.1		P	40 - 150
Naproxen	59.1		P	40 - 150
Primidone	90.9		P	40 - 150
Pyraclostrobin	82.0		P	40 - 150
Silvex	68.2		P	40 - 150
Thiamethoxam	86.5		P	40 - 150
Tolfenpyrad	56.5		P	30 - 150
Triclopyr	83.1		P	40 - 150

Reference Method: EPA 8321B

Batch ID: P416474

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Acesulfame K	88.1		P	40 - 150
AMPA	113		P	40 - 150
Endothall	80.3		P	40 - 150
Glufosinate	111		P	40 - 150
Glyphosate	108		P	40 - 150
Sucralose	105		P	40 - 150

Reference Method: EPA 8321B

Batch ID: P416544

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2,4-D	77.5		P	40 - 150
2,4,5-T	71.2		P	40 - 150
Acetaminophen	93.5		P	30 - 150
Acetamiprid	85.0		P	40 - 150
Afidopyropen	60.7		P	30 - 150
Bentazon	97.0		P	30 - 150
Benzovindiflupyr	90.0		P	40 - 150
Carbamazepine	93.0		P	40 - 150
Clothianidin	100		P	40 - 150
Dinotefuran	104		P	40 - 150
Diuron	84.7		P	40 - 150
Fenuron	107		P	40 - 150
Fluridone	99.3		P	40 - 150
Hydrocodone	97.9		P	40 - 150

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: EPA 8321B

Batch ID: P416544

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ibuprofen	82.0		P	40 - 150
Imazapyr	94.2		P	40 - 150
Imidacloprid	110		P	40 - 150
Linuron	104		P	40 - 150
Mandestrobin	89.0		P	40 - 150
MCPP	83.2		P	40 - 150
Naproxen	64.4		P	40 - 150
Primidone	101		P	40 - 150
Pyraclostrobin	81.3		P	40 - 150
Silvex	67.7		P	40 - 150
Thiamethoxam	99.6		P	40 - 150
Tolfenpyrad	44.7		P	30 - 150
Triclopyr	77.4		P	40 - 150

Reference Method: SM 2320 B-2011

Batch ID: P416838

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total Alkalinity	99.5		P	94 - 106

Reference Method: SM 2320 B-2011

Batch ID: P416839

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total Alkalinity	99.5		P	94 - 106

Reference Method: SM 4500-F- C-2011

Batch ID: P417357

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Fluoride	103		P	96 - 104

Reference Method: SM 5310 B-2011

Batch ID: P416723

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Organic Carbon	98.3		P	85 - 115

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 200.7 Rev. 4.4

Batch ID: P416617

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340504	Calcium	98.9		P	80 - 120
2340504	Iron	102		P	80 - 120
2340504	Magnesium	103		P	80 - 120
2340504	Potassium	101		P	80 - 120
2340504	Sodium	101		P	80 - 120
2340504	Strontium	107		P	80 - 120
2340504	Tin	99.3		P	80 - 120
2340504	Titanium	106		P	80 - 120
2340504	Vanadium	105		P	80 - 120
2340504	Zinc	101		P	80 - 120
2340703	Calcium	96.4		P	80 - 120
2340703	Iron	99.9	98.3	P/P	80 - 120
2340703	Magnesium	98.6	96.8	P/P	80 - 120
2340703	Potassium	98.9	99.4	P/P	80 - 120
2340703	Sodium	103	101	P/P	80 - 120
2340703	Strontium	104	104	P/P	80 - 120
2340703	Tin	96.3	95.8	P/P	80 - 120
2340703	Titanium	101	100	P/P	80 - 120
2340703	Vanadium	101	100	P/P	80 - 120
2340703	Zinc	95.1	94.2	P/P	80 - 120

Reference Method: EPA 200.8 Rev. 5.4

Batch ID: P416617

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340504	Aluminum	100		P	80 - 120
2340504	Antimony	104		P	80 - 120
2340504	Arsenic	99.4		P	80 - 120
2340504	Barium	98.2		P	80 - 120
2340504	Beryllium	98.0		P	80 - 120
2340504	Boron	98.0		P	80 - 120
2340504	Cadmium	99.2		P	80 - 120
2340504	Chromium	98.3		P	80 - 120
2340504	Cobalt	99.3		P	80 - 120
2340504	Copper	95.2		P	80 - 120
2340504	Lead	98.3		P	80 - 120
2340504	Manganese	100		P	80 - 120
2340504	Molybdenum	99.1		P	80 - 120
2340504	Nickel	97.2		P	80 - 120
2340504	Selenium	99.8		P	80 - 120
2340504	Silver	99.4		P	80 - 120
2340504	Thallium	101		P	80 - 120
2340703	Aluminum	103	102	P/P	80 - 120
2340703	Antimony	107	104	P/P	80 - 120
2340703	Arsenic	99.3	98.6	P/P	80 - 120
2340703	Barium	99.1	104	P/P	80 - 120
2340703	Beryllium	93.4	92.5	P/P	80 - 120
2340703	Boron	108	105	P/P	80 - 120
2340703	Cadmium	103	100	P/P	80 - 120
2340703	Chromium	102	100	P/P	80 - 120
2340703	Cobalt	101	99.5	P/P	80 - 120
2340703	Copper	93.9	92.3	P/P	80 - 120

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P416617

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340703	Lead	100	99.0	P/P	80 - 120
2340703	Manganese	104	102	P/P	80 - 120
2340703	Molybdenum	103	102	P/P	80 - 120
2340703	Nickel	98.4	97.4	P/P	80 - 120
2340703	Selenium	97.0	97.6	P/P	80 - 120
2340703	Silver	104	101	P/P	80 - 120
2340703	Thallium	104	103	P/P	80 - 120

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P416959

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340220	Chloride	99.3		P	90 - 110
2340232	Chloride	98.2		P	90 - 110

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P416963

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340220	Sulfate	97.6		P	90 - 110
2340232	Sulfate	96.3		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P417004

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340376	Ammonia-N	95.2	98.2	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P416706

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340224	Kjeldahl Nitrogen	101	95.6	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P416708

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340226	Kjeldahl Nitrogen	96.8	110	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P416739

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340322	NO2NO3-N	102	102	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P416802

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340324	Total-P	103	103	P/P	90 - 110

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 365.1 Rev. 2.0 dissolved
 Batch ID: P416494

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340214	O-Phosphate-P	91.3	86.7	P/F	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
 Batch ID: P416495

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340378	O-Phosphate-P	99.3	101	P/P	90 - 110

Reference Method: EPA 8270E
 Batch ID: P416699

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340505	2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	96.0	87.3	P/P	50 - 150
2340505	Acetochlor	102	107	P/P	65 - 124
2340505	Alachlor	91.8	91.7	P/P	61 - 121
2340505	Ametryn	82.3	80.5	P/P	52 - 216
2340505	Atrazine Desethyl	60.9	62.6	P/P	15 - 160
2340505	Avobenzene	93.0	85.6	P/P	59 - 206
2340505	Azinphos Methyl	142	142	P/P	40 - 292
2340505	Azoxystrobin	142	127	P/P	12 - 242
2340505	Bromacil	82.7	98.9	P/P	54 - 167
2340505	Butylate	59.9	60.8	P/P	14 - 94.0
2340505	Caffeine	75.3	76.8	P/P	10 - 226
2340505	Carbophenothion	82.5	82.4	P/P	49 - 122
2340505	Carfentrazone Ethyl	123	110	P/P	53 - 138
2340505	Chlorfenapyr	64.1	59.5	P/P	50 - 150
2340505	Chlorpyrifos Ethyl	67.2	68.2	P/P	52 - 122
2340505	Chlorpyrifos Methyl	83.5	81.3	P/P	66 - 117
2340505	Coumaphos	100	81.3	P/P	50 - 220
2340505	Cyanazine	85.9	85.7	P/P	43 - 245
2340505	Cyprodinil	94.9	89.6	P/P	50 - 150
2340505	Demeton	97.2	77.2	P/P	43 - 188
2340505	Diazinon	111	119	P/P	69 - 131
2340505	Difenoconazole	160	143	P/P	34 - 231
2340505	Dimethenamid	87.0	82.1	P/P	55 - 118
2340505	Dimethomorph	154	132	F/P	50 - 150
2340505	Disulfoton	91.8	84.3	P/P	38 - 141
2340505	Dithiopyr	99.7	90.9	P/P	42 - 116
2340505	EPTC	54.6	57.6	P/P	18 - 85.0
2340505	Ethion	50.7	34.5	P/P	10 - 131
2340505	Ethoprop	104	99.1	P/P	65 - 129
2340505	Etridiazole	70.7	76.8	P/P	50 - 150
2340505	Fenamiphos	59.3	51.0	P/P	31 - 137
2340505	Fenbuconazole	109	88.5	P/P	57 - 160
2340505	Fipronil	97.0	90.8	P/P	62 - 132
2340505	Fipronil Desulfinyl	96.4	91.9	P/P	57 - 131
2340505	Fipronil Sulfide	59.3	49.8	P/P	15 - 138
2340505	Fipronil Sulfone	79.1	73.4	P/P	21 - 134
2340505	Fluazifop-P-butyl	84.4	69.5	P/P	54 - 133
2340505	Fludioxonil	84.4	68.0	P/P	58 - 127
2340505	Flumioxazin	166	149	P/P	33 - 300
2340505	Flutolanil	85.2	85.4	P/P	42 - 130

Quality Assurance Report

Matrix Spike Accuracy

Reference Method: EPA 8270E

Batch ID: P416699

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340505	Fluxapyroxad	73.4	57.5	P/P	23 - 141
2340505	Fonofos	85.0	78.0	P/P	58 - 119
2340505	Hexazinone	103	94.2	P/P	68 - 172
2340505	Imazalil	78.8	96.1	P/P	48 - 283
2340505	Iprodione	111	96.6	P/P	38 - 140
2340505	Loratadine	144	131	P/P	50 - 150
2340505	Malathion	95.9	98.8	P/P	40 - 137
2340505	Metolachlor	89.9	93.4	P/P	55 - 122
2340505	Metribuzin	102	110	P/P	38 - 187
2340505	Mevinphos	109	99.0	P/P	54 - 134
2340505	Molinate	82.5	83.2	P/P	41 - 97.0
2340505	Myclobutanil	89.2	81.6	P/P	56 - 125
2340505	Naled	83.4	79.5	P/P	10 - 108
2340505	Napropamide	78.4	65.6	P/P	50 - 150
2340505	Octinoxate	119	92.6	P/P	25 - 150
2340505	Oxadiazon	82.4	71.8	P/P	40 - 119
2340505	Oxybenzone	94.2	86.3	P/P	59 - 147
2340505	Oxyfluorfen	103	83.0	P/P	61 - 153
2340505	Parathion Ethyl	113	102	P/P	59 - 130
2340505	Parathion Methyl	117	110	P/P	65 - 155
2340505	PBDE-47	78.2	70.1	P/P	50 - 150
2340505	PBDE-99	79.8	70.7	P/P	50 - 150
2340505	Pendimethalin	103	94.7	P/P	49 - 138
2340505	Phenytoin	13.9	11.3	F/F	50 - 200
2340505	Phorate	161	155	P/P	54 - 161
2340505	Prodiamine	39.9	51.4	P/P	33 - 161
2340505	Prometon	92.4	85.9	P/P	48 - 140
2340505	Prometryn	90.0	88.9	P/P	55 - 134
2340505	Pronamide	119	121	P/P	66 - 137
2340505	Propanil	99.2	93.3	P/P	50 - 150
2340505	Propargite	73.8	53.3	P/P	50 - 200
2340505	Propiconazole	105	86.5	P/P	36 - 150
2340505	Pyraflufen Ethyl	106	98.4	P/P	50 - 150
2340505	Pyridaben	119	101	P/P	50 - 200
2340505	Pyriproxyfen	87.8	78.2	P/P	10 - 165
2340505	Stirophos	39.5	37.1	F/F	50 - 150
2340505	Sulfentrazone	107	108	P/P	34 - 140
2340505	Tebuconazole	31.3	18.8	P/P	10 - 127
2340505	Terbufos	113	106	P/P	59 - 138
2340505	Terbutylazine	92.6	101	P/P	68 - 119
2340505	Thiobencarb	89.7	100	P/P	50 - 150
2340505	Tri-o-cresyl Phosphate	95.7	86.4	P/P	50 - 150
2340505	Triadimefon	91.7	83.2	P/P	50 - 150

Reference Method: EPA 8321B

Batch ID: P416342

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2339950	Acesulfame K	79.5	92.9	P/P	40 - 150
2339950	AMPA	102	128	P/P	40 - 150
2339950	Endothall	78.7	89.5	P/P	40 - 150
2339950	Glufosinate	88.9	106	P/P	40 - 150

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8321B
Batch ID: P416342

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2339950	Glyphosate	70.1	88.1	P/P	40 - 150
2339950	Sucralose	79.5	94.8	P/P	40 - 150

Reference Method: EPA 8321B
Batch ID: P416433

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2339950	2,4-D	93.4	96.3	P/P	40 - 150
2339950	2,4,5-T	80.3	89.6	P/P	40 - 150
2339950	Acetaminophen	90.6	93.3	P/P	30 - 150
2339950	Acetamiprid	77.9	92.8	P/P	40 - 150
2339950	Afidopyropen	58.5	63.3	P/P	30 - 150
2339950	Bentazon	79.0	76.6	P/P	30 - 150
2339950	Benzovindiflupyr	89.1	86.5	P/P	40 - 150
2339950	Carbamazepine	88.6	93.8	P/P	40 - 150
2339950	Clothianidin	103	95.3	P/P	40 - 150
2339950	Dinotefuran	100	107	P/P	40 - 150
2339950	Diuron	79.5	65.2	P/P	40 - 150
2339950	Fenuron	85.8	88.7	P/P	40 - 150
2339950	Fluridone	81.8	80.5	P/P	40 - 150
2339950	Hydrocodone	91.9	92.9	P/P	40 - 150
2339950	Ibuprofen	83.7	66.5	P/P	40 - 150
2339950	Imazapyr	87.5	89.9	P/P	40 - 150
2339950	Imidacloprid	133	128	P/P	40 - 150
2339950	Linuron	80.1	77.3	P/P	40 - 150
2339950	Mandestrobin	78.6	81.1	P/P	40 - 150
2339950	MCPP	91.9	99.6	P/P	40 - 150
2339950	Naproxen	54.2	75.8	P/P	40 - 150
2339950	Primidone	92.8	97.6	P/P	40 - 150
2339950	Pyraclostrobin	81.8	86.5	P/P	40 - 150
2339950	Silvex	82.2	82.6	P/P	40 - 150
2339950	Thiamethoxam	94.0	101	P/P	40 - 150
2339950	Tolfenpyrad	55.1	54.0	P/P	30 - 150
2339950	Triclopyr	87.4	106	P/P	40 - 150

Reference Method: EPA 8321B
Batch ID: P416474

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340387	Acesulfame K	75.9	76.4	P/P	40 - 150
2340387	AMPA	96.9	97.2	P/P	40 - 150
2340387	Endothall	83.3	81.1	P/P	40 - 150
2340387	Glufosinate	72.7	70.8	P/P	40 - 150
2340387	Glyphosate	84.2	88.5	P/P	40 - 150
2340387	Sucralose	98.5	99.2	P/P	40 - 150

Reference Method: EPA 8321B
Batch ID: P416544

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340387	2,4-D	88.3	84.5	P/P	40 - 150
2340387	2,4,5-T	60.0	67.6	P/P	40 - 150

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8321B

Batch ID: P416544

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340387	Acetaminophen	113	107	P/P	30 - 150
2340387	Acetamiprid	86.8	87.1	P/P	40 - 150
2340387	Afidopyropen	74.5	74.7	P/P	30 - 150
2340387	Bentazon	85.4	84.3	P/P	30 - 150
2340387	Benzovindiflupyr	87.7	89.8	P/P	40 - 150
2340387	Carbamazepine	97.3	97.1	P/P	40 - 150
2340387	Clothianidin	115	119	P/P	40 - 150
2340387	Dinotefuran	139	135	P/P	40 - 150
2340387	Diuron	83.6	69.2	P/P	40 - 150
2340387	Fenuron	90.4	92.5	P/P	40 - 150
2340387	Fluridone	81.6	88.4	P/P	40 - 150
2340387	Hydrocodone	101	104	P/P	40 - 150
2340387	Ibuprofen	72.6	73.6	P/P	40 - 150
2340387	Imazapyr	92.3	86.0	P/P	40 - 150
2340387	Imidacloprid	146	149	P/P	40 - 150
2340387	Linuron	88.3	91.2	P/P	40 - 150
2340387	Mandestrobin	76.2	80.5	P/P	40 - 150
2340387	MCPP	94.9	80.0	P/P	40 - 150
2340387	Naproxen	74.9	86.2	P/P	40 - 150
2340387	Primidone	101	107	P/P	40 - 150
2340387	Pyraclostrobin	85.9	89.4	P/P	40 - 150
2340387	Silvex	70.9	82.8	P/P	40 - 150
2340387	Thiamethoxam	129	135	P/P	40 - 150
2340387	Tolfenpyrad	49.4	49.6	P/P	30 - 150
2340387	Triclopyr	71.7	80.8	P/P	40 - 150

Reference Method: SM 4500-F- C-2011

Batch ID: P417357

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340221	Fluoride	103	104	P/F	94 - 104

Reference Method: SM 5310 B-2011

Batch ID: P416723

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2340375	Organic Carbon	100	100	P/P	85 - 115

Quality Assurance Report Precision

Reference Method: DEP SOP: NU-094-1
Batch ID: P416502

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340407	Color (true)	0.591	Sample	P	0 - 20

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P416507

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340232	Turbidity	3.72	Sample	P	0 - 20

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P416617

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340703	Calcium	1.24	Spike	P	0 - 20
2340703	Iron	1.64	Spike	P	0 - 20
2340703	Magnesium	1.06	Spike	P	0 - 20
2340703	Potassium	0.470	Spike	P	0 - 20
2340703	Sodium	0.831	Spike	P	0 - 20
2340703	Strontium	0.676	Spike	P	0 - 20
2340703	Tin	0.586	Spike	P	0 - 20
2340703	Titanium	0.914	Spike	P	0 - 20
2340703	Vanadium	0.936	Spike	P	0 - 20
2340703	Zinc	0.989	Spike	P	0 - 20

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P416617

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340703	Aluminum	1.59	Spike	P	0 - 20
2340703	Antimony	2.89	Spike	P	0 - 20
2340703	Arsenic	0.715	Spike	P	0 - 20
2340703	Barium	4.89	Spike	P	0 - 20
2340703	Beryllium	1.02	Spike	P	0 - 20
2340703	Boron	2.34	Spike	P	0 - 20
2340703	Cadmium	2.89	Spike	P	0 - 20
2340703	Chromium	1.11	Spike	P	0 - 20
2340703	Cobalt	1.76	Spike	P	0 - 20
2340703	Copper	1.68	Spike	P	0 - 20
2340703	Lead	1.14	Spike	P	0 - 20
2340703	Manganese	1.49	Spike	P	0 - 20
2340703	Molybdenum	0.793	Spike	P	0 - 20
2340703	Nickel	0.995	Spike	P	0 - 20
2340703	Selenium	0.570	Spike	P	0 - 20
2340703	Silver	2.74	Spike	P	0 - 20
2340703	Thallium	0.749	Spike	P	0 - 20

Quality Assurance Report Precision

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P416959

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340220	Chloride	0.259	Sample	P	0 - 20

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P416963

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340220	Sulfate	0.557	Sample	P	0 - 20

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P417004

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340376	Ammonia-N	2.88	Spike	P	0 - 20

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P416706

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340224	Kjeldahl Nitrogen	4.52	Spike	P	0 - 20

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P416708

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340226	Kjeldahl Nitrogen	8.54	Spike	P	0 - 20

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P416739

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340322	NO2NO3-N	0.445	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P416802

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340324	Total-P	0.0	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P416494

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340214	O-Phosphate-P	3.61	Spike	P	0 - 20

Quality Assurance Report Precision

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P416495

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340378	O-Phosphate-P	1.70	Spike	P	0 - 20

Reference Method: EPA 8270E
Batch ID: P416699

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340505	2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	9.42	Spike	P	0 - 30
2340505	Acetochlor	4.48	Spike	P	0 - 27
2340505	Alachlor	0.0879	Spike	P	0 - 27
2340505	Ametryn	1.86	Spike	P	0 - 34
2340505	Atrazine	4.66	Spike	P	0 - 41
2340505	Atrazine Desethyl	2.36	Spike	P	0 - 38
2340505	Avobenzone	8.31	Spike	P	0 - 30
2340505	Azinphos Methyl	0.347	Spike	P	0 - 62
2340505	Azoxystrobin	9.19	Spike	P	0 - 32
2340505	Bromacil	14.7	Spike	P	0 - 30
2340505	Butylate	1.38	Spike	P	0 - 59
2340505	Caffeine	1.99	Spike	P	0 - 60
2340505	Carbophenothion	0.0591	Spike	P	0 - 25
2340505	Carfentrazone Ethyl	11.0	Spike	P	0 - 26
2340505	Chlorfenapyr	7.50	Spike	P	0 - 30
2340505	Chlorpyrifos Ethyl	1.52	Spike	P	0 - 27
2340505	Chlorpyrifos Methyl	2.65	Spike	P	0 - 26
2340505	Coumaphos	20.8	Spike	P	0 - 30
2340505	Cyanazine	0.286	Spike	P	0 - 58
2340505	Cyprodinil	5.69	Spike	P	0 - 30
2340505	Demeton	22.9	Spike	P	0 - 25
2340505	Diazinon	7.74	Spike	P	0 - 29
2340505	Difenoconazole	11.2	Spike	P	0 - 25
2340505	Dimethenamid	5.75	Spike	P	0 - 30
2340505	Dimethomorph	15.2	Spike	P	0 - 30
2340505	Disulfoton	8.46	Spike	P	0 - 33
2340505	Dithiopyr	8.43	Spike	P	0 - 22
2340505	EPTC	5.32	Spike	P	0 - 38
2340505	Ethion	37.9	Spike	P	0 - 79
2340505	Ethoprop	4.50	Spike	P	0 - 23
2340505	Etridiazole	8.29	Spike	P	0 - 30
2340505	Fenamiphos	15.1	Spike	P	0 - 58
2340505	Fenbuconazole	18.8	Spike	P	0 - 37
2340505	Fipronil	6.60	Spike	P	0 - 33
2340505	Fipronil Desulfinyl	4.77	Spike	P	0 - 26
2340505	Fipronil Sulfide	17.4	Spike	P	0 - 37
2340505	Fipronil Sulfone	7.44	Spike	P	0 - 50
2340505	Fluazifop-P-butyl	19.3	Spike	P	0 - 24
2340505	Fludioxonil	21.4	Spike	P	0 - 26
2340505	Flumioxazin	10.4	Spike	P	0 - 37
2340505	Flutolanil	0.234	Spike	P	0 - 26
2340505	Fluxapyroxad	24.3	Spike	P	0 - 34
2340505	Fonofos	8.62	Spike	P	0 - 27
2340505	Hexazinone	8.78	Spike	P	0 - 36

Quality Assurance Report

Precision

Reference Method: EPA 8270E

Batch ID: P416699

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340505	Imazalil	19.8	Spike	P	0 - 65
2340505	Iprodione	14.2	Spike	P	0 - 33
2340505	Loratadine	8.94	Spike	P	0 - 30
2340505	Malathion	2.90	Spike	P	0 - 44
2340505	Metalaxyl	1.99	Spike	P	0 - 38
2340505	Metolachlor	3.47	Spike	P	0 - 36
2340505	Metribuzin	7.63	Spike	P	0 - 63
2340505	Mevinphos	9.66	Spike	P	0 - 26
2340505	Molinate	0.905	Spike	P	0 - 40
2340505	Myclobutanil	8.93	Spike	P	0 - 21
2340505	Naled	4.75	Spike	P	0 - 26
2340505	Napropamide	17.7	Spike	P	0 - 30
2340505	Norflurazon	5.74	Spike	P	0 - 24
2340505	Octinoxate	20.4	Spike	P	0 - 30
2340505	Oxadiazon	13.9	Spike	P	0 - 27
2340505	Oxybenzone	8.74	Spike	P	0 - 30
2340505	Oxyfluorfen	21.7	Spike	P	0 - 24
2340505	Parathion Ethyl	10.0	Spike	P	0 - 28
2340505	Parathion Methyl	5.67	Spike	P	0 - 27
2340505	PBDE-47	10.9	Spike	P	0 - 30
2340505	PBDE-99	12.2	Spike	P	0 - 30
2340505	Pendimethalin	8.56	Spike	P	0 - 31
2340505	Phenytoin	20.4	Spike	P	0 - 30
2340505	Phorate	3.68	Spike	P	0 - 27
2340505	Prodiamine	25.2	Spike	P	0 - 52
2340505	Prometon	7.23	Spike	P	0 - 31
2340505	Prometryn	1.16	Spike	P	0 - 28
2340505	Pronamide	1.91	Spike	P	0 - 26
2340505	Propanil	6.17	Spike	P	0 - 30
2340505	Propargite	32.3	Spike	F	0 - 30
2340505	Propiconazole	15.4	Spike	P	0 - 31
2340505	Pyraflufen Ethyl	7.84	Spike	P	0 - 30
2340505	Pyridaben	16.3	Spike	P	0 - 30
2340505	Pyriproxyfen	11.5	Spike	P	0 - 50
2340505	Simazine	1.39	Spike	P	0 - 29
2340505	Stirophos	6.35	Spike	P	0 - 30
2340505	Sulfentrazone	0.607	Spike	P	0 - 33
2340505	Tebuconazole	50.0	Spike	F	0 - 44
2340505	Terbufos	5.92	Spike	P	0 - 29
2340505	Terbutylazine	8.34	Spike	P	0 - 27
2340505	Thiobencarb	11.1	Spike	P	0 - 30
2340505	Tri-o-cresyl Phosphate	10.2	Spike	P	0 - 30
2340505	Triadimefon	9.73	Spike	P	0 - 30

Reference Method: EPA 8321B

Batch ID: P416342

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2339950	Acesulfame K	15.6	Spike	P	0 - 30
2339950	AMPA	22.3	Spike	P	0 - 30

Quality Assurance Report Precision

Reference Method: EPA 8321B
 Batch ID: P416342

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2339950	Endothall	12.9	Spike	P	0 - 30
2339950	Glufosinate	17.8	Spike	P	0 - 30
2339950	Glyphosate	22.7	Spike	P	0 - 30
2339950	Sucralose	16.0	Spike	P	0 - 30

Reference Method: EPA 8321B
 Batch ID: P416433

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2339950	2,4-D	3.12	Spike	P	0 - 30
2339950	2,4,5-T	10.9	Spike	P	0 - 30
2339950	Acetaminophen	2.96	Spike	P	0 - 30
2339950	Acetamiprid	17.4	Spike	P	0 - 30
2339950	Afidopyropen	7.88	Spike	P	0 - 30
2339950	Bentazon	3.06	Spike	P	0 - 30
2339950	Benzovindiflupyr	2.96	Spike	P	0 - 30
2339950	Carbamazepine	5.73	Spike	P	0 - 30
2339950	Clothianidin	7.88	Spike	P	0 - 30
2339950	Dinotefuran	6.83	Spike	P	0 - 30
2339950	Diuron	19.7	Spike	P	0 - 30
2339950	Fenuron	3.41	Spike	P	0 - 30
2339950	Fluridone	1.57	Spike	P	0 - 30
2339950	Hydrocodone	1.12	Spike	P	0 - 30
2339950	Ibuprofen	22.9	Spike	P	0 - 30
2339950	Imazapyr	2.70	Spike	P	0 - 30
2339950	Imidacloprid	3.87	Spike	P	0 - 30
2339950	Linuron	3.52	Spike	P	0 - 30
2339950	Mandestrobin	3.05	Spike	P	0 - 30
2339950	MCPP	8.06	Spike	P	0 - 30
2339950	Naproxen	33.2	Spike	F	0 - 30
2339950	Primidone	5.04	Spike	P	0 - 30
2339950	Pyraclostrobin	5.62	Spike	P	0 - 30
2339950	Silvex	0.531	Spike	P	0 - 30
2339950	Thiamethoxam	7.59	Spike	P	0 - 30
2339950	Tolfenpyrad	1.97	Spike	P	0 - 30
2339950	Triclopyr	19.5	Spike	P	0 - 30

Reference Method: EPA 8321B
 Batch ID: P416474

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340387	Acesulfame K	0.698	Spike	P	0 - 30
2340387	AMPA	0.270	Spike	P	0 - 30
2340387	Endothall	2.66	Spike	P	0 - 30
2340387	Glufosinate	2.62	Spike	P	0 - 30
2340387	Glyphosate	5.07	Spike	P	0 - 30
2340387	Sucralose	0.509	Spike	P	0 - 30

Quality Assurance Report Precision

Reference Method: EPA 8321B
Batch ID: P416544

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340387	2,4-D	3.08	Spike	P	0 - 30
2340387	2,4,5-T	12.0	Spike	P	0 - 30
2340387	Acetaminophen	5.18	Spike	P	0 - 30
2340387	Acetamiprid	0.388	Spike	P	0 - 30
2340387	Afidopyropen	0.284	Spike	P	0 - 30
2340387	Bentazon	0.830	Spike	P	0 - 30
2340387	Benzovindiflupyr	2.40	Spike	P	0 - 30
2340387	Carbamazepine	0.259	Spike	P	0 - 30
2340387	Clothianidin	3.83	Spike	P	0 - 30
2340387	Dinotefuran	2.76	Spike	P	0 - 30
2340387	Diuron	18.2	Spike	P	0 - 30
2340387	Fenuron	2.34	Spike	P	0 - 30
2340387	Fluridone	7.92	Spike	P	0 - 30
2340387	Hydrocodone	3.04	Spike	P	0 - 30
2340387	Ibuprofen	1.44	Spike	P	0 - 30
2340387	Imazapyr	7.09	Spike	P	0 - 30
2340387	Imidacloprid	1.69	Spike	P	0 - 30
2340387	Linuron	3.16	Spike	P	0 - 30
2340387	Mandestrobin	5.41	Spike	P	0 - 30
2340387	MCP	17.0	Spike	P	0 - 30
2340387	Naproxen	14.0	Spike	P	0 - 30
2340387	Primidone	5.65	Spike	P	0 - 30
2340387	Pyraclostrobin	4.02	Spike	P	0 - 30
2340387	Silvex	15.5	Spike	P	0 - 30
2340387	Thiamethoxam	4.54	Spike	P	0 - 30
2340387	Tolfenpyrad	0.481	Spike	P	0 - 30
2340387	Triclopyr	11.9	Spike	P	0 - 30

Reference Method: SM 2320 B-2011
Batch ID: P416838

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340221	Total Alkalinity	1.29	Sample	P	0 - 3.8

Reference Method: SM 2320 B-2011
Batch ID: P416839

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340697	Total Alkalinity	1.00	Sample	P	0 - 3.8

Reference Method: SM 2540 C-2011
Batch ID: P416902

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340211	TDS	3.15	Sample	P	0 - 10

Quality Assurance Report Precision

Reference Method: SM 2540 C-2011
Batch ID: P416903

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340374	TDS	7.54	Sample	P	0 - 10

Reference Method: SM 4500-F- C-2011
Batch ID: P417357

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340221	Fluoride	0.953	Spike	P	0 - 1.6

Reference Method: SM 5310 B-2011
Batch ID: P416723

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2340375	Organic Carbon	0.0996	Spike	P	0 - 20

* Sample, spike and/or laboratory control sample precision (LCS) is reported.

Quality Assurance Report Surrogates

Lab Sample ID: 2340386

Field Sample ID: G4CE0229

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	92.3	P	30 - 160
EPA 8321B	Acetaminophen-d4	91.8	P	30 - 160
EPA 8321B	Carbamazepine-d10	80.8	P	30 - 160
EPA 8321B	Diuron-d6	56.1	P	30 - 160
EPA 8321B	Endothall-d6	69.6	P	30 - 160
EPA 8321B	Glyphosate 13C 15N	78.5	P	30 - 160
EPA 8321B	Ibuprofen-d3	61.6	P	30 - 160
EPA 8321B	Primidone-d5	93.1	P	30 - 160
EPA 8321B	Sucralose-d6	96.0	P	30 - 160

Lab Sample ID: 2340387

Field Sample ID: G4CE0222

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	92.2	P	30 - 160
EPA 8321B	Acetaminophen-d4	103	P	30 - 160
EPA 8321B	Carbamazepine-d10	94.7	P	30 - 160
EPA 8321B	Diuron-d6	76.3	P	30 - 160
EPA 8321B	Endothall-d6	81.8	P	30 - 160
EPA 8321B	Glyphosate 13C 15N	80.3	P	30 - 160
EPA 8321B	Ibuprofen-d3	66.1	P	30 - 160
EPA 8321B	Primidone-d5	97.5	P	30 - 160
EPA 8321B	Sucralose-d6	99.5	P	30 - 160

Lab Sample ID: 2340395

Field Sample ID: G4CE0229

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8270E	Caffeine-d9	70.6	P	20 - 200
EPA 8270E	Simazine-d10	129	P	71 - 140
EPA 8270E	Terbufos-d10	99.5	P	62 - 131
EPA 8270E	Terphenyl-d14	111	P	52 - 141

Lab Sample ID: 2340396

Field Sample ID: G4CE0222

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8270E	Caffeine-d9	80.5	P	20 - 200
EPA 8270E	Simazine-d10	120	P	71 - 140
EPA 8270E	Terbufos-d10	86.3	P	62 - 131
EPA 8270E	Terphenyl-d14	113	P	52 - 141

Quality Assurance Report Calibration Verification

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Run ID: A113442

Included Lab Sample IDs: 2340377, 2340378

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
O-Phosphate-P	101	102	P/P	90 - 110
O-Phosphate-P	102	99.7	P/P	90 - 110

Reference Method: DEP SOP: NU-094-1

Run ID: A113443

Included Lab Sample IDs: 2340373, 2340374

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Color (true)	98.7	101	P/P	90 - 110

Reference Method: EPA 180.1 Rev. 2.0

Run ID: A113445

Included Lab Sample IDs: 2340373, 2340374

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Turbidity	98.5	98.0	P/P	95 - 105

Reference Method: EPA 8321B

Run ID: A113489

Included Lab Sample IDs: 2340386, 2340387

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
AMPA	104	110	P/P	60 - 160
AMPA	105	117	P/P	60 - 160
Endothall	69.4	75.7	P/P	60 - 160
Endothall	78.0	93.3	P/P	60 - 160
Glufosinate	77.9	78.4	P/P	60 - 160
Glufosinate	95.9	120	P/P	60 - 160
Glyphosate	103	110	P/P	60 - 160
Glyphosate	89.2	92.5	P/P	60 - 160

Reference Method: EPA 8321B

Run ID: A113494

Included Lab Sample IDs: 2340386

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Acesulfame K	101	99.6	P/P	60 - 160
Sucralose	98.6	96.4	P/P	60 - 160

Reference Method: EPA 8321B

Run ID: A113497

Included Lab Sample IDs: 2340387

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Acesulfame K	86.5	89.9	P/P	60 - 160
Sucralose	102	104	P/P	60 - 160

Quality Assurance Report Calibration Verification

Reference Method: EPA 8321B

Run ID: A113508

Included Lab Sample IDs: 2340386, 2340387

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
2,4-D	95.9	100	P/P	50 - 150
2,4-D	96.0	95.9	P/P	50 - 150
2,4,5-T	101	114	P/P	50 - 150
2,4,5-T	114	108	P/P	50 - 150
Acetaminophen	102	98.4	P/P	60 - 160
Acetaminophen	96.5	99.0	P/P	60 - 160
Acetamiprid	101	98.0	P/P	50 - 150
Acetamiprid	105	101	P/P	50 - 150
Afidopyropen	100	92.2	P/P	50 - 150
Afidopyropen	94.8	100	P/P	50 - 150
Bentazon	111	128	P/P	50 - 160
Bentazon	128	113	P/P	50 - 160
Benzovindiflupyr	110	97.5	P/P	50 - 150
Benzovindiflupyr	97.5	97.4	P/P	50 - 150
Carbamazepine	105	101	P/P	60 - 150
Carbamazepine	99.3	105	P/P	60 - 150
Clothianidin	111	94.3	P/P	60 - 150
Clothianidin	94.3	106	P/P	60 - 150
Dinotefuran	103	99.4	P/P	50 - 150
Dinotefuran	99.4	102	P/P	50 - 150
Diuron	103	86.0	P/P	60 - 160
Diuron	86.0	88.1	P/P	60 - 160
Fenuron	100	103	P/P	60 - 150
Fenuron	98.7	100	P/P	60 - 150
Fluridone	109	112	P/P	60 - 160
Fluridone	112	104	P/P	60 - 160
Hydrocodone	101	98.4	P/P	60 - 150
Hydrocodone	98.4	103	P/P	60 - 150
Ibuprofen	122	92.6	P/P	50 - 160
Ibuprofen	92.6	113	P/P	50 - 160
Imazapyr	86.3	97.3	P/P	50 - 150
Imazapyr	97.3	115	P/P	50 - 150
Imidacloprid	107	99.8	P/P	60 - 150
Imidacloprid	99.8	97.3	P/P	60 - 150
Linuron	93.2	96.4	P/P	60 - 150
Linuron	96.4	97.2	P/P	60 - 150
Mandestrobin	103	103	P/P	50 - 150
Mandestrobin	104	103	P/P	50 - 150
MCPP	103	112	P/P	50 - 150
MCPP	112	96.1	P/P	50 - 150
Naproxen	139	145	P/P	50 - 160
Naproxen	88.3	146	P/P	50 - 160
Primidone	101	99.9	P/P	60 - 150
Primidone	94.0	101	P/P	60 - 150
Pyraclostrobin	102	104	P/P	60 - 150
Pyraclostrobin	104	102	P/P	60 - 150
Silvex	84.0	93.3	P/P	50 - 150
Silvex	93.3	81.0	P/P	50 - 150
Thiamethoxam	102	101	P/P	50 - 150
Thiamethoxam	99.7	102	P/P	50 - 150
Tolfenpyrad	103	103	P/P	60 - 150

Quality Assurance Report Calibration Verification

Reference Method: EPA 8321B

Run ID: A113508

Included Lab Sample IDs: 2340386, 2340387

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Tolfenpyrad	105	103	P/P	60 - 150
Triclopyr	102	112	P/P	50 - 150
Triclopyr	112	99.8	P/P	50 - 150

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A113518

Included Lab Sample IDs: 2340393, 2340394

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Aluminum	97.9	98.5	P/P	90 - 110
Antimony	101	101	P/P	90 - 110
Arsenic	98.0	97.6	P/P	90 - 110
Beryllium	97.5	94.1	P/P	90 - 110
Boron	95.3	98.8	P/P	90 - 110
Cadmium	99.5	101	P/P	90 - 110
Chromium	97.6	96.7	P/P	90 - 110
Cobalt	99.3	98.9	P/P	90 - 110
Copper	94.9	93.9	P/P	90 - 110
Lead	95.6	96.4	P/P	90 - 110
Manganese	100	100	P/P	90 - 110
Molybdenum	98.2	98.0	P/P	90 - 110
Nickel	97.1	96.8	P/P	90 - 110
Selenium	98.8	98.0	P/P	90 - 110
Silver	102	103	P/P	90 - 110
Thallium	97.9	98.9	P/P	90 - 110

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A113519

Included Lab Sample IDs: 2340393, 2340394

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Barium	94.1	93.7	P/P	90 - 110

Reference Method: SM 5310 B-2011

Run ID: A113531

Included Lab Sample IDs: 2340375, 2340376

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Organic Carbon	97.6	97.6	P/P	90 - 110
Organic Carbon	98.2	97.6	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A113536

Included Lab Sample IDs: 2340375, 2340376

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
NO2NO3-N	102	102	P/P	90 - 110

Quality Assurance Report Calibration Verification

Reference Method: EPA 200.7 Rev. 4.4

Run ID: A113542

Included Lab Sample IDs: 2340393, 2340394

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Calcium	97.2	96.0	P/P	90 - 110
Iron	98.0	94.9	P/P	90 - 110
Magnesium	97.1	94.4	P/P	90 - 110
Potassium	99.9	97.6	P/P	90 - 110
Sodium	98.9	97.4	P/P	90 - 110
Strontium	106	103	P/P	90 - 110
Tin	101	97.6	P/P	90 - 110
Titanium	104	99.1	P/P	90 - 110
Vanadium	103	101	P/P	90 - 110
Zinc	101	96.0	P/P	90 - 110

Reference Method: SM 2320 B-2011

Run ID: A113576

Included Lab Sample IDs: 2340373, 2340374

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total Alkalinity	96.3	100	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A113582

Included Lab Sample IDs: 2340375, 2340376

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Kjeldahl Nitrogen	100	96.0	P/P	90 - 110
Kjeldahl Nitrogen	100	97.8	P/P	90 - 110

Reference Method: EPA 8270E

Run ID: A113600

Included Lab Sample IDs: 2340395, 2340396

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	96.1		P	80 - 120
Avobenzone	98.5		P	80 - 120
Octinoxate	95.2		P	80 - 120
Oxybenzone	98.5		P	80 - 120
PBDE-47	96.1		P	80 - 120
PBDE-99	96.7		P	80 - 120
Tri-o-cresyl Phosphate	97.0		P	80 - 120

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A113617

Included Lab Sample IDs: 2340375, 2340376

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	101	101	P/P	90 - 110

Reference Method: EPA 300.0 Rev. 2.1

Run ID: A113634

Included Lab Sample IDs: 2340373, 2340374

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
-----------	---------	---------	------------	----------------

Quality Assurance Report Calibration Verification

Reference Method: EPA 300.0 Rev. 2.1

Run ID: A113634

Included Lab Sample IDs: 2340373, 2340374

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Chloride	100	101	P/P	90 - 110
Sulfate	99.7	99.9	P/P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A113645

Included Lab Sample IDs: 2340375, 2340376

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Ammonia-N	99.0	98.9	P/P	90 - 110

Reference Method: EPA 8270E

Run ID: A113692

Included Lab Sample IDs: 2340395, 2340396

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Acetochlor	101		P	80 - 120
Alachlor	105		P	80 - 120
Ametryn	103		P	80 - 120
Atrazine	94.3		P	80 - 120
Atrazine Desethyl	94.7		P	80 - 120
Azinphos Methyl	102		P	80 - 120
Azoxystrobin	94.0		P	80 - 120
Bromacil	104		P	80 - 120
Butylate	98.0		P	80 - 120
Caffeine	103		P	80 - 120
Chlorfenapyr	97.6		P	80 - 120
Chlorpyrifos Ethyl	98.6		P	80 - 120
Chlorpyrifos Methyl	103		P	80 - 120
Coumaphos	104		P	80 - 120
Cyanazine	105		P	80 - 120
Cyprodinil	101		P	80 - 120
Demeton	95.9		P	80 - 120
Diazinon	96.5		P	80 - 120
Difenoconazole	108		P	80 - 120
Dimethenamid	104		P	80 - 120
Dimethomorph	100		P	80 - 120
Disulfoton	93.3		P	80 - 120
Dithiopyr	106		P	80 - 120
EPTC	100		P	80 - 120
Ethion	101		P	80 - 120
Ethoprop	100		P	80 - 120
Etridiazole	99.0		P	80 - 120
Fenamiphos	98.2		P	80 - 120
Fenbuconazole	102		P	80 - 120
Fipronil	107		P	80 - 120
Fipronil Desulfinyl	104		P	80 - 120
Fipronil Sulfide	97.9		P	80 - 120
Fipronil Sulfone	99.8		P	80 - 120
Fluazifop-P-butyl	98.1		P	80 - 120
Fludioxonil	99.0		P	80 - 120
Flumioxazin	97.2		P	80 - 120

Quality Assurance Report Calibration Verification

Reference Method: EPA 8270E

Run ID: A113692

Included Lab Sample IDs: 2340395, 2340396

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Flutolanil	103		P	80 - 120
Fluxapyroxad	107		P	80 - 120
Fonofos	99.4		P	80 - 120
Hexazinone	96.8		P	80 - 120
Imazalil	101		P	80 - 120
Iprodione	111		P	80 - 120
Loratadine	103		P	80 - 120
Malathion	97.9		P	80 - 120
Metaxyl	102		P	80 - 120
Metolachlor	99.7		P	80 - 120
Metribuzin	99.3		P	80 - 120
Mevinphos	99.2		P	80 - 120
Molinate	101		P	80 - 120
Myclobutanil	102		P	80 - 120
Naled	117		P	80 - 120
Napropamide	100		P	80 - 120
Oxadiazon	98.7		P	80 - 120
Oxyfluorfen	90.6		P	80 - 120
Parathion Ethyl	105		P	80 - 120
Parathion Methyl	93.7		P	80 - 120
Pendimethalin	91.3		P	80 - 120
Phenytol	102		P	80 - 120
Phorate	99.4		P	80 - 120
Prodiamine	91.0		P	80 - 120
Prometon	97.8		P	80 - 120
Prometryn	102		P	80 - 120
Pronamide	97.1		P	80 - 120
Propanil	96.7		P	80 - 120
Propargite	107		P	80 - 120
Propiconazole	91.0		P	80 - 120
Pyridaben	99.8		P	80 - 120
Pyriproxyfen	101		P	80 - 120
Simazine	102		P	80 - 120
Stirophos	104		P	80 - 120
Sulfentrazone	111		P	80 - 120
Tebuconazole	102		P	80 - 120
Terbufos	95.3		P	80 - 120
Terbuthylazine	101		P	80 - 120
Thiobencarb	104		P	80 - 120
Triadimefon	111		P	80 - 120

Reference Method: EPA 8270E

Run ID: A113705

Included Lab Sample IDs: 2340396

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Atrazine	94.3		P	80 - 120

Quality Assurance Report Calibration Verification

Reference Method: EPA 8270E

Run ID: A113716

Included Lab Sample IDs: 2340395, 2340396

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Carbophenothion	98.7		P	80 - 120
Carfentrazone Ethyl	98.8		P	80 - 120
Norflurazon	93.4		P	80 - 120
Pyraflufen Ethyl	101		P	80 - 120

Reference Method: SM 4500-F- C-2011

Run ID: A113778

Included Lab Sample IDs: 2340373, 2340374

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Fluoride	104	101	P/P	90 - 110

* Pass/Fail determinations are made for each bracketing calibration verification check.

Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.

Where they are different, both control limits are provided.

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery			LCS	Precision SMP	MS
DEP SOP: NU-094-1	Color (true)	98.5					0.591	
EPA 180.1 Rev. 2.0	Turbidity	95.0					3.72	
EPA 200.7 Rev. 4.4	Calcium	100	98.9	96.4				1.24
	Iron	101	102	99.9	98.3			1.64
	Magnesium	99.3	103	98.6	96.8			1.06
	Potassium	104	101	98.9	99.4			0.470
	Sodium	103	101	103	101			0.831
	Strontium	106	107	104	104			0.676
	Tin	99.9	99.3	96.3	95.8			0.586
	Titanium	104	106	101	100			0.914
	Vanadium	103	105	101	100			0.936
	Zinc	99.1	101	95.1	94.2			0.989
EPA 200.8 Rev. 5.4	Aluminum	104	100	103	102			1.59
	Antimony	105	104	107	104			2.89
	Arsenic	101	99.4	99.3	98.6			0.715
	Barium	97.6	99.1	104	98.2			4.89
	Beryllium	95.3	98.0	93.4	92.5			1.02
	Boron	103	98.0	108	105			2.34
	Cadmium	99.4	99.2	103	100			2.89
	Chromium	102	98.3	102	100			1.11
	Cobalt	103	99.3	101	99.5			1.76
	Copper	97.9	95.2	93.9	92.3			1.68
	Lead	99.5	98.3	100	99.0			1.14
	Manganese	104	100	104	102			1.49
	Molybdenum	101	99.1	103	102			0.793
	Nickel	101	97.2	98.4	97.4			0.995
	Selenium	102	99.8	97.0	97.6			0.570
	Silver	104	99.4	104	101			2.74
	Thallium	102	101	104	103			0.749
EPA 300.0 Rev. 2.1	Chloride	98.5	99.3	98.2			0.259	
	Sulfate	98.1	97.6	96.3			0.557	
EPA 350.1 Rev. 2.0	Ammonia-N	97.4	95.2	98.2				2.88
EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	107	101	95.6				4.52
	Kjeldahl Nitrogen	102	96.8	110				8.54
EPA 353.2 Rev. 2.0	NO2NO3-N	103	102	102				0.445
EPA 365.1 Rev. 2.0	Total-P	101	103	103				0.0
EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	99.7	91.3	86.7				3.61
	O-Phosphate-P	101	99.3	101				1.70
EPA 8270E	2-Ethylhexyl 2,3,4,5-tetrabromobenzoate (EHTBB)	99.1	96.0	87.3				9.42
	Acetochlor	95.7	102	107				4.48
	Alachlor	95.5	91.8	91.7				0.0879
	Ametryn	88.4	82.3	80.5				1.86
	Atrazine	91.4						4.66
	Atrazine Desethyl	57.2	60.9	62.6				2.36
	Avobenzone	91.3	93.0	85.6				8.31
	Azinphos Methyl	121	142	142				0.347
	Azoxystrobin	98.1	142	127				9.19
	Bromacil	94.2	82.7	98.9				14.7
	Butylate	58.7	59.9	60.8				1.38
	Caffeine	74.4	75.3	76.8				1.99
	Carbophenothion	92.4	82.5	82.4				0.0591
	Carfentrazone Ethyl	137	123	110				11.0

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		Precision SMP	MS
			LCS			
EPA 8270E	Chlorfenapyr	87.0	64.1	59.5		7.50
	Chlorpyrifos Ethyl	93.1	67.2	68.2		1.52
	Chlorpyrifos Methyl	94.6	83.5	81.3		2.65
	Coumaphos	124	100	81.3		20.8
	Cyanazine	85.6	85.9	85.7		0.286
	Cyprodinil	94.8	94.9	89.6		5.69
	Demeton	73.7	97.2	77.2		22.9
	Diazinon	100	111	119		7.74
	Difenoconazole	161	160	143		11.2
	Dimethenamid	80.7	87.0	82.1		5.75
	Dimethomorph	92.0	154	132		15.2
	Disulfoton	88.7	91.8	84.3		8.46
	Dithiopyr	98.0	99.7	90.9		8.43
	EPTC	48.7	54.6	57.6		5.32
	Ethion	103	50.7	34.5		37.9
	Ethoprop	80.4	104	99.1		4.50
	Etridiazole	51.2	70.7	76.8		8.29
	Fenamiphos	93.5	59.3	51.0		15.1
	Fenbuconazole	128	109	88.5		18.8
	Fipronil	96.8	97.0	90.8		6.60
	Fipronil Desulfinyl	96.5	96.4	91.9		4.77
	Fipronil Sulfide	83.4	59.3	49.8		17.4
	Fipronil Sulfone	93.7	79.1	73.4		7.44
	Fluazifop-P-butyl	102	84.4	69.5		19.3
	Fludioxonil	94.8	84.4	68.0		21.4
	Flumioxazin	153	166	149		10.4
	Flutolanil	99.9	85.2	85.4		0.234
	Fluxapyroxad	101	73.4	57.5		24.3
	Fonofos	84.3	85.0	78.0		8.62
	Hexazinone	103	103	94.2		8.78
	Imazalil	80.3	78.8	96.1		19.8
	Iprodione	134	111	96.6		14.2
	Loratadine	162	144	131		8.94
	Malathion	104	95.9	98.8		2.90
	Metalaxyl	92.5				1.99
	Metolachlor	89.9	89.9	93.4		3.47
	Metribuzin	94.7	102	110		7.63
	Mevinphos	64.9	109	99.0		9.66
	Molinate	68.1	82.5	83.2		0.905
	Myclobutanil	100	89.2	81.6		8.93
	Naled	82.8	83.4	79.5		4.75
	Napropamide	85.1	78.4	65.6		17.7
	Norflurazon	105				5.74
	Octinoxate	131	119	92.6		20.4
	Oxadiazon	85.7	82.4	71.8		13.9
	Oxybenzone	87.2	94.2	86.3		8.74
	Oxyfluorfen	114	103	83.0		21.7
	Parathion Ethyl	101	113	102		10.0
	Parathion Methyl	102	117	110		5.67
	PBDE-47	90.6	78.2	70.1		10.9
	PBDE-99	96.5	79.8	70.7		12.2
	Pendimethalin	105	103	94.7		8.56
	Phenytol	42.7	13.9	11.3		20.4
	Phorate	80.3	161	155		3.68

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		LCS	Precision	MS
						SMP	
EPA 8270E	Prodiamine	77.3	39.9	51.4			25.2
	Prometon	82.8	92.4	85.9			7.23
	Prometryn	94.4	90.0	88.9			1.16
	Pronamide	92.8	119	121			1.91
	Propanil	92.4	99.2	93.3			6.17
	Propargite	123	73.8	53.3			32.3
	Propiconazole	65.3	105	86.5			15.4
	Pyraflufen Ethyl	121	106	98.4			7.84
	Pyridaben	126	119	101			16.3
	Pyriproxyfen	122	87.8	78.2			11.5
	Simazine	91.8					1.39
	Stirophos	98.0	39.5	37.1			6.35
	Sulfentrazone	115	107	108			0.607
	Tebuconazole	97.6	31.3	18.8			50.0
	Terbufos	102	113	106			5.92
	Terbuthylazine	93.6	92.6	101			8.34
	Thiobencarb	89.4	89.7	100			11.1
	Tri-o-cresyl Phosphate	96.2	95.7	86.4			10.2
	Triadimefon	95.6	91.7	83.2			9.73
EPA 8321B	2,4-D	86.0	93.4	96.3			3.12
	2,4-D	77.5	88.3	84.5			3.08
	2,4,5-T	74.9	80.3	89.6			10.9
	2,4,5-T	71.2	60.0	67.6			12.0
	Acesulfame K	95.5	79.5	92.9			15.6
	Acesulfame K	88.1	75.9	76.4			0.698
	Acetaminophen	86.0	90.6	93.3			2.96
	Acetaminophen	93.5	113	107			5.18
	Acetamiprid	89.8	77.9	92.8			17.4
	Acetamiprid	85.0	86.8	87.1			0.388
	Afidopyropen	62.8	58.5	63.3			7.88
	Afidopyropen	60.7	74.5	74.7			0.284
	AMPA	108	102	128			22.3
	AMPA	113	96.9	97.2			0.270
	Bentazon	84.2	79.0	76.6			3.06
	Bentazon	97.0	85.4	84.3			0.830
	Benzovindiflupyr	74.1	89.1	86.5			2.96
	Benzovindiflupyr	90.0	87.7	89.8			2.40
	Carbamazepine	83.3	88.6	93.8			5.73
	Carbamazepine	93.0	97.3	97.1			0.259
	Clothianidin	92.5	103	95.3			7.88
	Clothianidin	100	115	119			3.83
	Dinotefuran	91.6	100	107			6.83
	Dinotefuran	104	139	135			2.76
	Diuron	53.5	79.5	65.2			19.7
	Diuron	84.7	83.6	69.2			18.2
	Endothall	93.8	78.7	89.5			12.9
	Endothall	80.3	83.3	81.1			2.66
	Fenuron	84.9	85.8	88.7			3.41
	Fenuron	107	90.4	92.5			2.34
	Fluridone	79.6	81.8	80.5			1.57
	Fluridone	99.3	81.6	88.4			7.92
	Glufosinate	104	88.9	106			17.8
	Glufosinate	111	72.7	70.8			2.62
	Glyphosate	99.2	70.1	88.1			22.7

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		Precision	
					LCS	MS
EPA 8321B	Glyphosate	108	84.2	88.5		5.07
	Hydrocodone	86.0	91.9	92.9		1.12
	Hydrocodone	97.9	101	104		3.04
	Ibuprofen	75.1	83.7	66.5		22.9
	Ibuprofen	82.0	72.6	73.6		1.44
	Imazapyr	90.6	87.5	89.9		2.70
	Imazapyr	94.2	92.3	86.0		7.09
	Imidacloprid	115	133	128		3.87
	Imidacloprid	110	146	149		1.69
	Linuron	80.3	80.1	77.3		3.52
	Linuron	104	88.3	91.2		3.16
	Mandestrobin	76.7	78.6	81.1		3.05
	Mandestrobin	89.0	76.2	80.5		5.41
	MCPP	84.1	91.9	99.6		8.06
	MCPP	83.2	94.9	80.0		17.0
	Naproxen	59.1	54.2	75.8		33.2
	Naproxen	64.4	74.9	86.2		14.0
	Primidone	90.9	92.8	97.6		5.04
	Primidone	101	101	107		5.65
	Pyraclostrobin	82.0	81.8	86.5		5.62
	Pyraclostrobin	81.3	85.9	89.4		4.02
	Silvex	68.2	82.2	82.6		0.531
	Silvex	67.7	70.9	82.8		15.5
	Sucralose	96.4	79.5	94.8		16.0
	Sucralose	105	98.5	99.2		0.509
	Thiamethoxam	86.5	94.0	101		7.59
	Thiamethoxam	99.6	129	135		4.54
	Tolfenpyrad	56.5	55.1	54.0		1.97
	Tolfenpyrad	44.7	49.4	49.6		0.481
	Triclopyr	83.1	87.4	106		19.5
	Triclopyr	77.4	71.7	80.8		11.9
SM 2320 B-2011	Total Alkalinity	99.5			1.29	
	Total Alkalinity	99.5			1.00	
SM 2540 C-2011	TDS				3.15	
	TDS				7.54	
SM 4500-F- C-2011	Fluoride	103	103	104		0.953
SM 5310 B-2011	Organic Carbon	98.3	100	100		0.0996

Reference Method Descriptions

Method	Description	Associated Samples
DEP SOP: NU-094-1	True Color measured at 450 nm (not valid for NPDES monitoring)	2340373, 2340374
EPA 180.1 Rev. 2.0	Turbidity in aqueous matrices	2340373, 2340374
EPA 200.7 Rev. 4.4	Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	2340393, 2340394
EPA 200.8 Rev. 5.4	Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects	2340393, 2340394
EPA 300.0 Rev. 2.1	Chloride in aqueous matrices	2340373, 2340374
EPA 300.0 Rev. 2.1	Sulfate in aqueous matrices	2340373, 2340374
EPA 350.1 Rev. 2.0	Ammonia in aqueous matrices as mg N/L	2340375, 2340376
EPA 351.2 Rev. 2.0	Total Kjeldahl Nitrogen in aqueous matrices	2340375, 2340376
EPA 353.2 Rev. 2.0	Nitrite/Nitrate in aqueous matrices as mg N/L	2340375, 2340376
EPA 365.1 Rev. 2.0	Total Phosphorus in aqueous matrices as mg P/L	2340375, 2340376

Reference Method Descriptions

Method	Description	<u>Associated Samples</u>
EPA 365.1 Rev. 2.0 dissolved	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	2340377, 2340378
EPA 8270E	Analysis of Sunscreen Compounds and Flame Retardants in Water by GC/MS-SIM	2340395, 2340396
EPA 8270E	Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS	2340395, 2340396
EPA 8321B	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	2340386, 2340387
SM 2320 B-2011	Alkalinity in aqueous matrices as mg CaCO ₃ /L	2340373, 2340374
SM 2340 B-2011	Hardness by calculation, in aqueous matrices, reported as mg/L CaCO ₃	2340393, 2340394
SM 2540 C-2011	Total Dissolved Solids in aqueous matrices	2340373, 2340374
SM 2540 D-2011	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	2340373, 2340374
SM 4500-F- C-2011	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	2340373, 2340374
SM 5310 B-2011	Nonpurgeable Organic Carbon in aqueous matrices	2340375, 2340376

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
DEP SOP: NU-094-1	07/12/2022			07/12/2022 15:40	Samantha L Bates	2340373
	07/12/2022			07/12/2022 15:41	Samantha L Bates	2340374
EPA 180.1 Rev. 2.0	07/12/2022			07/12/2022 13:40	Khloe J Berg	2340373
	07/12/2022			07/12/2022 13:41	Khloe J Berg	2340374
EPA 200.7 Rev. 4.4	07/12/2022	07/14/2022 09:59	Mackenzie Hunt	07/15/2022 20:54	McKinley C Carter	2340393
	07/12/2022	07/14/2022 09:59	Mackenzie Hunt	07/15/2022 21:02	McKinley C Carter	2340394
EPA 200.8 Rev. 5.4	07/12/2022	07/14/2022 09:59	Mackenzie Hunt	07/14/2022 17:47	Megan Whitefoot	2340393
	07/12/2022	07/14/2022 09:59	Mackenzie Hunt	07/14/2022 17:56	Megan Whitefoot	2340394
	07/12/2022	07/14/2022 09:59	Mackenzie Hunt	07/15/2022 03:59	Emily M Philpot	2340393
	07/12/2022	07/14/2022 09:59	Mackenzie Hunt	07/15/2022 04:05	Emily M Philpot	2340394
	07/12/2022			07/19/2022 20:54	Anna M. Plaviak	2340373
EPA 300.0 Rev. 2.1	07/12/2022			07/19/2022 21:06	Anna M. Plaviak	2340374
	07/12/2022			07/21/2022 12:57	Ping Hua	2340376
EPA 350.1 Rev. 2.0	07/12/2022			07/21/2022 13:04	Ping Hua	2340375
	07/12/2022	07/18/2022 16:27	Samantha L Bates	07/19/2022 12:11	Alexandra J Mattheus	2340375
EPA 351.2 Rev. 2.0	07/12/2022	07/18/2022 16:27	Samantha L Bates	07/19/2022 13:06	Alexandra J Mattheus	2340376
	07/12/2022			07/15/2022 11:32	Judith K. Clark	2340375
EPA 353.2 Rev. 2.0	07/12/2022			07/15/2022 11:34	Judith K. Clark	2340376
	07/12/2022	07/19/2022 16:00	Adam P Silver	07/20/2022 14:09	James L Waggeberby	2340375
EPA 365.1 Rev. 2.0	07/12/2022	07/19/2022 16:00	Adam P Silver	07/20/2022 14:10	James L Waggeberby	2340376
	07/12/2022			07/12/2022 14:51	Chandler E Cox	2340377
EPA 365.1 Rev. 2.0 dissolved	07/12/2022			07/12/2022 14:59	Chandler E Cox	2340378
	07/12/2022	07/14/2022 08:00	Rasheda Ghaffari	07/17/2022 20:52	Michael Poppell	2340395
EPA 8270E	07/12/2022	07/14/2022 08:00	Rasheda Ghaffari	07/17/2022 21:18	Michael Poppell	2340396
	07/12/2022	07/14/2022 08:00	Rasheda Ghaffari	07/19/2022 20:22	Arthur Maknenko	2340395
	07/12/2022	07/14/2022 08:00	Rasheda Ghaffari	07/19/2022 20:41	Arthur Maknenko	2340396
	07/12/2022	07/14/2022 08:00	Rasheda Ghaffari	07/23/2022 23:42	Michael Poppell	2340396
	07/12/2022	07/14/2022 08:00	Rasheda Ghaffari	07/26/2022 20:09	Michael Poppell	2340395
	07/12/2022	07/14/2022 08:00	Rasheda Ghaffari	07/26/2022 20:35	Michael Poppell	2340396
	07/12/2022	07/12/2022 12:00	Manjita Shrestha	07/12/2022 16:09	Umesh Chiluwal	2340386
	07/12/2022	07/12/2022 12:00	Manjita Shrestha	07/13/2022 00:04	Manjita Shrestha	2340386
	07/12/2022	07/13/2022 09:00	Hoor Shaik	07/14/2022 14:21	Juyoung Kim	2340386
	07/12/2022	07/13/2022 11:00	Umesh Chiluwal	07/13/2022 13:18	Umesh Chiluwal	2340387
EPA 8321B	07/12/2022	07/13/2022 11:00	Umesh Chiluwal	07/13/2022 23:57	Umesh Chiluwal	2340387
	07/12/2022	07/14/2022 09:00	June Rhew	07/14/2022 16:26	Juyoung Kim	2340387
	07/12/2022			07/15/2022 03:52	Dale L. Simmons	2340373
	07/12/2022			07/15/2022 05:13	Dale L. Simmons	2340374
	07/12/2022			07/15/2022 20:54	McKinley C Carter	2340393
	07/12/2022			07/15/2022 21:02	McKinley C Carter	2340394
	07/12/2022			07/13/2022 16:09	Yijie Li	2340373, 2340374
	07/12/2022					
	07/12/2022					
	07/12/2022					
SM 2320 B-2011	07/12/2022					
SM 2340 B-2011	07/12/2022					
	07/12/2022					
SM 2540 C-2011	07/12/2022					
	07/12/2022					

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
SM 2540 D-2011	07/12/2022			07/13/2022 16:09	Yijie Li	2340373, 2340374
SM 4500-F- C-2011	07/12/2022			07/29/2022 05:48	Dale L. Simmons	2340373
	07/12/2022			07/29/2022 05:53	Dale L. Simmons	2340374
SM 5310 B-2011	07/12/2022			07/14/2022 17:03	Khloe J Berg	2340375
	07/12/2022			07/14/2022 20:00	Khloe J Berg	2340376